






NTNV-N41-PC3-30-60-L-DFT-QPSK-Edge\_1RB\_Left-18000-3000  
0-Ant1-PASS




NTNV-N41-PC3-30-60-L-DFT-QPSK-Edge\_1RB\_Right-0.009-0.1  
5-Ant1-PASS





NTNV-N41-PC3-30-60-L-DFT-QPSK-Edge\_1RB\_Right-0.15-30-A  
nt1-PASS




NTNV-N41-PC3-30-60-L-DFT-QPSK-Edge\_1RB\_Right-30-1000-  
Ant1-PASS




NTNV-N41-PC3-30-60-L-DFT-QPSK-Edge\_1RB\_Right-1000-3000  
-Ant1-PASS

NTNV-N41-PC3-30-60-L-DFT-QPSK-Edge\_1RB\_Right-3000-180  
00-Ant1-PASSNTNV-N41-PC3-30-60-L-DFT-QPSK-Edge\_1RB\_Right-18000-300  
00-Ant1-PASS


NTNV-N41-PC3-30-60-M-DFT-PI2BPSK-Edge\_1RB\_Left-0.009-0.15-Ant1-PASS




NTNV-N41-PC3-30-60-M-DFT-PI2BPSK-Edge\_1RB\_Left-0.15-30-Ant1-PASS




NTNV-N41-PC3-30-60-M-DFT-PI2BPSK-Edge\_1RB\_Left-30-100-0-Ant1-PASS




NTNV-N41-PC3-30-60-M-DFT-PI2BPSK-Edge\_1RB\_Left-1000-30-00-Ant1-PASS




NTNV-N41-PC3-30-60-M-DFT-PI2BPSK-Edge\_1RB\_Left-3000-1-8000-Ant1-PASS




NTNV-N41-PC3-30-60-M-DFT-PI2BPSK-Edge\_1RB\_Left-18000-3  
0000-Ant1-PASS




NTNV-N41-PC3-30-60-M-DFT-PI2BPSK-Edge\_1RB\_Right-0.009  
-0.15-Ant1-PASS




NTNV-N41-PC3-30-60-M-DFT-PI2BPSK-Edge\_1RB\_Right-0.15-3  
0-Ant1-PASS



NTNV-N41-PC3-30-60-M-DFT-PI2BPSK-Edge\_1RB\_Right-30-10  
00-Ant1-PASS




NTNV-N41-PC3-30-60-M-DFT-PI2BPSK-Edge\_1RB\_Right-1000-3000-Ant1-PASS




NTNV-N41-PC3-30-60-M-DFT-PI2BPSK-Edge\_1RB\_Right-3000-18000-Ant1-PASS



NTNV-N41-PC3-30-60-M-DFT-PI2BPSK-Edge\_1RB\_Right-18000-30000-Ant1-PASS




NTNV-N41-PC3-30-60-M-DFT-QPSK-Edge\_1RB\_Left-0.009-0.15-Ant1-PASS




NTNV-N41-PC3-30-60-M-DFT-QPSK-Edge\_1RB\_Left-0.15-30-Ant  
1-PASS




NTNV-N41-PC3-30-60-M-DFT-QPSK-Edge\_1RB\_Left-30-1000-A  
nt1-PASS



NTNV-N41-PC3-30-60-M-DFT-QPSK-Edge\_1RB\_Left-1000-3000-  
Ant1-PASS




NTNV-N41-PC3-30-60-M-DFT-QPSK-Edge\_1RB\_Left-3000-1800  
0-Ant1-PASS

NTNV-N41-PC3-30-60-M-DFT-QPSK-Edge\_1RB\_Left-18000-300  
00-Ant1-PASS


NTNV-N41-PC3-30-60-M-DFT-QPSK-Edge\_1RB\_Right-0.009-0.  
15-Ant1-PASS




NTNV-N41-PC3-30-60-M-DFT-QPSK-Edge\_1RB\_Right-0.15-30-A  
nt1-PASS




NTNV-N41-PC3-30-60-M-DFT-QPSK-Edge\_1RB\_Right-30-1000-  
Ant1-PASS



NTNV-N41-PC3-30-60-M-DFT-QPSK-Edge\_1RB\_Right-1000-300  
0-Ant1-PASS




NTNV-IN41-PC3-30-60-M-DFT-QPSK-Edge\_1RB\_Right-3000-18  
000-Ant1-PASS




NTNV-N41-PC3-30-60-M-DFT-QPSK-Edge\_1RB\_Right-18000-30  
000-Ant1-PASS



NTNV-N41-PC3-30-60-H-DFT-PI2BPSK-Edge\_1RB\_Left-0.009-0.15-Ant1-PASS



NTNV-N41-PC3-30-60-H-DFT-PI2BPSK-Edge\_1RB\_Left-0.15-30-Ant1-PASS




NTNV-N41-PC3-30-60-H-DFT-PI2BPSK-Edge\_1RB\_Left-30-100-0-Ant1-PASS




NTNV-N41-PC3-30-60-H-DFT-PI2BPSK-Edge\_1RB\_Left-1000-30-00-Ant1-PASS





NTNV-N41-PC3-30-60-H-DFT-PI2BPSK-Edge\_1RB\_Left-3000-1-8000-Ant1-PASS




NTNV-N41-PC3-30-60-H-DFT-PI2BPSK-Edge\_1RB\_Left-18000-3  
0000-Ant1-PASS




NTNV-N41-PC3-30-60-H-DFT-PI2BPSK-Edge\_1RB\_Right-0.009-  
0.15-Ant1-PASS


NTNV-N41-PC3-30-60-H-DFT-P12BPSK-Edge\_1RB\_Right-0.15-3  
0-Ant1-PASSNTNV-N41-PC3-30-60-H-DFT-PI2BPSK-Edge\_1RB\_Right-30-10  
00-Ant1-PASS




NTNV-N41-PC3-30-60-H-DFT-PI2BPSK-Edge\_1RB\_Right-1000-3  
000-Ant1-PASS




NTNV-N41-PC3-30-60-H-DFT-PI2BPSK-Edge\_1RB\_Right-3000-18000-Ant1-PASS




NTNV-N41-PC3-30-60-H-DFT-PI2BPSK-Edge\_1RB\_Right-18000-30000-Ant1-PASS



NTNV-N41-PC3-30-60-H-DFT-QPSK-Edge\_1RB\_Left-0.009-0.15  
-Ant1-PASS



NTNV-N41-PC3-30-60-H-DFT-QPSK-Edge\_1RB\_Left-0.15-30-Ant  
1-PASS




NTNV-N41-PC3-30-60-H-DFT-QPSK-Edge\_1RB\_Left-30-1000-A  
nt1-PASS




NTNV-N41-PC3-30-60-H-DFT-QPSK-Edge\_1RB\_Left-1000-3000-  
Ant1-PASS




NTNV-N41-PC3-30-60-H-DFT-QPSK-Edge\_1RB\_Left-3000-1800  
0-Ant1-PASS




NTNV-N41-PC3-30-60-H-DFT-QPSK-Edge\_1RB\_Left-18000-3000  
0-Ant1-PASS






NTNV-N41-PC3-30-60-H-DFT-QPSK-Edge\_1RB\_Right-0.009-0.1  
5-Ant1-PASS




NTNV-N41-PC3-30-60-H-DFT-QPSK-Edge\_1RB\_Right-0.15-30-A  
nt1-PASS




NTNV-N41-PC3-30-60-H-DFT-QPSK-Edge\_1RB\_Right-30-1000-  
Ant1-PASS

NTNV-N41-PC3-30-60-H-DFT-QPSK-Edge\_1RB\_Right-1000-300  
0-Ant1-PASSNTNV-N41-PC3-30-60-H-DFT-QPSK-Edge\_1RB\_Right-3000-180  
00-Ant1-PASSNTNV-N41-PC3-30-60-H-DFT-QPSK-Edge\_1RB\_Right-18000-30  
000-Ant1-PASS


NTNV-N41-PC3-30-70-L-DFT-PI2BPSK-Edge\_1RB\_Left-0.009-0.  
15-Ant1-PASS




NTNV-N41-PC3-30-70-L-DFT-PI2BPSK-Edge\_1RB\_Left-0.15-30-Ant1-PASS





NTNV-N41-PC3-30-70-L-DFT-PI2BPSK-Edge\_1RB\_Left-30-1000-Ant1-PASS





NTNV-N41-PC3-30-70-L-DFT-PI2BPSK-Edge\_1RB\_Left-1000-3000-Ant1-PASS





NTNV-N41-PC3-30-70-L-DFT-PI2BPSK-Edge\_1RB\_Left-3000-18000-Ant1-PASS


NTNV-N41-PC3-30-70-L-DFT-PI2BPSK-Edge\_1RB\_Left-18000-3  
0000-Ant1-PASS

NTNV-N41-PC3-30-70-L-DFT-PI2BPSK-Edge\_1RB\_Right-0.009-0.15-Ant1-PASS

NTNV-N41-PC3-30-70-L-DFT-PI2BPSK-Edge\_1RB\_Right-0.15-30  
-Ant1-PASSNTNV-N41-PC3-30-70-L-DFT-PI2BPSK-Edge\_1RB\_Right-30-10  
00-Ant1-PASS

NTNV-N41-PC3-30-70-L-DFT-PI2BPSK-Edge\_1RB\_Right-1000-3  
000-Ant1-PASS


NTNV-N41-PC3-30-70-L-DFT-PI2BPSK-Edge\_1RB\_Right-3000-18000-Ant1-PASS




NTNV-N41-PC3-30-70-L-DFT-PI2BPSK-Edge\_1RB\_Right-18000-30000-Ant1-PASS




NTNV-N41-PC3-30-70-L-DFT-QPSK-Edge\_1RB\_Left-0.009-0.15-  
Ant1-PASS




NTNV-N41-PC3-30-70-L-DFT-QPSK-Edge\_1RB\_Left-0.15-30-Ant  
1-PASS




NTNV-N41-PC3-30-70-L-DFT-QPSK-Edge\_1RB\_Left-30-1000-A  
nt1-PASS




NTNV-N41-PC3-30-70-L-DFT-QPSK-Edge\_1RB\_Left-1000-3000-Ant1-PASS




NTNV-N41-PC3-30-70-L-DFT-QPSK-Edge\_1RB\_Left-3000-1800  
0-Ant1-PASS




NTNV-N41-PC3-30-70-L-DFT-QPSK-Edge\_1RB\_Left-18000-3000  
0-Ant1-PASS



NTNV-N41-PC3-30-70-L-DFT-QPSK-Edge\_1RB\_Right-0.009-0.1  
5-Ant1-PASS



NTNV-N41-PC3-30-70-L-DFT-QPSK-Edge\_1RB\_Right-0.15-30-A  
nt1-PASS




NTNV-N41-PC3-30-70-L-DFT-QPSK-Edge\_1RB\_Right-30-1000-  
Ant1-PASS




NTNV-N41-PC3-30-70-L-DFT-QPSK-Edge\_1RB\_Right-1000-3000  
-Ant1-PASS



NTNV-N41-PC3-30-70-L-DFT-QPSK-Edge\_1RB\_Right-3000-180  
00-Ant1-PASS



NTNV-N41-PC3-30-70-L-DFT-QPSK-Edge\_1RB\_Right-18000-300  
00-Ant1-PASS



NTNV-N41-PC3-30-70-M-DFT-PI2BPSK-Edge\_1RB\_Left-0.009-0.15-Ant1-PASS