







NTNV-N41-PC3-30-80-M-DFT-PI2BPSK-Edge_1RB_Right-1000-3
000-Ant1-PASS




NTNV-N41-PC3-30-80-M-DFT-PI2BPSK-Edge_1RB_Right-3000-18000-Ant1-PASS




NTNV-N41-PC3-30-80-M-DFT-PI2BPSK-Edge_1RB_Right-18000-30000-Ant1-PASS

NTNV-N41-PC3-30-80-M-DFT-QPSK-Edge_1RB_Left-0.009-0.15
-Ant1-PASS



NTNV-N41-PC3-30-80-M-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant
1-PASS




NTNV-N41-PC3-30-80-M-DFT-QPSK-Edge_1RB_Left-30-1000-A
nt1-PASS




NTNV-N41-PC3-30-80-M-DFT-QPSK-Edge_1RB_Left-1000-3000-
Ant1-PASS




NTNV-N41-PC3-30-80-M-DFT-QPSK-Edge_1RB_Left-3000-1800
0-Ant1-PASS




NTNV-N41-PC3-30-80-M-DFT-QPSK-Edge_1RB_Left-18000-300
00-Ant1-PASS




NTNV-N41-PC3-30-80-M-DFT-QPSK-Edge_1RB_Right-0.009-0.
15-Ant1-PASS




NTNV-N41-PC3-30-80-M-DFT-QPSK-Edge_1RB_Right-0.15-30-A
nt1-PASS



NTNV-N41-PC3-30-80-M-DFT-QPSK-Edge_1RB_Right-30-1000-
Ant1-PASS




NTNV-N41-PC3-30-80-M-DFT-QPSK-Edge_1RB_Right-1000-300
0-Ant1-PASS




NTNV-N41-PC3-30-80-M-DFT-QPSK-Edge_1RB_Right-3000-18
000-Ant1-PASS




NTNV-N41-PC3-30-80-M-DFT-QPSK-Edge_1RB_Right-18000-30
000-Ant1-PASS




NTNV-N41-PC3-30-80-H-DFT-PI2BPSK-Edge_1RB_Left-0.009-0
.15-Ant1-PASS




NTNV-N41-PC3-30-80-H-DFT-PI2BPSK-Edge_1RB_Left-0.15-30-Ant1-PASS




NTNV-N41-PC3-30-80-H-DFT-PI2BPSK-Edge_1RB_Left-30-100-0-Ant1-PASS




NTNV-N41-PC3-30-80-H-DFT-PI2BPSK-Edge_1RB_Left-1000-30-00-Ant1-PASS




NTNV-N41-PC3-30-80-H-DFT-PI2BPSK-Edge_1RB_Left-3000-1-8000-Ant1-PASS




NTNV-N41-PC3-30-80-H-DFT-PI2BPSK-Edge_1RB_Left-18000-30000-Ant1-PASS





NTNV-N41-PC3-30-80-H-DFT-PI2BPSK-Edge_1RB_Right-0.009-0.15-Ant1-PASS




NTNV-N41-PC3-30-80-H-DFT-PI2BPSK-Edge_1RB_Right-0.15-30-Ant1-PASS



NTNV-N41-PC3-30-80-H-DFT-PI2BPSK-Edge_1RB_Right-30-1000-Ant1-PASS


NTNV-N41-PC3-30-80-H-DFT-PI2BPSK-Edge_1RB_Right-1000-3
000-Ant1-PASS

NTNV-N41-PC3-30-80-H-DFT-PI2BPSK-Edge_1RB_Right-3000-18000-Ant1-PASS




NTNV-N41-PC3-30-80-H-DFT-PI2BPSK-Edge_1RB_Right-18000-30000-Ant1-PASS

NTNV-N41-PC3-30-80-H-DFT-QPSK-Edge_1RB_Left-0.009-0.15
-Ant1-PASS




NTNV-N41-PC3-30-80-H-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant
1-PASS




NTNV-N41-PC3-30-80-H-DFT-QPSK-Edge_1RB_Left-30-1000-A
nt1-PASS




NTNV-N41-PC3-30-80-H-DFT-QPSK-Edge_1RB_Left-1000-3000-
Ant1-PASS




NTNV-N41-PC3-30-80-H-DFT-QPSK-Edge_1RB_Left-3000-1800
0-Ant1-PASS




NTNV-N41-PC3-30-80-H-DFT-QPSK-Edge_1RB_Left-18000-3000
0-Ant1-PASS






NTNV-N41-PC3-30-80-H-DFT-QPSK-Edge_1RB_Right-0.009-0.1
5-Ant1-PASS




NTNV-N41-PC3-30-80-H-DFT-QPSK-Edge_1RB_Right-0.15-30-A
nt1-PASS




NTNV-N41-PC3-30-80-H-DFT-QPSK-Edge_1RB_Right-30-1000-
Ant1-PASS

NTNV-N41-PC3-30-80-H-DFT-QPSK-Edge_1RB_Right-1000-300
0-Ant1-PASSNTNV-N41-PC3-30-80-H-DFT-QPSK-Edge_1RB_Right-3000-180
00-Ant1-PASS


NTNV-N41-PC3-30-80-H-DFT-QPSK-Edge_1RB_Right-18000-30
000-Ant1-PASS




NTNV-N41-PC3-30-90-L-DFT-PI2BPSK-Edge_1RB_Left-0.009-0.
15-Ant1-PASS



NTNV-N41-PC3-30-90-L-DFT-PI2BPSK-Edge_1RB_Left-0.15-30-
Ant1-PASS



NTNV-N41-PC3-30-90-L-DFT-PI2BPSK-Edge_1RB_Left-30-1000
-Ant1-PASS




NTNV-N41-PC3-30-90-L-DFT-PI2BPSK-Edge_1RB_Left-1000-30
00-Ant1-PASS




NTNV-N41-PC3-30-90-L-DFT-PI2BPSK-Edge_1RB_Left-3000-18
000-Ant1-PASS




NTNV-N41-PC3-30-90-L-DFT-PI2BPSK-Edge_1RB_Left-18000-30000-Ant1-PASS





NTNV-N41-PC3-30-90-L-DFT-PI2BPSK-Edge_1RB_Right-0.009-0.15-Ant1-PASS




NTNV-N41-PC3-30-90-L-DFT-PI2BPSK-Edge_1RB_Right-0.15-30-Ant1-PASS




NTNV-N41-PC3-30-90-L-DFT-PI2BPSK-Edge_1RB_Right-30-1000-Ant1-PASS

NTNV-N41-PC3-30-90-L-DFT-PI2BPSK-Edge_1RB_Right-1000-3
000-Ant1-PASS


NTNV-N41-PC3-30-90-L-DFT-PI2BPSK-Edge_1RB_Right-3000-18000-Ant1-PASS




NTNV-N41-PC3-30-90-L-DFT-PI2BPSK-Edge_1RB_Right-18000-30000-Ant1-PASS




NTNV-N41-PC3-30-90-L-DFT-QPSK-Edge_1RB_Left-0.009-0.15-
Ant1-PASS




NTNV-N41-PC3-30-90-L-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant
1-PASS



NTNV-N41-PC3-30-90-L-DFT-QPSK-Edge_1RB_Left-30-1000-A
nt1-PASS




NTNV-N41-PC3-30-90-L-DFT-QPSK-Edge_1RB_Left-1000-3000-
Ant1-PASS




NTNV-N41-PC3-30-90-L-DFT-QPSK-Edge_1RB_Left-3000-1800
0-Ant1-PASS




NTNV-N41-PC3-30-90-L-DFT-QPSK-Edge_1RB_Left-18000-3000
0-Ant1-PASS




NTNV-N41-PC3-30-90-L-DFT-QPSK-Edge_1RB_Right-0.009-0.1
5-Ant1-PASS





NTNV-N41-PC3-30-90-L-DFT-QPSK-Edge_1RB_Right-0.15-30-A
nt1-PASS




NTNV-N41-PC3-30-90-L-DFT-QPSK-Edge_1RB_Right-30-1000-
Ant1-PASS




NTNV-N41-PC3-30-90-L-DFT-QPSK-Edge_1RB_Right-1000-3000
-Ant1-PASS

NTNV-N41-PC3-30-90-L-DFT-QPSK-Edge_1RB_Right-3000-180
00-Ant1-PASSNTNV-N41-PC3-30-90-L-DFT-QPSK-Edge_1RB_Right-18000-300
00-Ant1-PASS


NTNV-N41-PC3-30-90-M-DFT-PI2BPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS




NTNV-N41-PC3-30-90-M-DFT-PI2BPSK-Edge_1RB_Left-0.15-30-
Ant1-PASS




NTNV-N41-PC3-30-90-M-DFT-PI2BPSK-Edge_1RB_Left-30-100
0-Ant1-PASS




NTNV-N41-PC3-30-90-M-DFT-PI2BPSK-Edge_1RB_Left-1000-30
00-Ant1-PASS





NTNV-N41-PC3-30-90-M-DFT-PI2BPSK-Edge_1RB_Left-3000-1
8000-Ant1-PASS





NTNV-N41-PC3-30-90-M-DFT-PI2BPSK-Edge_1RB_Left-18000-3
0000-Ant1-PASS




NTNV-N41-PC3-30-90-M-DFT-PI2BPSK-Edge_1RB_Right-0.009
-0.15-Ant1-PASS


NTNV-N41-PC3-30-90-M-DFT-PI2BPSK-Edge_1RB_Right-0.15-3
0-Ant1-PASSNTNV-N41-PC3-30-90-M-DFT-PI2BPSK-Edge_1RB_Right-30-10
00-Ant1-PASS


NTNV-N41-PC3-30-90-M-DFT-PI2BPSK-Edge_1RB_Right-1000-3
000-Ant1-PASS

NTNV-N41-PC3-30-90-M-DFT-PI2BPSK-Edge_1RB_Right-3000-18000-Ant1-PASS




NTNV-N41-PC3-30-90-M-DFT-PI2BPSK-Edge_1RB_Right-18000-30000-Ant1-PASS

NTNV-N41-PC3-30-90-M-DFT-QPSK-Edge_1RB_Left-0.009-0.15
-Ant1-PASS




NTNV-N41-PC3-30-90-M-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant
1-PASS



NTNV-N41-PC3-30-90-M-DFT-QPSK-Edge_1RB_Left-30-1000-A
nt1-PASS



NTNV-N41-PC3-30-90-M-DFT-QPSK-Edge_1RB_Left-1000-3000-
Ant1-PASS



NTNV-N41-PC3-30-90-M-DFT-QPSK-Edge_1RB_Left-3000-1800
0-Ant1-PASS