


MOVE  
BAND

MB10



Quick Start Guide

CJB1GX0ALAAA

alcatel

# About your band


alcatel MOVEBAND can intelligently track your daily activity and sleep status, allow you to set your own activity target, urge you to achieve goals by incentive mechanism and notification to live a healthier life.

## Getting Started


1. Take out the main body from your wrist-band.



2. Charging the main body via USB cable to activate your band.



3. Wear your band.



# Download and install the application

1. Search "MOVEBAND" from Google play  or App Store  to download and install the application.
2. Create an account or use your social accounts to login.
3. Pair your band with your device after turning on the Bluetooth.

**Note:** One band can bind multiple accounts, but only one each time.

## LED Status

### Sports monitoring mode

Process	LED	Description
100%	● ● ● ●	Total four white LED keep lighting and stay for 2 seconds.
75% - 99%	● ● ● ○	The first three white LED keep lighting and stay for 2 seconds.
50% - 74%	● ● ○ ○	The first two white LED keep lighting and stay for 2 seconds.
25% - 49%	● ○ ○ ○	The first one white LED keeps lighting and stays for 2 seconds.
0 - 24%	※ ○ ○ ○	The first white LED keeps flashing and stays for 2 seconds.

### Information reminding mode



Missing Call, Unread Message, Unread E-Mail

Total Four blue LED keep lighting

---

- Light White
- ※ Flashing
- Light off

## **Operating progress**

Keep your band (face up) still for 2 seconds. Shake your band 3 seconds or 4~7 times to show activity progress (last for 2 seconds).

## **More**

You can receive more detail information in user manual in the App.

## **Health and safety information**

All users read the following warnings before using the band to reduce the risk of personal injury, discomfort or property damage. Review the hardware and software recommendations for use of the band. Risk of discomfort may increase if recommended hardware and software is not used.

### **Children health**

Do not leave your band within the reach of children or allow them to play with it. They could hurt themselves or others, or could accidentally damage your band such as swallowing the accessories and result in suffocating. Children should be monitored by an adult when using the band.

### **Battery Handling & Safety**

Only use the battery and charger supplied, or manufacturer approved replacements intended for use with your band. Using other batteries and chargers could be dangerous.

Do not disassemble or short-circuit the battery. Accidental short-circuiting can occur if a metallic object such as a key, paper clip, or pen touches the terminals of the battery.

Improper battery use may result in a fire, explosion, or other hazard. If you believe the battery has been damaged, do not use it and take it to a service center for testing.

## **Environment**

You alone are responsible for how you use your band and any consequences of its use.

Use of your band is subject to safety measures designed to protect users and their environment.

- Always treat your band with care and keep it in a clean and dust-free place.
- Do not expose your band to liquid, moisture or high humidity.
- Do not drop, throw or try to bend your band.
- Do not use harsh chemicals, cleaning solvents, or aerosols to clean your band.
- Do not paint your band.
- Do not attempt to disassemble your band, only authorized personnel must do so.
- Do not expose your band to extreme temperatures, minimum -10 and maximum 55 degrees Celsius.
- Do not leave your band in direct sunlight. Exposure to direct sunlight can damage it

# Certification

## WEEE Approval

This device is in compliance with the essential requirements and other relevant provisions of the Waste Electrical and Electronic Equipment Directive 2012/19/EU (WEEE Directive).



This symbol on device means that these products must be taken to collection points at the end of their life:

- Municipal waste disposal centres with specific bins for these items of equipment.
- Collection bins at points of sale.

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

### In European Union countries:

These collection points are accessible free of charge.

All products with this sign must be brought to these collection points.

### In non European Union jurisdictions:

Items of equipment with this symbol are not to be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled.

CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

## RoHs Approval

This device is in compliance with the restriction of the use of certain hazardous substances in electrical and electronic equipment Directive 2011/65/EU (RoHs Directive).

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

# Warranty

The device is warranted against any deviation from technical specifications for a period of twelve (12)<sup>(1)</sup> months from the date specified on your original invoice.

Under the terms of this warranty, you must immediately inform your vendor in case of a conformity defect on this device, and present a proof of purchase.

The vendor or repair center will decide whether to replace or repair this device, as appropriate.

Repaired or replaced this device is warranted ONE (1) month unless there are statutory provisions to the contrary.

This warranty shall not apply to damage or defects to this device due to:

- 1) Not following the instructions for use or installation.
- 2) Not being compliant with technical and safety standards applicable in the geographical area where this device is used.
- 3) Improper maintenance of sources of energy, and of the overall electric installation.
- 4) Accidents or consequences of theft of the vehicle in which this device is transported, acts of vandalism, lightning, fire, humidity, infiltration of liquids, inclement weather.
- 5) Connecting to or integrating into this device any equipment not supplied or not recommended by the manufacturer.
- 6) Any servicing, modification or repair performed by individuals not authorised by the manufacturer, the vendor or the approved maintenance centre.
- 7) Use of this device for a purpose other than that for which it was designed.

---

<sup>(1)</sup> The warranty period may vary depending on your country.

- 8) Malfunctions caused by external causes (e.g., radio interference from other equipment, power voltage fluctuations).
- 9) Faulty connections resulting from unsatisfactory radio transmission or caused by the absence of radio relay coverage.

Warranty is also excluded for this device on which markings or serial numbers have been removed or altered.

This device is also warranted against hidden defects (defects inherent in the design, manufacture, etc.).

There are no other express warranties than this printed limited warranty, expressed or implied, of any nature whatsoever.