



Model: A610

Please read this user manual carefully before use

IV. CAUTION

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

1. The unit should be stored and used under room temperature environment.
2. The unit should not be used under water and in a humid environment.
3. The unit should not be thrown, as damage could result.
4. The unit should not be disassembled or repaired by an unauthorized person.
5. The built-in Li-ion battery should not be thrown into the fire or any other place to avoid hazards.
6. The unit should only be cleaned with a dried cloth.
7. The unit should be serviced and repaired by the qualified personnel when it is damaged in any way.

V. WARNING

1. Please read all safety and operating instructions carefully before use.

2. In order to prolong the unit's life and protect your health, please do not listen to the music under high volume environment for a long time to avoid damaging your hearing.

3. Please switch off the power and pull up the plug immediately, if any device malfunction happens.

4. Please charge in time, or it will affect the BT connection when the battery runs low.

5. Please refer to the user manual to resolve any setting and function problems. If you have some other operating problems caused by this unit, please call and ask our customer service teams for help.

China Service Hotline: 400-7777-315
Shenzhen Thecoo Technology Co.,Ltd.
E: thecoo@thecoo.com.cn
W: www.thecoo.com.cn

I. ILLUSTRATION



1.SKIP BACK/VOLUME DOWN:

In Bluetooth playing mode, short press skips back to previous song, long press turns down the volume. In Aux mode, long press turns down the volume.

2.SKIP FORWARD/VOLUME UP:

In Bluetooth playing mode, short press skips forward to next song, long press turns up the volume. In Aux mode, long press turns up the volume.

3.POWER ON/OFF:

Long press this button, power on with a "du" tone remind. Long press again, Power off.

4.PLAY/PAUSE/BLUETOOTH:

1)In Bluetooth playing mode, short press, music is pause.
2)While in Bluetooth connection without playing music, long press, Bluetooth is disconnected and entering Bluetooth pairing condition.

5.ANSWER CALL/HANG UP CALL

1)While receiving an incoming call, short press answers the incoming call or hangs up the incoming call; long press rejects the call.

2)While in conversation, long press can switch conversation to your mobile phone.

3)While in Bluetooth connection without playing music, short press twice can dial your last call.


6.CHARGING INDICATOR

7.MICROPHONE

8.BLUETOOTH INDICATOR

9.POWER BANK ON/OFF:

Long press, power bank USB output is enabled. Output is DC 5V 2.1A. It can be used to charge Ipod, Iphone and Ipad etc. Long press again, shut off USB



output charging function.

10.MICRO USB CHARGING INTERFACE

11.USB INTERFACE: Power output port.

12.POWER BANK LEVEL LED INDICATOR:

When battery level is less than 25%, LED light will flash red color. When battery level is between 25%-50%, LED light shows green color. When battery level is between 50%-100%, LED light shows blue color.

13.AUX IN:

connecting to external audio resources by 3.5mm audio cable.

II. OPERATING GUIDE

1.BLUETOOTH CONNECTION AND MUSIC PLAY

1)Set your Bluetooth enabled device to search and pair "THECOO BTA610".
2)play the music on the paired device and adjust the volume to a desired level.

2.EXTERNAL AUDIO RESOURCE PLAY

Connecting the external audio resources with this speaker by 3.5mm audio cable, the speaker turns to AUX IN mode automatically. Then you can play any music you like.

3.BLUETOOTH SPEAKER PHONE

1)While receiving an incoming call, short press "ANSWER CALL" button answers the incoming call. Short press again, hangs up the call. Long press, rejects the call.

2)While in conversation, long press "ANSWER CALL" button switches conversation to your mobile phone

3) While in Bluetooth connection without playing music, short press "ANSWER CALL" button twice dials your last call.

4.CHARGE INSTRUCTION

1)When the power level is too low, charging indicator LED light flashes. Please fully charge the speaker.
2)using the USB-Micro cable, connect the speaker to a USB power source on a computer or USB AC adapter.
3)While in charging, the charge indicator LED light shows red color, after full power, LED light off. Note: while in charging, please turn off the power.

5.BLUETOOTH DISCONNECTION

1)long press "POWER BUTTON" until the indicator off, Bluetooth disconnection.
2)Bluetooth enabled device shut off Bluetooth function.

Notes:

After the first successful pairing, the mobile phone and this speaker have a memory of the pairing; It will be quickly paired next time.

III. SPECIFICATIONS

Bluetooth Version	Bluetooth4.0
Output power	5W X2
Driver Unit	4Ω/5W 45mm
Frequency Response	120Hz ~ 20kHz
S/N Ratio	≥85dB(Except charging condition)
THD	≤0.1% (Output 1v at 1kHz)
Receiving Range	≥10M (No blocking)
Power Supply	DC 5V
USB Output Power	DC 5V / 2.1A
Battery Capacity	5200mAh (Built-in Li-ion)
Play Time	≥8Hrs (Due to the volume level and audio content varies)
Charging Time	≥3Hrs
Item Size	Φ72.6X217.5mm

Accessories:

1pc Stereo audio cable (Φ3.5mm, L=0.5M)
1pc USB charging cable
1pc Product user manual

PRODUCT WARRANTY

Please fill in this card carefully after purchasing this product and keep it in a safe place.

Product Model: _____ Purchasing Date: _____

User name: _____ User address: _____

TEL: _____ Post Code: _____

Dealer: _____ Principal: _____

Address: _____

TEL: _____ Seal: _____

CERTIFICATE

Product Name: _____ Product Mode: _____

Production Date: _____ Quality inspector: _____



China Service Hotline
400-7777-315

www.thecoo.com.cn