





正面

 PORTABLE THINEST BLUETOOTH SPEAKER		I. ILLUSTRATION	II. OPERATING GUIDE	III. SPECIFICATIONS	
<b>USER MANUAL</b>	 Type: BTD708K	 <b>1. POWER BUTTON:</b> 1) Long press this button, power on with a "du" tone remind. 2) Long press again, Power off; short press switch to TF card play mode and Aux mode. 3) In Bluetooth playing mode, short press, music is pause. 4) While receiving an incoming call, short press answer or hang up the call; long press reject the call. 5) While in Bluetooth connection without playing music, short press twice can dial your last call. 6) While in conversation, long press can switch conversation to your mobile phone. <b>2. SKIP BACK/VOLUME DOWN:</b> In Bluetooth or TF card playing mode, short press skip back to previous song; In Bluetooth/ TF card/ Aux mode, long press make the volume down. <b>3. SKIP FORWARD/VOLUME UP:</b> In Bluetooth or TF card playing mode, short press skip forward to next song; In Bluetooth/ TF card/ Aux mode, long press make the volume up.	<b>4. PLAY/PAUSE/MUTE:</b> 1) In Bluetooth or TF card playing mode, short press play or pause. 2) In Bluetooth mode(non-conversation),long press disconnect Bluetooth. 3) While receiving an income call, short press answer or hang up the call; long press reject the call. 4) While in conversation, long press switch conversation to your mobile phone. 5) While in Bluetooth connection without playing music, short press twice can dial your last call. <b>5. FUNCTION INDICATOR</b>  <b>6. AUX INPUT PORT:</b> Connecting audio resources and the speaker with 3.5mm audio cable, short press "POWER BUTTTON" switch to AUX mode. <b>7. TF CARD SLOT:</b> Insert Micro SD card, short press "POWER BUTTTON" switch to TF card play mode. <b>8. MICRO USB CONNECTOR PORT:</b> For charging use <b>9. CHARGING INDICATOR</b> <b>10. RESET KEY</b>	<b>1. BLUETOOTH CONNECTION AND MUSIC PLAY</b> 1) Set your Bluetooth enabled device to search and pair "THECOO BTD188". 2) Play the music on the paired device and adjust the volume to a desired level. <b>2. EXTERNAL AUDIO RESOURCE PLAY</b> Connecting external audio resources and the speaker with 3.5mm audio cable, short press "POWER BUTTTON" switch to AUX mode, then play any music by external audio resources. <b>3. BLUETOOTH SPEAKER PHONE</b> 1) While receiving an incoming call, short press "PAUSE BUTTTON" can answer or hang up the incoming call. 2) While receiving an incoming call, long press reject the incoming call. 3) While in conversation, long press switch conversation to your mobile phone. 4) While in Bluetooth connection without playing music, short press twice can dial your last call.	
<b>IV. CAUTION</b>	<b>V. WARNING</b>	<b>VI. WARRANTY</b>	<b>VII. WARNING</b>	<b>PRODUCT PATENT NUMBER:</b> 201430334109.X	
<p>When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.</p> <ol style="list-style-type: none"> <li>The unit should be stored and used under room temperature environment.</li> <li>The unit should not be used under water and in a humid environment.</li> <li>The unit should not be thrown, as damage could result.</li> <li>The unit should not be disassembled or repaired by an unauthorized person.</li> <li>The built-in Li-ion battery should not be thrown into the fire or any other place to avoid hazards.</li> <li>The unit should only be cleaned with a dried cloth.</li> <li>The unit should be serviced and repaired by the qualified personnel when it is damaged in any way.</li> </ol>	<p>1. Please read all safety and operating instructions carefully before use.            2. In order to prolong the unit's life and protect your health, please do not listen to the music under high volume environment for a long time to avoid damaging your hearing.            3. Please switch off the power and pull up the plug immediately, if any device malfunction happens.            4. Please charge in time, or it will affect the BT connection when the battery runs low.            5. Please refer to the user manual to resolve any setting and function problems. If you have some other operating problems caused by this unit, please call and ask our customer service teams for help.</p> <p>China Service Hotline: 400-7777-315            SHENZHEN THECOO TECHNOLOGY CO.,LTD.            E: thecoo@thecoo.com.cn            W: www.thecoo.com.cn</p>	<p>This limited warranty does not affect the Consumer's statutory rights under law. THECOO maintenance is based on the original invoice &amp; cash receipt that was provided by dealers with complete purchasing date, dealer name and product model. The warranty period is 12 months from the date of original purchased. (Main parts' maintenance would be 24 months: PCB board, drives). This limited warranty does not cover:            1. After the purchasing vouchers without permission. (can not be identified).            2. Product model or serial number was removed, altered and different from the product type certified. (can not be identified).            3. Product that has been damaged due to repairs, reinstallation and modification by unauthorized service organizations or persons.            4. Item used for commercial purpose.            5. Damages caused by wrong operation, or operate under an unworkable environment which was not recommended.            6. Damages caused by using unrelated peripheral equipments, additional equipments or accessories that was not recommended by THECOO.            7. Accident damages included but not limited to lightning, abnormal voltage, water, fire, flood, nature, accident.            8. Damages caused by animals.            9. Damages caused by consumable parts (these parts are considered to be consumable ones according to their performance).            THECOO reserves the right to amend the terms and conditions if necessary.</p>	<p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:            • Reorient or relocate the receiving antenna.            • Increase the separation between the equipment and receiver.            • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</p>	<b>PRODUCT WARRANTY</b> <p>Please fill in this card carefully after purchasing this product and keep it in a safe place.</p> <p>Product Mode: _____ Purchasing Date: _____            User name: _____ User address: _____            TEL: _____ Post Code: _____</p> <p>Dealer: _____ Principal: _____            Address: _____            TEL: _____ Seal: _____</p> <p><b>CERTIFICATE</b>            Product Name: _____ Product Mode: _____            Production Date: _____ Quality inspector: _____</p>	
<b>THECOO 西客® 便携式超薄蓝牙音箱</b>	<b>产品使用手册</b>	<b>1 产品示意图</b>  1. Power键: 长按开机，并有“进入蓝牙，等待连接”的语音提示；再次长按关机，并有“关机”的语音提示；短按即可切换蓝牙/AUX模式，并有对应的语音提示 2. 上/下音量减: 在蓝牙/插卡模式下，短按即可播放下一曲目；在蓝牙/插卡模式和AUX模式下，长按即可减小音量，当音量达到最低时，并有“最小音量”的语音提示 3. 下/上音量加: 在蓝牙/插卡播放状态下，长按即可播放下一曲目；在蓝牙/插卡模式和AUX模式下，长按即可增加音量，当音量达到最高时，并有“最大音量”的语音提示 4. 播放/暂停/静音: 1)在蓝牙/插卡播放状态下，短按即可播放/暂停； 2)在工作状态下(非通话状态)中，长按即可实现连接重新进入配对状态，并有“蓝牙断开，等待连接”的语音提示； 3)来电时短按可接听或挂断来电，长按可拒绝来电； 4)来电时短按可接听或挂断来电，长按可拒绝来电； 5)在蓝牙/插卡播放状态下，短按即可播放/暂停； 6)在工作状态下(非通话状态)中，长按即可实现连接重新进入配对状态，并有“蓝牙断开，等待连接”的语音提示； 7)来电时短按可接听或挂断来电，长按可拒绝来电； 8)TF插卡: 插入Micro SD卡，有“音乐播放”的语音提示，然后即可播放音乐 9)USB接口: 电源充电接口 10)AUX音频输入端口: 3.5mm外接音频输入，并有“音频输入播放”的语音提示	<b>2 操作方法:</b> <ul style="list-style-type: none"> <li>1. 通话中长按可语音转移；            5)在连接待机未播放音乐状态下，连续短按两次可未码重拨；            6)在AUX模式下，短按即可静音；            5. 指示灯: 功能指示蓝灯</li> <li>6) 复位            7) 充电指示红灯            8) TF插卡: 插入Micro SD卡，有“音乐播放”的语音提示，然后即可播放音乐            9) USB接口: 电源充电接口            10) AUX音频输入端口: 3.5mm外接音频输入，并有“音频输入播放”的语音提示</li> </ul>	<b>4. 电源充电</b> <p>1. 当音箱电量不足时，有“电池电量低，请充电”的警示音。            2. 充电时充电指示灯红灯常亮，充满电时红灯熄灭。(注：充电时请长按Power键关机。)</p> <p><b>5. 蓝牙断开连接</b></p> <p>1. 长按音箱播放/暂停键，即可断开连接；手机、平板电脑或其它设备断开连接。            2. 超出蓝牙信号接收距离亦自动断开连接。            3. 关闭音箱电源，即可断开连接。(注：当不使用音箱时，请长按音箱Power键进入关机模式，可防止电量损耗。)</p> <p><b>温馨提示:</b>            首次配对成功后手机和音箱有认证记忆功能，再次开机使用时会先回连上次配对过的设备，回连失败后自动进入配对状态。</p>	<b>产品专利号:</b> 201430334109.X
<b>3 产品规格</b>	<b>4 注意事项:</b>	<b>5 温馨提示:</b>	<b>6 质保信息:</b>	<b>产品保修信息</b> <p>购买本产品时,请认真填写此卡,并予以妥善保管。</p> <p>产品型号: _____ 购买日期: _____            用 户 名: _____ 用 户 地 址: _____            联系电话: _____ 邮 编: _____</p> <p>经 销 单 位: _____ 负 责 人: _____            地 址: _____            联系电话: _____ 签 章: _____</p> <p><b>产品合格证</b>            产品名称: _____ 规格型号: _____            出厂日期: _____ 质 检 员: _____</p>	
<p>蓝牙版本: Bluetooth4.0            额定功率: 3W x2            喇叭单元: 4Ω/3W 40mm            频率响应: 120Hz ~ 18kHz            信噪比: ≥75dB(充电状态除外)            失真度: ≤0.1% (Output 1v@1kHz)            传输距离: ≥10米 无阻隔空间            充电电压: DC5V            电池规格: 内置锂电池3.7V, 900mAh            播放时间: ≥8h (因音量水平和音频内容而异)            充电时间: ≥3h            产品尺寸: 172.7x21x66.6mm</p> <p>产品配件:            立体声音频线: Φ3.5mm L=0.5M 1PCS            USB充电线: 1PCS            产品使用手册: 1PCS</p>	<p>用户按指导方式正常使用时，本产品的设计和制造可确保您的人身安全，但使用不当仍可能导致潜在的触电或火灾隐患。配对使用前，请仔细阅读所有的安全说明和操作说明，并妥善保管本手册以备参考。请着重注意以下说明中列出的所有警告信息。</p> <ol style="list-style-type: none"> <li>1. 请在常温环境中存放以及使用本产品；</li> <li>2. 请勿将本产品暴露在雨中或潮湿环境中；</li> <li>3. 请勿丢弃，避免因跌落造成产品损坏；</li> <li>4. 请勿自行拆解、修理和改造本产品；</li> <li>5. 产品内置锂电池，请勿随意丢弃或置以火中，以免引起危险！</li> <li>6. 请用干布进行清洁；</li> <li>7. 无论设备以任何方式损坏，请让专业的维修人员进行维修工作。</li> </ol>	<p>1. 开始使用前请仔细阅读所有安全说明书。            2. 为有利于延长音箱使用寿命和你的身心健康，请不要在长时间大音量的环境下听音，以免损害你的听力。            3. 出现故障时，请立即切断电源开关。            4. 电量不足会影响蓝牙距离或蓝牙容易断开，请及时充电。            5. 涉及设置与性能的多数问题均可在本手册中找到答案。如果您对本产品的操作或使用存在其他疑问，请与我们的客户服务团队进行联系以寻求帮助。</p> <p>中国区服务热线: 400-7777-315            深圳市西客科技有限公司            邮箱: thecoo@thecoo.com.cn            网址: www.thecoo.com.cn</p>	<p>西客的保修不影响您根据法律所享有的质保法定权利，也不影响您在购买过程中对零售商主张的权利。西客依据用户购买购买产品时由经销商提供的证明购买日期、经销商名称和产品型号的原始发票或现金收据给用户提供保修服务。保修的有效期从您购买该产品开始算起提供保修期整机12个月（大写保修期12个月，集成电路板、喇叭1年）。            西客保修将不适用于下列情况：            1.擅自对产品的购买凭证进行涂改或导致使凭证字迹模糊（无法辨认）；            2.产品型号和/或序列号（如果有）已被涂改、擦掉或字迹模糊（无法辨认）；            3.已由任何非授权维修机构或个人实施产品维修、改装和改造；            4.产品用于商业目的；            5.滥用或产品误操作导致的故障，或在与推器的产品使用环境不符的场所进行操作而产生的故障；            6.使用非西客推荐的相关外围设备、附加设备或产品附件而产生的故障；            7.事故产生的损坏，包括但不限于闪电、异常电压、火灾或火灾、自然灾害或交通事故；            8.动物造成的损坏；            9.部件损耗造成的产品损坏（该类部件根据他们的性能被认定为是易耗部件）；            西客有权在必要时修改条款和条件。</p>	<b>产品保修信息</b> <p>购买本产品时,请认真填写此卡,并予以妥善保管。</p> <p>产品型号: _____ 购买日期: _____            用 户 名: _____ 用 户 地 址: _____            联系电话: _____ 邮 编: _____</p> <p>经 销 单 位: _____ 负 责 人: _____            地 址: _____            联系电话: _____ 签 章: _____</p> <p><b>产品合格证</b>            产品名称: _____ 规格型号: _____            出厂日期: _____ 质 检 员: _____</p>	

西客科技 BTD708K中英文说明书

尺寸: 65X80mm

材质: 105g铜版纸

折页: 扇形

印刷: 正反双面印刷