



THECOO®

## USER MANUAL




Please read this user manual carefully before use

### 1 ILLUSTRATION



1. POWER ON/OFF PLAY/PAUSE:  
 A. Long press the key to power on. Long press again to turn off if the speaker was disconnected.  
 B. On Bluetooth mode, long press to disconnect and enter pairing mode, you will hear the notify tone. If keep press the bottom, the speaker will power off.  
 C. On Bluetooth mode. Short press to PLAY/PAUSE the music.  
 D. While received an incoming call, short press could answer or hang up the call. Short press twice could reject the call.  
 E. While Bluetooth connected the mobile without playing music, short press twice will dial the last phone call before.  
 F. While in conversation, long press could switch the speaker from Bluetooth mode to mobile mode.

2. SKIP BACK/VOLUME DOWN  
 Short press to skip back in Bluetooth mode. Long press to turn down the volume and you will hear the notify tone when in minimum volume.  
 3. SKIP FORWARD/VOLUME UP  
 Short press to skip forward in Bluetooth mode. Long press to turn up the volume and you will hear the notify tone when maximum volume.



4. CHARGING LED INDICATOR  
 5. MICRO-USB/CHARGING PORT

### 2 OPERATING GUIDE

1. BLUETOOTH CONNECTION AND MUSIC PLAY  
 Set the Bluetooth enabled on your device, search and pair with 'THECOO BTM107', you will hear the notify tone once connected successfully. Play the music on the device and adjust the volume to a desired level.

#### 2. BLUETOOTH HANDS FREE

1) Once the Bluetooth connect successfully, and there is an incoming call, short press the POWER key to answer or hang up the call, or short press twice will reject the call.  
 2) While in conversation, long press the POWER key to switch the speaker from mobile mode to Bluetooth playing  
 3) While Bluetooth connected the mobile without playing music, short press twice will dial the last phone call before.

#### 3. CHARGE INSTRUCTION

1) When the battery is low, speaker will warning by tone.  
 2) While charging the speaker, the indicator LED shows red and will turn off once full charged.  
 Note: Please do turn off the speaker when charging it.

4. BLUETOOTH DISCONNECTION  
 A. On Bluetooth mode, long press the POWER key to disconnect Bluetooth and ready to pairing with other device, you will hear the notify tone.  
 B. Ensure your device don't connect with any others.  
 C. The speaker will lost connection automatically when out of Bluetooth working range.  
 D. Turn off the power will disconnect directly.  
 (Note: Please turn off the speaker to keep long battery life, while the speaker is not in use)

#### Tips:

1. When Bluetooth disconnect for 5 minutes, the speaker will turn off.  
 2. The speaker will memory all devices that have connected before, it will connect the last connect device when power on again. If connecting failed, speaker will switch to auto pairing mode.

### 3 SPECIFICATIONS

Bluetooth Version	Bluetooth 2.0+EDR
Output power	3W X1
Driver Unit	4Ω/3W 40mm
Frequency Response	120Hz~20kHz
S/N Ratio	≥75dB(Except charging condition)
THD	≤0.1% (Output 1v@1kHz)
Receiving Range	≥10M (No blocking)
Power Supply	DC 5V
Battery Capacity	3.7V/500mAh (Built-in Li-ion)
Play Time	≥6Hrs (Due to the volume level and audio content varies)
Charging Time	≥2-3Hrs
Item Size	64.5*58*31mm

Accessories:  
 Tpc USB charging cable  
 Tpc Product user manual

### 4 CAUTION

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.  
 1. The unit should be stored and used under room temperature environment.  
 2. The unit should not be used under water and in a humid environment.  
 3. The unit should not be thrown, as damage could result.  
 4. The unit should not be disassembled or repaired by an unauthorized person.  
 5. The built-in Li-ion battery should not be thrown into the fire or any other place to avoid hazards.  
 6. The unit should only be cleaned with a dried cloth.  
 7. The unit should be serviced and repaired by the qualified personnel when it is damaged in any way.

### 5 WARNING

1. Please read all safety and operating instructions carefully before use.  
 2. In order to prolong the unit's life and protect your health, please do not listen to the music under high volume environment for a long time to avoid damaging your hearing.  
 3. Please switch off the power and pull up the plug immediately, if any device malfunction happens.  
 4. Please charge in time, or it will affect the Bluetooth connection when the battery runs low.  
 5. Please refer to the user manual to resolve any setting and function problems. If you have some other operating problems caused by this unit, please call and ask our customer service teams for help.

China Service Hotline: 400-7777-315  
 Shenzhen Thecoo Technology Co., Ltd.  
 E.: thecoo@thecoo.com.cn  
 W.: www.thecoo.com.cn

### 6 WARRANTY

This limited warranty does not affect the Consumer's statutory rights under law. THECOO maintenance is based on the original invoice & cash receipt that was provided by dealers with complete purchasing date, dealer name and product model. The warranty period is 12 months from the date of original purchased. (Main parts' maintenance would be 24 months: PCB board, drives).  
 This limited warranty does not cover:  
 1. To alter the purchasing vouchers without permission. (can not be identified).  
 2. Product model or serial number was removed, altered and different from the product type certified. (can not be identified).  
 3. Product that has been damaged due to repairs, reinstallation and modification by unauthorized service organizations or persons.  
 4. Been used for commercial purpose.  
 5. Damages caused by wrong operation, or operate under an unworkable environment which was not recommended.  
 6. Damages caused by using unrelated peripheral equipments, additional equipments or accessories that was not recommended by THECOO.  
 7. Accident damages included but not limited to lightning, abnormal voltage, water, fire, flood, nature, accident.  
 8. Damages caused by animals.  
 9. Damages caused by consumable parts (these parts are considered to be consumable ones according to their performance).  
 THECOO reserves the right to amend the terms and conditions if necessary.

#### PRODUCT WARRANTY

Please fill in this card carefully after purchasing this product and keep it in a safe place.

Product Model: \_\_\_\_\_ Purchasing Date: \_\_\_\_\_  
 User name: \_\_\_\_\_ User address: \_\_\_\_\_  
 TEL: \_\_\_\_\_ Post Code: \_\_\_\_\_

Dealer: \_\_\_\_\_ Principal: \_\_\_\_\_  
 Address: \_\_\_\_\_  
 TEL: \_\_\_\_\_ Seal: \_\_\_\_\_

#### CERTIFICATE

Product Name: \_\_\_\_\_ Product Model: \_\_\_\_\_  
 Production Date: \_\_\_\_\_ Quality Inspector: \_\_\_\_\_

China Service Hotline  
 400-7777-315

www.thecoo.com.cn

## NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.