

WR114 Remote Control Instructions

1. Product Overview

Product Name: Remote Control

Product Model No.: WR114

2. Environment requirement

Operation temperature: +10°C~ +40°C.

Storage temperature: 10°C~65°C.

Operating Humidity: 10%~80%RH, non-condensing.

Storage Humidity: 10%~ 85%RH, non-condensing.

3. Directions for Operation

3.1 Pairing Remote

The original remote that comes in the box is already paired to the foundation. No further action is required. In the event when the remote is not paired with the foundation, follow the pairing instructions below.



STEP 1: Make sure the batteries are good. Replace them when needed.

STEP 2: Unplug the power cord from the power source. If 9V backup batteries were installed in the power supply, remove them.

STEP 3: Press and hold Select buttons ◀ and ▶ until the LCD screen of the remote control shows PAIR.

STEP 4: Plug the power cord back into the power source. The LCD screen on the remote control shows "PASS", and you will hear an activation sound in 2 seconds indicating the remote is paired to the power foundation.

3.2 ADJUST:



ADJUST



This button lifts the Head/Foot/
Tilt section of the foundation.



This button lowers the Head/Foot/
Tilt section of the foundation.

3.3 ONE TOUCH BUTTON:

SELECT BUTTON



Press these two button to select
head, foot or tilt zone.

SETTING PROGRAMMABLE POSITION



One touch programmable positions.

MASSAGE FEATURES



Turn on the head massage. Cycle
through 3 massage intensities.



Turn on the foot massage. Cycle
through 3 massage intensities.

STOP Turn off the head/foot massage.

UNDER BED LIGHTING



Under bed LED lighting on/off.

ONE TOUCH BUTTON



One touch **ANTI-SNORE** preset
position.



One touch flat position.



One touch **TV** preset position.



One touch **ZERO G** preset
position. **ZERO G** adjusts your
legs to a higher level than your
heart, helping to relieve
pressure of the lower back and
promote circulation.

4. Matters needing attention:

- 4.1 The function will only work normally in proper working power conditions.
- 4.2 Remote Control needs three AAA batteries.
- 4.3 The control box is needed for proper control.
- 4.4 If problems are identified, they must be treated by professional personnel.

5. Additional attention for user:

5.1 This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

5.2 Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.