

User Guide

Table of Contents

Getting Started.....	2
Getting Started Continued.....	3
App Screen Overview.....	4
App Features.....	5
Locate	5
Dogs.....	5
	5
Add dog	5
Edit Existing dogs:	5
Delete Dog.....	6
Waypoints.....	6
	6
New Waypoint:	6
Edit Waypoint.....	6
Delete Waypoint	6
Settings.....	6
Information Bars.....	7
Compass Page.....	7
Caution Symbol.....	7
Collar and Receiver Light Indications	8
Receiver	9
Collar	10
FCC	11
FCC Label Locations.....	12

Getting Started

Step 1

Download the app from the app store for apple devices or google play for android devices.

Step 2

Use the username and password supplied to login to the app.

Step 3

Once you login the “Hunt Locations screen will display.

On the bottom of the screen touch “Devices”

Step 4

Turn on Bluetooth on your smartphone or tablet.

Power on the receiver and place next to your smartphone or tablet.

On the devices page touch “Pair Receiver”.

Step 5

Power on a **single collar** and place next to your smartphone or tablet and the receiver.

On the devices page touch “Pair Collar”.

Step 6

Name and select color for collar.

Step 7

Power off paired collar and repeat steps 5 through 7 to pair additional collars.

Only one collar can be powered on at a time during pairing.

Getting Started Continued

Step 8

After pairing all of your collars touch “Hunt Locations” on the bottom of the screen.

Step 9

Touch “Add Hunt Location”

Step 10

IMPORTANT NOTE:

Stream Map is used for getting familiar with the system.

Preload Map should be used for an actual hunt and must be downloaded while on WI-FI prior to the hunt. When selecting preload map make sure hunt location address or GPS coordinates is near the center of the hunt location.

The Pre-Hunt screen will appear. Name the location, enter address or select use current location, select map style, and choose stream map or preload map and touch “Start Hunt”

Step 11

While outdoors power on paired collars and wait for receiver and collars to acquire a satellite signal.

Step 12

Verify both collar and receiver have acquired satellites by having a blinking green light, and dog icon pulses approximately every 10 seconds on the map.

Step 13

You are now ready to hunt if you have completed steps 1 through 12 and have downloaded a hunt area map on WI-FI.

App Screen Overview

Map Scale, Receiver Battery Life, Your Heading, Access compass page



Selected Dog's Icon and name

You

You can touch another dog's icon on map to select

Adjust Rex's Settings

Rex's Collar Battery Life

Distance to Rex



Selected Dog's Info bar with name and collar color displayed

Bearing to Rex

App Features

Locate



Centers waypoints, dogs, or you on the map and updates information bar

Dogs



Add dog

1. Touch Add Dog
2. Remove Magnet from collar and place next to device and receiver
3. When prompted name and select collar color.
4. Adjust collar settings then touch back.
5. Collar has now been added.

Edit Existing dogs:

1. Touch Dogs Icon or 3 dots



2. Select desired dog and edit the following:

Bread Crumbs ON/OFF

Display on Map ON/OFF

Display Dog Name ON/OFF

Name & Color

Delete Dog

1. Touch Dogs Icon
2. Select desired dog
3. Press X by dog name
4. Select Delete

Waypoints



New Waypoint:

1. Touch Waypoints Icon
2. Select Add Waypoint
3. Choose Color and Name waypoint
4. Adjust Waypoint settings
5. Touch “Back” and then “Done”
6. Touch “Locate” and select desired waypoint
7. Drag and drop added waypoint on map to desired location

Edit Waypoint

1. Touch Waypoints Icon on menu bar.
2. Select desired waypoint and edit the following:

Display on Map ON/OFF

Display Waypoint Name ON/OFF

Name & Color

Delete Waypoint

1. Touch Waypoints Icon on menu bar.
2. Select desired waypoint
3. Press X by waypoint name
4. Select Delete

Settings

Choose Day Mode/Night Mode


Close Map (allows you to change maps)

Information Bars

Top information bar displays receiver battery level, hunter's heading, and map scale.



Bottom information bar displays selected dog's battery level, distance, and bearing to dog.



Compass Page

Touch the blue compass symbol on top right of map page

Touch the blue compass symbol again to exit

Whichever dog is selected on the bottom information bar will be the dog displayed on the compass page


Caution Symbol

Indicates that the receiver is not receiving position information from the collar.

Collar and Receiver Light Indications

Unit	Light	Meaning
Receiver	Blinking Blue	Bluetooth Discoverable
Receiver	Blinking Yellow	No GPS fix
Receiver	Blinking Green	Has GPS fix
Collar	Blinking Blue	Bluetooth Discoverable
Collar	Blinking Yellow	No GPS fix
Collar	Blinking Green	GPS fix

Receiver



Power Button



Change AA batteries by removing the two Philips head screws on back of receiver

Collar

Remove magnet to power on. Insert magnet to power off.



FCC

The O (Collar) and OR (Receiver) complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any question regarding operation of these devices under FCC rules please contact:

DGreen Engineering, LLC
8830 County Road 57 North
Abbeville, AL 36310
(334) 791-0027



FCC CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This includes operating the equipment without the FCC label access panels installed. The O is not intended for human use. Do NOT attempt to use on any person

FCC Label Locations

Collar

MURS Radio FCC ID: 2AERJ-O-Ø1



Location of the collar FCC label

CE910-DUAL Module FCC ID: RI7CE910-DUAL

Receiver

FCC ID: 2AERJ-OR-Ø1



Location of the receiver FCC label