





This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be

determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the ollowing measures: - Reorient or relocate the receiving antenna.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/ TV technician for help.

- Increase the separation between the equipment and receiver.

MOUSE DROID:

Rechargeable batteries and one Micro USB cable are included. The Micro USB charging port is located on the bottom of the Mouse Droid.

Connect the supplied Micro USB cable into the Mouse Droid, and connect the USB into your computer or electrical outlet.

The Mouse Droid's battery life can run for approximately 5 hours, if the device is fully charged.

REMOTE CONTROL:

Requires 3 AA Type batteries (1.5V) - Demonstrating batteries includes 3 AA batteries

PLEASE READ CAREFULLY BEFORE OPERATING THE PRODUCT

Non-rechargeable batteries are not to be recharged.
 Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium batteries).
 Do not mix old and new batteries.

4 - Only batteries of the same or equivalent type as recommended

are to be used. 5 - Batteries are to be inserted with the correct polarity.

6 - Exhausted batteries are to be removed from the toy.
7 - The supply terminals are not be short-circuited.
8 - Dispose of batteries safely. 9 - Rechargeable batteries are to be removed from the toy before

being charged. 10 - Rechargeable batteries are only to be charged under an adult 11- Do not immerse in water.



Disney.com Disney Theme Park Merchandise Lake Buena Vista, FL 32830 © Disney © & ™ Lucasfilm Ltd.

Made in China

Colors may vary from images shown. Product may vary in size from images shown.

