



MobilePal™ 10400mAh QiWi™ Power Bank User Manual



Thank you for choosing the MobilePal™ QiWi™ wireless power bank! Before using the product, please read the manual carefully and follow the instructions to operate properly.

The MobilePal™ QiWi™ power bank is an innovative, carefully crafted Qi wireless and wired charger with an integrated high-capacity portable power bank. It smart phones, tablets, digital cameras, MP3/MP4 provides you the ultimate convenience of charging your players, and other electronic devices at home, in your office, or on the go. This manual applies to the 2nd generation wireless power banks with model numbers have numerous improvements over the previous QIWI-G2-GW, QIWI-G2-LW, and QIWI-G2-LK, which generation.

Feature Overview

- Integrated Qi wireless charging transmitter for wirelessly charging all devices conforming to the Qi charging standard, either as a wireless charging pad or a charging station in the pass-through mode.
- Integrated high-capacity, grade - A lithium - polymer battery for on-the-go use.
- Dual 2.1A USB outputs optimized for Apple and Samsung devices, respectively.
- A 2-in-1 Lightning+Micro - USB high - speed charging cable included for your convenience to charge Apple and Android devices at high speed.
- Simultaneous wireless charging via Qi wireless and wired charging via USB ports.
- Intelligent circuit for avoiding short - circuiting, over-charging, and malfunctioning.

- Anti-skid surface for leatherette models ; anti - skid rubber pads for glossy white model.
- Certifications: CE, FCC, RoHS

Technical Specifications

ITEM	SPECIFICATION
Generation/Model	2nd generation QIWI-G2
Input	5V, 1A to 2A max (as labeled on device)
USB Output 1	5V0.25V, 2.1A (optimized for Samsung devices)
USB Output 2	5V0.25V, 2.1A (optimized for Apple devices)
Wireless Output	5W
Cell Type	Li-polymer 3.75V, 10400mAh
Charging Efficiency	>85% for wired charging; >70% for wireless charging
Charging Frequency	100~200KHz
Wireless Distance	Up to 1cm
Qi Compatibility	Any Qi-integrated or Qi-ready device with Qi wireless receiver
USB Compatibility	Apple or Android devices; most other devices with USB charging
Battery Indicators	4 blue LEDs, each indicating 25% of capacity
Charging Modes	1. Wired+wireless charging mode (red LED on) 2. Wired-only charging mode (red LED off)
Color	Glossy white; leatherette white; leatherette black
Dimensions	6in(L) x 2.87in(W) x 0.49in(H) (153mm x 73mm x 12.5mm)
Weight	10.9oz (310g)

Package Contents

- QiWi power bank1 piece
- 2-in-1 Lightning+Micro-USB cable1 piece (supports up to 2.1A currents)
- User Manual1 piece
- Anti-skid rubber pads(for glossy white QIWI-G2-GW only)

I/O Ports, Buttons and Indicators

- Micro-USB input
- USB output 1 optimized for Samsung
- USB output 2 optimized for Apple
- LED indicators (blue and red)
- Power button
- Center of wireless transmitter



Operating Instructions

Recharging Power Bank

- Before using the QiWi power bank for the first time or if only one blue LED is on or flashing, please recharge the power bank.
- Connect the micro-USB connector of a USB cable (included) into the micro-USB input port, and connect the other end of the cable to a USB charger (not included). We recommend USB chargers with a 1A to 2A output.
- When charging, the blue LEDs will flash one by one. Each blue light indicates 25% of the charge. When fully charged, all blue LED lights will stay on.
- When recharging the power bank, you can charge other devices in pass-through mode. See **Charging in Wired+Wireless Mode** below for instructions. During pass-through charging, QiWi will first charge the external device and then charge the power bank after the external device is fully charged. Note: During pass-through charging, output current may be limited by the input current.

Turning On/Off and Toggling Wireless Charging

- When not connected with an external power source, QiWi supports two separate modes: wired+wireless charging mode and wired-only charging mode in the wired+wireless charging mode, the red LED is on; in the wired charging mode, the red LED is off.
- In either mode, press the power button briefly to turn the device on or off.
- To toggle between the two modes, press-and-hold the power button for 3 seconds.

Charging in Wired+Wireless Mode

- Before charging, make sure the device is on and in the wired+wireless charging mode, as indicated by the red LED. If only blue LEDs are on, press-and-hold the power button for 3 seconds to toggle to the wired+wireless charging mode.
- To charge a compatible device with wired charging, connect it to the USB output port through a USB cable (included). It is recommended to use USB Output 1 for rapid charging of Samsung devices and USB Output 2 for Apple devices. However, either port is capable of charging any USB device at 1A current or higher.
- When charging without external power, the blue LEDs will turn off after about 5 seconds to conserve battery. To check the remaining battery capacity, press the power button briefly to light up the blue LEDs.
- To charge wirelessly, place a Qi-compatible device on top of the QiWi to charge and align the centers of its wireless receiver and of QiWi.
- During wireless charging, the red LED remains on when charging. If no external power is connected and no Qi receiver is detected, it would time out after 16 seconds to conserve battery.

Charging in Wired-Only Mode

- If you would like to charge a device using USB cable only, it is more energy-efficient to use the wired-only mode. If the red LED is on, press-and-hold the power button for 3 seconds to turn off wireless transmitter. See **Charging in Wired+Wireless Mode** above for additional steps.

Safety Information and Precautions

- Keep your QiWi dry. Nev short-circuit, over-heating, smoking, fire, deformation, or even explosion of the battery. Do not touch the device if your hands or feet are wet. Store and charge your device in a cool and ventilated place.
- Do not store or charge your QiWi in very hot or very cold areas. Extreme temperatures can damage the device and reduce the charging capacity of the battery. It is recommended to use your device at temperatures from 41 to 95 degrees Fahrenheit (5 to 35 degrees Celsius).
- Never place your QiWi in fire. Never place the battery or device on or in heating devices, such as microwave, ovens, stoves, or radiators. The battery may leak and your device may explode when overheated.
- Do not expose your QiWi to direct sunlight for an extended period of time. Do not use your device outdoor during a thunderstorm.
- Do not crush, puncture, disassemble, or modify your QiWi, as this can damage the device or cause fire or explosion.
- Do not short-circuit your QiWi. Doing so may cause electric shock or fire, and the battery may malfunction or explode.

- Do not store your QiWi together with metal objects, such as coins, keys, and necklaces.

- Do not store your QiWi near strong magnetic fields. Your device may malfunction or the battery may discharge from exposure to magnetic fields.

Keep your QiWi out of reach of small children to prevent danger.

- Always comply with regulations for battery disposal to avoid causing explosion and/or pollution.

- Do not use damaged power cords or plugs, or loose electrical sockets.

- Recharge using only standard 5V USB chargers, such as wall chargers, car chargers, or computer USB ports. If you use an incompatible adapter, the built-in battery may not be charged fully or be damaged.

- Use only Qi-standard conforming wireless receivers to connect with the transmitting terminal.

- Please stop using your QiWi immediately if it bulges, leaks, or smells, and contact the Manufacturer for service.

Troubleshooting

- Before using your QiWi for the first time or if only one blue LED light is on or flashing, please recharge the power bank.

- The model QIWI-G2-GW (glossy white) has a shiny, slippery surface. To use the device on the go, install the anti-skid rubber pads on it based on your preference. For the lithium-polymer battery to reach its optimal charging capacity, it may take a few full charge-and-discharge cycles.

- To charge QIWI-G2-LW/LK at fast speed, use a USB

- charger with 2A+ current and a USB charging cable supports 2A+ current, such as the included 2-in-1 cable.

- For wireless charging, your mobile device must be equipped with a Qi wireless receiver. QiWi can automatically identify a Qi-compatible device placed on it.

- When QiWi is not connected with an external power source and no device is detected, QiWi will time out after 16 seconds of no activity to conserve battery.

- For wireless charging, the center of the wireless receiver must not deviate from the center of QiWi by more than 2cm (0.8in). The larger the deviation, the lower the charging efficiency becomes. If your wireless receiver is not detected, please adjust the position of your mobile device to find an optimal alignment. Most Qi-standard conforming smartphones or tablets place the center the Qi wireless receiver at the center of the device, but there are exceptions (such as some LG and Nokia phones).

- The blue LEDs are off during wired or wireless charging in order to conserve battery. You can confirm normal charging by checking your electronic device. You can check the remaining battery capacity of your QiWi by pressing the power button.

- If wired charging is not working properly, please try a different USB cable, since the micro-USB connector may become loose due to wear.

- During charging, QiWi may become warm due to high currents and resistance, especially during wireless charging. To reduce temperature, avoid running intensive applications or using GPS on your mobile device when charging.

Warranty Information

MobilePal LLC warrants that this device is free from defects in material and workmanship under normal use for twelve (12) months commencing upon the date of purchase by the first consumer purchaser. Proof of purchase is required for warranty service. The consumer should never attempt to open or disassemble the device, and doing so may cause damage that voids your warranty. This warranty does not apply to devices purchased from unauthorized sellers. During the warranty period, MobilePal will, at its sole discretion, repair or replace any defective devices. Repaired or replaced devices will be warranted for a period equal to the remainder of the original Limited Warranty on the original device or for ninety (90) days, whichever is longer. The customer is responsible for the shipping cost to MobilePal, and MobilePal will cover the one-way shipping cost to the customer.

Contact Information

- Email: support@mobilepal.us
- U.S. Toll-Free Service Number: (800) 299-2599 (Please leave voice mail)
- Website: <http://www.mobilepal.us>

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE 2: This product may cause interference to radio equipment and should not be installed near maritime safety communications equipment or other critical navigation or communication equipment operating between 0.45–30 MHz. Variations of this language are permitted provided all the points of the statement are addressed and may be presented in any legible font or text style.

Safety Information for RF Exposure

The device should not be used next to the body.

This device is designed for desktop usage.

This device has been tested for compliance with RF exposure limits at 10 cm from user.