

Universal Wireless Remote Controller User Manual



difference due to different software and system, like: \textcircled{A} key is for mute under iOS, but for camera under Android.

4.2 Shutter operation

For iOS mobile, press \textcircled{B} key to shutter; for Android Samsung mobile, then press \textcircled{A} key to shutter, Volume key to adjust focus; for other Android mobile, please enter camera setup first, then set volume key to shutter or scan barcode to download Zuzhulin camera software.

4.3 Mouse operation (just for Android)

Press START/U and \textcircled{X} at same time, then joystick can change to mouse function, START/U is for mouse confirm key. Press START/U and \textcircled{A} at same time, then can switch to music mode. If need mouse function in default when power on, please press button START/U and \textcircled{X} at same time to boot.

MENU function: press \textcircled{B} and \textcircled{X} at same time, then change to MENU.

4.4 E-Book flip function

In iReader: use Volume +/- to turn page up down; In Kindle, use Game mode to turn page.

5. GAME function: Turn side switch to Game side (there is "GAME" on back), now device is operated by two-hands horizontal.

5.1 Game function on Android

In Menu, if joystick can move cursor, Key \textcircled{X} is confirmation button, Key \textcircled{A} is returning button, then means your mobile system can support international standard gamepad, just download game and play directly (If can't operate, then refer to part 6, Android MTK mobile operation)



Game Download: use QR code software to scan QR

code on the packing (or enter into website: <http://112.124.19.238:8080/GameMarket/>) to enter

03

6.1 MTK Power on mode: under power off state, press key \textcircled{A} first, then press START/U at same time until red LED light is on, the device turn on successfully. Next time, press key START then default to MTK mode. If want to shift to standard Android mode, press key \textcircled{A} , and START/U , then ok.

6.2 Function instruction on MTK mode Music, mouse and shutter are same with standard Android, just game mode is different. MTK mode can support Zuzhulin simulation directly, but can't support standard Android APK games.

7. Charge: Our product is with inner rechargeable lithium battery, when power is low, charging LED will flash (standard mode is red color, MTK mode is blue color), please insert 5V USB port to charge, then charging LED will be on. And when power is full, charging LED will be off.

Notes:

- When accident cause not boot or unable to shutdown, please use needle to press Reset button on back
- If already paired, but can't connect, please cancel the pair and boot the device and connect again.

Product Specifications

Item	SPEC
SIZE	73mmx31mmx13mm
Wireless Protocol	Wireless 3.0 Compliant
Wireless Distance	2-10 Meters
OS	Android /iOS/PC
CPU	ARM968E-S Core

05

Many thanks for purchasing our product! This is a portable Wireless control, used for mobile phone, MID, TV box, smart TV, PC and so on. It can be used as gamepad, wireless mouse, music control, e-book page, PPT presentation etc. and support iOS, Android, Windows and so on.

Important Note: Products are subject to change without any notice. And this product has applied for patents, counterfeiting is not permitted.

Operating instructions:

- Power On: Press START/U button until LED is on (about 2 seconds).
- Power Off: Press START/U button until LED is off (about 5 seconds). Note: If no connecting with Wireless device after 5mins, system will power off automatically; after connecting with Wireless device, if no any operation, system will power off after 60mins.
- Pair and connect: after power on, LED indicator will flash, the device will enter into the Wireless pair mode automatically to find the address and name of this device (SKB032A xx-xxxx), click then can connect. Pair and connect successfully, LED indicator will turn off. Next power on, it can connect and match the last Wireless device. Under turn off state, press START/U (over 8 seconds), LED will flash, then go to pair mode again, and can't connect last paired device automatically.

- KEY Mode: Turn switch on side to KEY (there is "KEY" on the back). The device operation is one-hand vertical operation. (as shown to the right)

4.1 Music operation:

After connecting with Wireless, open mobile's music player (like Samsung's player), click play, then can use this device to operate, like music play, pause, changing songs and so on. There are some



02

into ZUZULIN download center, then you can download ZUZULIN game application or third party's game application. ZUZULIN Game center have all gamepad games, and support NES/GB/GBC/SFC/SMD/GBA/N64/MAME/PS games. Users can also download simulator BIN files to Games file folder in mobile, then can use ZUZULIN software to open the game file, like many famous games: Super Mario, Metal Slug, Sangokushi and so on.

Android games usually have gamepad type, download this kind of games, just connect with Wireless then can operate with gamepad directly (please note, turn side switch to "Game"), this kind of games are like: Eternity Warriors 2, FIFA 15 and so on. (Some games maybe need to use gamepad control when playing)

senior game combination key:

SELECT = START/U + \textcircled{A} L1 = START/U + \textcircled{X} R1 = START/U + $\textcircled{△}$
right joystick = left joystick + START/U L2 = START/U + $\textcircled{○}$ + \textcircled{X} R2 = START/U + $\textcircled{○}$

5.2 iOS game

Game download: Enter into iOS APP store or other Apple store, search "icade", then you can find games of iCade which support gamepad, download and install then ok, like Akane Lite, Brotherhood, TTR Premium and so on.

Before play games, please set keyboard input mode to English input and can input English letters then ok. Next, please connect with Bluetooth and enter games then can play (Some games maybe need set to use iCade when playing)

Combination keys: SELECT = START/U + \textcircled{A} L1 = START/U + \textcircled{X} R1 = START/U + $\textcircled{△}$

6. Android MTK mobile operation

Like Redmi 3G version, Huawei Honor3X, CoolPAD, Zhongxing, these old style mobiles use MTK CPU, due to MTK bad compatibility, they can't support international standard gamepad agreement. So if by standard Android connection method, unusual problems will happen. We preset MTK mode to support ZUZULIN games.

04

Battery	Rechargeable lithium battery 180mAH
Working time	About 20-40 hours
Working current	0.5~8mA
Standby current	0.5-1mA
Recharging current	5V <200mA
Shutdown current	<20uA

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.



Scan above QR code to get more details, help and game resource.