



ECIFICATIONS Earbud Weight: 4.5 grams Speaker Driver Size: 10 mm Supported Profiles: HFP, HSP, A2DP, AVRCP Bluetooth Version: 5.0 Earbud Charging Time: Up to 1.5 hours Working Voltage: 5V Standby Time: Up to 70 hours Daytime (Normal mode): Up to 7 hours Daytime (ANC mode): Up to 5 hours Volume: 70% volume Bluetooth Range: 10m Number of Microphones: 3 Working Temperature: 0°C to +45°C	CHARGING CASE SPECIFICATION • Charging Case Weight: 48 grams • Charging Port: Type-C • Number of Earbud Charges from Case: Up to 4 times • Case Charging Time: Up to 2 hours • FCC ID: 2AEZG-I3	PACKAGE CONTAINS Insmy-i3 Earbuds x1 Charging case x1 Large Ear Tips x2 Medium Ear Tips x2 Small Ear Tips x4 USB Type-C Charging Cable x1	POWER ON The earbuds will automatically turn on on opening the charging case. POWER OFF The earbuds will automatically turn off on closing off the charging case. PAIRING • Open the charging case. • Turn on the Bluetooth of your device. • Select 'Add Device' and from the list of devices, select Insmy-i3. • Your Insmy-i3 are now paired with your device and ready to use. • Note: Your Insmy-i3 will automatically connect to the last paired device as soon as you open the charging case.	 POWER ON	RESET Make sure that Insmy-i3 are fully charged and the case is open throughout the process. Unpair/forget the earbuds from the 'saved devices' on your Bluetooth settings. Place both the earbuds inside the case. Open the charging case. Long press the button on the charging case for 10 seconds while it's charging. Note: The 4 LEDs will flash in white 5 times indicating that the earbuds are reset.	 MEDIUM TIPS LARGE TIPS SMALL TIPS	SMART SOUND FEATURES HYBRID ANC The Insmy-i3 feature 3 advanced microphones on each earbud that capture ambient/environmental noises. These noises are processed by the hybrid noise-cancellation system that equalises them before they reach your ears, making sure that you get the best sound. Long press the right earbud for 2 seconds to enter the ANC mode.	 POWER ON	How to clear the product memory of connected Bluetooth devices? Put the earbuds into charging case without closing the lid, long press 8 seconds to clear the paired Bluetooth device records.	 POWER ON	Clear successfully 4 lights will turn off after 3 seconds	 POWER ON	Failed 4 lights flash 10 times then go out.	 POWER ON	CHOOSE YOUR EAR TIP SIZE Earphones are fitted with medium-size tips. However, if you find they don't fit perfectly, please remove and try the small and large ear tips. Follow the images and chart to learn how to wear the earbuds in the right manner.	 Basic mode > ANC mode > Transparency mode	TRANSPARENCY MODE Transparency mode ensures that you get to hear the outer sounds and know what's going on around you, without affecting the quality of what's being played on your earbuds. Long press the right earbud for 2 seconds to enter transparency mode from the ANC mode.	 Basic mode > ANC mode > Transparency mode	Charging or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
--	---	--	--	---	--	--	---	---	--	---	---	---	---	---	---	--	--	--	--