



Square Handheld

Getting started

For additional help, visit square.com/support

Setup

- 1

Power on

Push the power button until the Square logo appears on the screen. Charge the battery if it's low. Be sure to keep your device on and connected to the internet while charging overnight for necessary software updates.
- 2


Connect to Wi-Fi

Follow the steps on the screen to connect to Wi-Fi and install any software updates.
- 3

Log in to your Square account

If you don't yet have a Square account, please create one at square.com to get started.

Device overview



Device functions

- #### Contactless payments

Hold the device or card close to the screen to complete payment.
- #### Chip card payments

Insert the chip card into the dip slot with the chip facing up.
- #### Barcode scanner

Hold down the barcode button and aim the green light at the barcode you want to read. You can also scan gift card QR codes for payment.
- #### Camera

Use the built-in camera to easily add photos to item details and more in Square Point of Sale.
- #### Swipe (additional reader required)

Plug in Square Reader for magstripe (USB-C) to take swipe payments. Square Reader not included.

M-LIT-0341-01

EXTERIOR / FRONT PANEL

EXTERIOR / BACK PANEL

US	PART #	REV	MECHANICAL#	INK & COATING	BLACK + PMS CG11	2/2 w/Bleed + ASMAQ Mineral Oil Free Ink	REV. NOTE	
	M-LIT-0341	-01	M05					
MODIFIED	February 24, 2025 1:57 PM			SIZE	FLAT: 328 × 189 mm FINISHED: 82 × 189 x .6 mm		PROD. NOTE	Diecut Fold
FILE	M-LIT-0341-01_T3_QSG_US_M05				MATERIAL	157g C2S paper 8PP		
PROGRAM	T3 Packaging Quick Start Guide			FINISHING		Diecut, Score, 4-Panel Accordion Fold		
SELLABLE	US				SUPPLIER	RRD China		
	TEAM	DESIGN: Eric Manago PM: Liz Doering	PPM: Valerie Alaimo PA: Stef Lewendon	DRAWING		A019-24-2303-01A_110_05_T3 Retail PKG_GSG		

Configuración

1

Enciende el dispositivo

Pulsa el botón de encendido hasta que aparezca el logotipo de Square en la pantalla. Carga la batería si está baja. Asegúrate de mantener el dispositivo encendido y conectado a Internet mientras lo cargas durante la noche para realizar las actualizaciones de software necesarias.

2

Conéctate a Wi-Fi


Sigue los pasos que aparecen en pantalla para conectarte a Wi-Fi e instalar cualquier actualización de software.

3

Inicia sesión en tu cuenta de Square

Si aún no tienes una cuenta de Square, crea una en square.com para comenzar.

Vista general del dispositivo



Funciones del dispositivo



Pagos sin contacto

Mantén el dispositivo o la tarjeta cerca de la pantalla para completar el pago.



Pagos con tarjeta con chip

Inserta la tarjeta en la ranura con el chip hacia arriba.



Lector de códigos de barras

Mantén pulsado el botón del código de barras y apunta la luz verde al código de barras que quieras leer. Para pagar, también puedes escanear los códigos QR de las tarjetas regalo.



Cámara

Utiliza la cámara integrada para agregar fácilmente fotos a la información de artículo, y mucho más en PDV Square.



Desliza (se requiere un lector adicional)

Para recibir pagos deslizando una tarjeta, conecta Square Reader para tarjetas de banda magnética (USB-C). Square Reader no está incluido.

HARDWARE PROTECTION

Your Square hardware comes with a limited one-year warranty. To find warranty information, go to square.com/warranty.

FREE 30-DAY RETURNS

Square offers a 30-day, risk-free return policy for all purchases made from square.com/shop. Visit square.com/returns to process your return. After a return is complete, a refund will be credited back to you.

REGULATORY INFORMATION

View regulatory information for Square Handheld by swiping down from the top edge, tapping the ⚙️, and then tapping **Regulatory**.

Transmitters in the 5.925–7.125 GHz band are prohibited from operating to control or communicate with unmanned aircraft systems.

This device has been evaluated and meets the applicable regulatory requirements for exposure to radio waves. This device is evaluated in positions that simulate when worn or carried against the torso of the body with 10 mm separation, and when held by hands with no separation. Ensure that the device accessories, such as a device case and device holster, are not composed of metal components.

PROTECCIÓN DE HARDWARE

Tu hardware Square tiene una garantía limitada de un año. Para encontrar información sobre la garantía, ve a square.com/warranty.

DEVOLUCIONES GRATIS DE 30 DÍAS

Square ofrece una política de devoluciones de 30 días sin riesgo para todas las compras realizadas en square.com/shop. Visita square.com/go/devoluciones para procesar tu devolución. Una vez completada la devolución, se te abonará el reembolso.

INFORMACIÓN REGULATORIA

Para ver la información regulatoria del dispositivo portátil de Square, desliza el dedo hacia abajo desde el borde superior de la pantalla del dispositivo, pulsa el icono de engranaje ⚙️ y luego pulsa **Regulador**.

Este dispositivo ha sido evaluado y cumple con los requisitos reglamentarios aplicables para la exposición a ondas de radio. Este dispositivo se evalúa en posiciones que simulan cuando se usa o se lleva contra el torso del cuerpo con una separación de 10 mm y cuando se sostiene con las manos sin separación. Asegúrate de que los accesorios del dispositivo, como la funda y la funda del dispositivo, no estén compuestos de componentes metálicos.

© 2025 Block, Inc., 1955 Broadway, Ste. 600, Oakland, CA 94612. Square and the Square logo are trademarks of Block, Inc.