



THANK YOU
for your purchase

For warranty information go to
www.lockdown.com/warranty




This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions: (1) this
device may not cause harmful interference, and (2) this
device must accept any interference received, including
interference that may cause undesired operation

INSTRUCTIONS

PAIRING

1 2 3



The Hygrometer must pair with the Remote Sensor. To pair, set the Remote and Hygrometer to the same channel and then place the batteries into both units. It may take a few minutes for the devices to pair. The Remote Sensor channel selection switch is located behind the batteries in the battery compartment.

HYGROMETER



The illuminated screen defaults to off to conserve battery life. To turn the screen on, tap anywhere on the device. The screen will light up for 5 seconds, then turn off again.



The default display shows the current temperature and humidity. To view the Minimum and Maximum values, press the Min/Max button on the back of the device. It will cycle between Max, Min, then change back to the current view. To reset the Min/Max readings, hold the Min/Max button for 3 seconds.



To change the temperature scale to Celsius or Fahrenheit, press the C/F button on the back of the device.

REMOTE SENSOR



The Celsius or Fahrenheit button is located above the channel selection switch. You may need to use a pen to depress the button.