

## USER'S MANUAL

### BLUETOOTH HEADSET



\*The picture is only provided for reference. Please refer to the actual unit!

#### **GETTING STARTED**

Please read this user's manual carefully before using the product to make a correct use of all functions and know well about the system connection and usage. Please keep this manual in a safe place for future reference.

#### **INTRODUCTION**

This Bluetooth® earphone will allow you to listen to your music wirelessly from your mobile phone, tablet or other Bluetooth® enabled device. It delivers powerful and clear sound. The built-in microphone will allow you to answer calls from mobile phone.

#### **WARNING**

Prolonged use of earphones at high volume may cause irreparable hearing loss. We strongly advise you to adjust your listening volume to a reasonable level. The higher the volume, the more you risk damaging your hearing quickly.

We also recommend you to use your earphones responsibly! It is dangerous or even illegal in some areas, to use earphones in situations that require your full attention, such as driving a car, motorcycle or bicycle, but also as a pedestrian when crossing the street, etc.

#### **PRECAUTIONS**

First thank you for buying this Sport Bluetooth® earphone. Please refer to this Users' Manual before use to use it properly. The contents stated herein may be modified from time to time for better service as the product properties and functions are changed without prior notice. For the sound performances of the product, never use it in too cold, too hot, too dusty or humid places, especially:

1. Moist or underwater conditions
2. Near the heater or hi-temperature services or solarization
3. Places apt to fall
4. Never disassemble the combination audio; otherwise, it may invalidate the warranty.

### **Key description**

- 1: Multi-function button (MFB) : “—”Power on/power off/answer a call/end a call/reject a call/ pause/play music
- 2: “+” button: Short press to increase volume; Long press for Next track
- 3: “-” button: Short press to decrease volume; Long press for Previous Track
- 4: Built-in microphone
- 5 Charging port

### **FUNCTION OF LED INDICATOR**

#### **A. When charging**

RED LED is on when the battery is charging.

RED LED is off when battery charge is finished.

#### **B. When using the earphone**

RED and BLUE LED blink alternately when the earphone is in pairing mode.

Stand By mode: the LED rapidly flashes BLUE.

Music playback mode: LED flashes slowly in BLUE.

RED LED blinks with sound alert when the battery has low power.

### **CHARGING BATTERY**

The earphone comes with a built in rechargeable battery. Before using it for the first time we recommend you charge the battery fully. Only use the supplied USB Cord to charge the earphone. Please charge for 1 hours.

Connect the micro USB connector of the charging cable into the micro USB port on the side of the earphone. Connect the other end of the USB cable to your computer's USB port or to an optional USB wall charger (not included)

The RED LED indicator light is illuminated.

The BLUE LED indicator light on when the earphone is fully charged.

## **SWITCHING ON / OFF**

**Switch ON :** Press and hold the MFB for 3 seconds, until the LED flashes BLUE. You will hear a tone voice "du" in the earphone.

**Switch OFF:** Press and hold the MFB for 3 seconds, until the LED flashes RED. You will hear a tone voice "du" in the earphone.

## **PAIRING INSTRUCTIONS**

You need to pair the earphone with your Bluetooth® enabled device (smartphone, tablet, notebook, computer, etc.) before enjoying the music wirelessly with the earphone.

### **Enter in pairing mode**

Be sure that the earphone is in power off status first, press and hold the MFB for 3-5 seconds, until red and blue led blink alternately. Then release the MFB button, the unit is now in paring mode. The earphones emit the tone voice "di" it means in pairing mode.

**Pairing the earphones with Bluetooth® devices** Make the earphones enter into pairing mode (please refer to above section)

Place the Bluetooth® Earphone and Bluetooth® device (phone, tablet, music device) at 1 meter from each other.

Activate the Bluetooth® function on your Bluetooth® device. Please refer to the manufacturer's manual for instructions on enabling Bluetooth® on your device.

After searched, select "CK-BT19" in the device list on the Bluetooth® device.

If a password is asked, enter the "0000" and press "connect" (only some Bluetooth® devices will ask for a password)

When the connection is successful, the voice message "connected" is heard from earphones and BLUE LED will quickly flash a few times when pairing is successful.

Please note pairing mode on the headphone will last for around 3 minutes. If no devices are paired within around 3 minutes the headphone will automatically return to standby mode.

If pairing is unsuccessful, turn off the headphone first and then re-pair again following the above steps.

### **Re-connecting to Bluetooth® devices**

Every time the headphone is switched on, it will connect to the nearest and the last connected device automatically .

When the headphone is in standby mode and doesn't connect to any device, short press the MFB button and it will connect to last connected device automatically.

## **LISTEN TO MUSIC**

### **LISTEN TO MUSIC**

When the headphone is correctly paired with your Bluetooth® device, simply start to play music on your device and you can enjoy the sound wirelessly in your headphone.

**Volume up in music mode:** Short press on volume "+" key. You will hear a beep tone when the maximum volume level is reached.

**Volume down in music mode:** Short press on volume "-" key. You will hear a beep tone when the minimum volume level is reached.

**Go to next song of your playlist:** Long press on the Next « + » key.

**Go to previous song of your playlist:** Long press on the Prev « + » key.

**Play/Pause music:** Short press on the MFB to pause the music. Short press again to play again.

## **HANDS-FREE FUNCTION**

You can answer calls from your mobile phone when the headphone is paired with your mobile phone. If you receive a call when listening to music, your music will pause automatically and you will hear your telephone ring tone in the headphone.

**Answer a call:** Short press the multifunction button.

**Reject a call :** Press and hold the MFB button for 1 seconds until an indication tone is heard.

**End a call:** Short press the multifunction button.

**Volume up in conversation mode:** short press on volume "+" key. when the volume has reached the maximum level, you will hear an indication tone.

**Volume down in conversation mode:** short press on volume "-" key, when the volume has reached the minimum level, you will hear an indication tone.

## **MOBILE DEVICES SUPPORTED**

In theory, it can support all equipments with Bluetooth®-enabled phone or music device that supports Advanced Audio Distribution Profile (A2DP) and Audio Video

Remote Control Profile (AVRCP). In order for Bluetooth® devices to communicate with one another properly, they must utilize the same Bluetooth® profile. To determine the profiles supported by your device, please refer to the device's user guide. Certain Bluetooth features including those listed may not be supported by all compatible Bluetooth®-enabled devices, and/or the functionality of such features may be limited in certain devices.

## **TROUBLESHOOTING**

### **Bluetooth® pair and connection fail**

Other cell phone or equipment has been connected before connection, and has not left yet and Bluetooth® cannot be switched off. When connection feature is employed again, the Bluetooth® unit will automatically search for this Bluetooth® equipment for connection. First turn off the Bluetooth® feature of Bluetooth® equipment and the next Bluetooth equipment can search, pair and connect normally.

### **The indicator lamp does not turn on and the Bluetooth® unit is not available**

Bluetooth® unit has not operated for a long time, and may come into dormant state, then press the MFB on the unit for a longer time to re-use it.

### **Short Bluetooth® connection distance**

There is a barrier between the cell phone and Bluetooth® headphone, please clear it away.

### **Bluetooth® may be normally connected and played, but sometimes, there is interrupted**

1. There is a barrier between device phone and Bluetooth® headphone, please clear it away.
2. The distance between the Bluetooth® unit and connected device is too far away, out of normal connection range. Please put them nearer.
3. The battery of earphones is discharged, please recharge it.

## **TECHNICAL SPECIFICATIONS**

Bluetooth® specifications: v4.2

Working distance: up to 10 meters in open space

Built-in microphone for answering calls from mobile

Built-in rechargeable 90mAh lithium battery - Charging time 1 to 2 hours\*

Up to 3 to 4 hours play time and 150 hours standby time

\* Battery life & charging time may vary, based on usage & types of devices used

Charging method: Micro USB cable 5V

Box content : Bluetooth® Earphone – Micro USB cable – User manual

## RESPECT THE ENVIRONMENT

 This product or its battery can not be disposed of with household waste, it must be returned to a collection point to be recycled. Please check with your local authorities for details.

### Warnings

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## ABOUT THIS USER'S MANUAL

We strive to ensure that the information contained in this manual are as accurate as possible. Changes may be made to the manual or the product without prior notification. All brands and trademarks mentioned in this manual are the property of their respective owners.