



iRock-Elite
Elite Bluetooth Speaker with Flashing LED
Lights
User Manual

Caution and Safety

1. Do not immerse in water or expose to moisture, sunlight, or heat.
2. Store in a cool and dry place.
3. Do not expose to fire.
4. Avoid excessive impact; please discontinue use if the speaker is damaged.
5. Do not disassemble the speaker; there are no user-serviceable parts inside.
6. Excessive exposure to loud sound may result in hearing damage.

Introduction

The iRock-Elite Bluetooth Speaker gives you the freedom to enjoy your music anywhere. Exceptional sound quality is packed into this portable speaker. It is Bluetooth version 2.1 compliant and is compatible with mobile phones, tablets, laptops, and computer systems that feature Bluetooth technology.

You can also connect with the built-in 3.5mm LINE-IN audio port that allows you to play music directly from your MP3 player or other device.

The iRock-Elite Bluetooth Speaker can be used to conduct phone calls when you use the mobile phone function.

Charging the Speaker

1. Before first time use, charge the speaker for 2 hours with DC 5V output charger.
2. Plug the supplied USB connector into your Bluetooth Speaker's "DC 5V" port. Plug the cable into a desktop computer or an AC wall charger. The LED indicator will turn red when speaker is charging. The light will turn off when the charging is complete.

Bluetooth Pairing and Use Instructions

1. Slide the ON/OFF switch to ON position.
2. The speaker will beep and the LED light will flash blue. It is now ready to pair with your device.
3. Turn on Bluetooth on your device. Your device will search for any Bluetooth devices in range. You should select "IROCK-ELITE". The LED light is blue when successfully paired.
4. Music volume can be controlled by adjusting the volume on your device, or long press "-/||" or "+/||" button on speaker.
5. You can PAUSE and RESUME by pressing "▶||", go to next song by short press "+/||", go to previous song by short press "-/||".
6. When you use your telephone through the Bluetooth speaker, "📞" is for pick up and hang up, you can adjust the volume during the call.
7. If your speaker has been paired previously with another device within the effective range (30ft), then the original pairing must be removed. This is done by deleting or forgetting the Bluetooth settings of the original device.
8. If the device moves beyond the effective range, the Bluetooth connection will be disconnected. Once the device and speaker are back in effective range, you will need to again establish the Bluetooth connection between the device and the speaker.

Direct Connect

To use the speaker without a Bluetooth connection, use the supplied LINE IN

cable. Plug cable into "LINE-IN" port on the speaker and into the 3.5mm output jack on your device.

Product Specifications

- Up to 3 hours of playback time
- Charging: DC 5V/500mA
- Speaker power: 3W
- Frequency: 200Hz-20KHz
- Lithium battery capacity: 400mAh
- Scope: <30 ft. of wireless range
- Bluetooth compatibility: V2.1, V2.0, V1.1 and V1.2 standard
- Bluetooth protocol support: A2DP, AVRCP

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following

two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital

device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Tel: 852 2374 0002

Fax: 852 2374 0010

ADD: Units 2611 - 13A 26/F 113 Argyle st. Mongkok, Hong Kong



Made in China asi/57653