

Milaka Remote Shutter

Product Manual M01






Please scan the QR code to attention our WeChat Official Account.



WeChat Official Account

1 Product Display



Finger Grooves on Battery Cover

20perating Instructions

Before using Milaka remote shutter for the first time, you need to match it with the Bluetooth in your phone.

- a) Press shutter button to turn it on, the indicator will flash rapidly (1 second at intervals), indicating that the matching mode has been activated.
- b) When the indicator of Remote shutter turns into slow flashes, it means that Milaka remote shutter has been successfully matched with your phone.
- When Milaka remote shutters mains idle for a while, into the shutdown state.
 Unpaired:20 seconds.

Paired:60~120 seconds.

3 Matching Instructions with iPhone

- a) Enter Phone Settings.
- Turn on Bluetooth, so the phone can search and locate "Milaka Shutter" if the remote shutter is switched on.



 Match Milaka remote shutter with iPhone.




 d) "Connected" will be displayed after successful matching, then turn on the camera to take photos.



4 Matching Instructions with Android

- a) Enter Phone Settings.
- b) Turn on Bluetooth, so the phone can search and locate "Milaka Shutter" if the Remote shutter is



c) Choose "Milaka Shutter" for matching.



d) Matched will be displayed after successful connection. If the phone supports "side key volume '+' photo taking", Milaka remote shutter can directly to take photos. If not support "side key volume '+'photo taking", you need to download App "Camera.apk". App "Camera.apk" will be available via the following two channels:

- Visit the website to download at: <u>www.maircom.com/down/html/?11.ht</u> ml
 - Scan the QR code to download.



5 Product Parameters

Product Name	Milaka remote shutter
Туре	Intelligent Accessories
Bluetooth Version	4.0 Bluetooth
Battery Type	Button Battery(CR2016)
Dimensions	31.4 x 31.2 x 7.5 MM
Product Color	Orange / Pink / Green / Purple / Blue / White / Yellow
Battery life	Up to 200 days
Photograph -ic Distance	0-10 M
LED	Red
Button	A multifunction button

Stand by iPhone 6 Plus / iPhone 6 / iPhone 5S / iPhone 5C / iPhone 5 / iPhone 4S / iPad AIR / iPad 4 / iPad mini / iPod touch5. Compatible Stand by Samsung Models GALAXY S5 / Samsung Note 3 / LG Nexus 5. Support all models with Bluetooth 4.0 and Android system 4.3 or higher.

6 Statement

To know more information about our Company and our products, please visit the Milaka official website:

www.milaka.cn

Welcome to official website of Shenzhen Maircom Technology Co., Ltd.:

www.maircom.com

Shenzhen Maircom Technology Co., Ltd. reserves all intellectual property rights related to Milaka remote shutter.

FCC Caution.

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must

including interference that may cause undesired operation.
§ 15.21 Changes or modification

accept any interference received.

warning
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

the user's authority to operate the equipment.
§ 15.105 Information to the user.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits

are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can

radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not

occur in a particular installation. If this equipment does cause harmful interference to radio or television

reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between thee quipment and receiver.

on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced

Connect the equipment into an outlet

- radio/TV technician for help. * RF warning for Portable device:
- The device has been evaluated to meet general RF exposure requirement. The device can be used

in portable exposure condition

without restriction.