Remote Control Battery Box User Manual Model:RCBB-01





Pcamway Electronic Industry Limited Rm.1902, Easey Comm. Bldg., 253-261 Hennessy Road, Wanchai, Hong Kong

This product mainly through the remote controller to control the battery box, first of all, please according to the operation that the remote control device and a battery box matched, different buttons provide different functions, please strictly in accordance with the following operations required to operate.

How to use the remote controller?

1, Match the remote controller with battery box

The first time to use the heated socks: Press the battery box's button for about 2 seconds, when the LED is red flashing. Press the RED button of remote controller. When the battery box's LED is off, Match remote controller with the battery box is finished.

- 2, Remote controller: (Three stage is adjustable)
- ①.Press ON1, the first stage, The LED is red.
- ②.Press 2,the second stage,The LED is orange.
- ③ Press 3,. The third stage ,The LED is green.
- 4). Press Red button, it is closed

How to use the battery box's button. (Three stage is adjustable)

- ① The first time to press the button. The battey box is ON, It is the first stage, the LED is red.
- ② The second time to press the button. It is the second stage. The LED is orange.
- ③ The third time to press the button. It is the third stage. The LED is green.
- 4 The fourth time to press the button. It is OFF.



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.