YI Home Camera 1080P User Manual

Front




1.Download the app


Scan the YI Home app QR code below to complete the installation. You can also download it on the App Store™ or Google Play store by searching for YI Home app




2.Get Started

power outlet as shown.






3. Open The Back Cover



4.Inserting SD Card

Note: To enable local recording of video clip, please insert a Micro SD card* (not included) in the slot as shown below
*support minimum of 8GB up to 32GB, class4 & above Micro SD card



5. Connect the camera to your phone



Back

6. Preview live footage ① Hold to talk ② Show timeline ② Playback history ② Record Videos ③ Take photos ③ Alerts ③ Mute ⑤ Full screen

7.Switch Wi-Fi Networks

When you need to switch Wi-Fi networks or update your Wi-Fi password, follow the instructions below:

- Use a clip to press the reset button on the back of the camera, and wait until the yellow light comes on.



Recommendations



- READ these instruction.
 CLEAN ONLY with dry cloth.
 This camera is for indoor use only.
 ONLY USE attachments/accessories specified by the manufacturer.
 UNPLUG this apparatus during lightning storms or when unused for long periods of time.
 To get the best usage out of this product, please consistently update to the latest versions of our app and firmware.

Congratulations! Your YI Home Camera is ready to use.

Conformément à la réglementation d'industrie Canada, le présent émetteur radio peut fonctionner avec une antenne dun type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les réquises de trovulage radioléctrique d'intention des autres utilisateurs, I faut choisir le type d'antenne et son gain de sorte que la puissance todrope rayonnée équivaiente (pur.e.) ne dépasse pas l'intensité né cessaire à l'établissement d'une communication satisfaisante.

