

ENJOYOU

BT-09

Bluetooth headset

Shenzhen Puhua Technology Co.,Ltd.

Introduction
Congratulations, and thank you for choosing Enjoyou BT09 Bluetooth Earphone. This manual will help you operate the earphone, but you should first familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the earphone. To enjoy your time with our product.

Safety rules
1. Please follow the rules depicted in this manual closely to ensure your safety. Before using this Earphone, we would strongly encourage you to read through this user manual.
2. Be more wary of any edges, uneven surfaces, metal parts, accessories and tools when using this Earphone, as they may cause you damage.
3. Do not modify, repair or dismantle this Bluetooth Earphone. Doing so may result in fires, electric shocks, complete breakdown of the Bluetooth Earphone, etc.
4. Do not use any flammable volatile liquid to clean the Bluetooth Earphone.
5. Do not use the Bluetooth Earphone in a hazardous location.

Package included

Bluetooth earphone x1
Portable charger x1
USB charge cable x1
User manual x1


(Accessories will be different according to different models. If you have any questions please contact us).

Charging the battery

Battery must be fully charged before first time to use.
1. Put Bluetooth Earphone into the charger.
2. Open the USB cover and insert USB cable to charge the earphone.
3. The earphone indicator will be red when you charging it. If the battery is fully

charged, the red indicator will become blue.
4. Please take it off from the charging device in time after the earphone is fully charged.

Graphical representation



Multifunction button

Turn on / Turn off pairing, play/pause, Answer / end / reject a call, last number redial.

ON/OFF

Power on
Press and hold the multifunction button for about 3 seconds, the blue lights flash once.

Power off
Press and hold the multifunction button for about 4 seconds, the red lights flash twice.

Pairing

When the number on the mobile phone, once the call has been set up, the sound will be transmitted to your earphone automatically.

Pairing

You are required to pair the earphone with your mobile phone before using it. 1. Please take it off from the charging device in time after the earphone is fully charged. 2. Activate Bluetooth on your mobile phone.

3. Set your phone to cover 'BT09' and click 'Pairing' button.
4. If you are in for pairing mode, please enter '0000'.
5. When the earphone and 'BT09' are paired, the blue LED indicator flashes twice.

6. There is no need to pair again after your earphone and Bluetooth device are successfully paired.

7. It will be connected automatically when you use next time after successful paired.

Pairing with two mobile phone at the same time

BT09 supports multi-point. This means BT09 can be paired and connected with 2 mobile phones at the same time.

1. Pair and connect the earphone with the first mobile phone. (please refer to the 'Pairing' section)

2. Turn on the Bluetooth function of the first mobile phone.

3. Turn off/turn on the earphone to pair and connect second mobile.

4. Turn on the first mobile phone, turn off/turn on the Bluetooth function on earphone, BT09 will be automatically pairing with both phones.

Making a call

Once the earphone is successfully paired and connected with your mobile phone, you can use it to make and receive calls.

Dialing a call

Dial the number on the mobile phone, once the call has been set up, the sound will be transmitted to your earphone automatically.

Pairing

Redial
Double click the multifunction button to redial the last number you called after a short tone.

Rejecting/connecting/holding/continuing/ending a call

When earphone is turned on and there is an incoming call, the blue indicator light flashes fast, you will hear incoming prompts operation.

1) Rejecting a call
Press the multifunction button for 2 seconds to reject the call.

(2) Answering a call
Short press multifunction button to answer the call.

(3) Holding a call
Press multifunction button 2 seconds to hold the call.

(4) Continue
Press the multifunction button for 2 seconds to continue the current call.

(5) Hang up
Short press multifunction button to end a call.

Warm tips

You must select a qualified charger, from a regular manufacturer.

You must charge the Bluetooth earphone if it has been not used for more than 12 months.

FAQ

Q: How can I turn on the earphone?

A: Make sure your device is fully charged before using it for first time. Your device can not be turned on if battery level is very low.

Q: Is there any sound when playback?

A: Check connection between your device with phone or computer, if the connection is not established, please reconnect again. And adjust the volume level to a suitable level.

Q: Is there any sound when playback?

A: Check connection between your device with phone or computer, if the connection is not established, please reconnect again. And adjust the volume level to a suitable level.

Q: What is the music on your mobile phone, the music will be transmitted to your earphone automatically. Short press the multifunction key, music pause, and then press a multi-function keys, music player.

Playing music

1. Avoid display your device to very cold or very hot temperatures (below 0°C or above 45°C) extreme temperatures can cause the deformation of the device and reduce the charging capacity and life of your device.

2. Do not use the device during a thunderstorm, thunderstorms can cause the device malfunction and increase the risk of electric shock.

3. Do not damage the earphone, otherwise may lead to earphone fault or burned, please send earphone to authorized service center for repairs.

4. Place the device and all accessories out of the reach of children and pets.

5. Do not remove or modify earphone for any reason otherwise may lead to earphone fault or burned and which is not listed in the warranty paper.

Low electricity

When the battery is low, the LED indicator light will flashes in red and you will hear the voice prompt of "battery low". The red indicator light turns on during charging.

Safety rules

1. Do not remove or modify earphone for any reason otherwise may lead to earphone fault or burned and which is not listed in the warranty paper.

2. Do not put the earphone into the water.

Technical specification

Bluetooth Version: 4.1

Bluetooth Profile: A2DP/HFP/HSP/AVRCP/SPP

Solution: CSR8610

Noise Reduction

Link Time: 1 hours

Music Time: 50 minutes

Standby Time: 100 hours

Wireless Range: 10 meters

Charging Time: 1 hours

Dimension: D13.8x21mm&D16x56mm

Notice

1. If BT09 earphone is not in pairing mode, your mobile phone won't find the earphone, please set the earphone into pairing mode before making your mobile phone searches for BT09(red and blue lights flashing alternately)

2. If no pairing is possible for a period of time(approximately 5 minutes) the earphone will power off automatically.

Warranty tips

You must select a qualified charger, from a regular manufacturer.

You must charge the Bluetooth earphone if it has been not used for more than 12 months.

FAQ

Q: How can I turn on the earphone?

A: Make sure your device is fully charged before using it for first time. Your device can not be turned on if battery level is very low.

Q: Is there any sound when playback?

A: Check connection between your device with phone or computer, if the connection is not established, please reconnect again. And adjust the volume level to a suitable level.

Q: Is there any sound when playback?

A: Check connection between your device with phone or computer, if the connection is not established, please reconnect again. And adjust the volume level to a suitable level.

Q: What is the music on your mobile phone, the music will be transmitted to your earphone automatically. Short press the multifunction key, music pause, and then press a multi-function keys, music player.

Playing music

1. Avoid display your device to very cold or very hot temperatures (below 0°C or above 45°C) extreme temperatures can cause the deformation of the device and reduce the charging capacity and life of your device.

2. Do not use the device during a thunderstorm, thunderstorms can cause the device malfunction and increase the risk of electric shock.

3. Do not damage the earphone, otherwise may lead to earphone fault or burned, please send earphone to authorized service center for repairs.

4. Place the device and all accessories out of the reach of children and pets.

5. Do not remove or modify earphone for any reason otherwise may lead to earphone fault or burned and which is not listed in the warranty paper.

Low electricity

When the battery is low, the LED indicator light will flashes in red and you will hear the voice prompt of "battery low". The red indicator light turns on during charging.

Safety rules

1. Do not remove or modify earphone for any reason otherwise may lead to earphone fault or burned and which is not listed in the warranty paper.

2. Do not put the earphone into the water.

After-sales service and support

If the product you bought have a damage caused by not man made reason, please return to us or merchant to guarantee.

Warning

If an old has any change and will refers to national relevant laws basis on our country.

1. The defects resulting from improper or unreasonable use or maintenance, failure to follow operating instructions.

2. The damage caused by the dismantle movement of a non-our-company authorized merchant.

3. If do not use with the instruction request such as non standard and not meet the specific power and usage range to damage the device.

4. Do not damage the earphone, otherwise may lead to earphone fault or burned, please send earphone to authorized service center for repairs.

5. The damage caused by the drop, scratch or Transport collision etc. non quality problem after purchase.

6. The breakdown and the damage caused by the Force majeure(Such as lightning, floods, fires and other natural disasters)

Warranty instruction

Product warranty time for one year(calculated from the date of the invoice)

■ Please be sure to confirm the following matters

1. Please fill in and sign the product guarantee card to make sure that the products get the warranty service when you purchase the products.

2. During the warranty time, the user can obtain free maintenance service if occurred damage and use according to the instruction manual.

3. Please provide the warranty card along with your product and make sure that the information is true or it is invalid.

4. If the warranty period has expired, you still can get the company provides Warranty service, but need to pay the appropriate fees.

Warranty service, but need to give under the following circumstance

■ Free maintain won't be given under the following circumstance

If an old has any change and will refers to national relevant laws basis on our country.

1. The defects resulting from improper or unreasonable use or maintenance, failure to follow operating instructions.

2. The damage caused by the dismantle movement of a non-our-company authorized merchant.

3. If do not use with the instruction request such as non standard and not meet the specific power and usage range to damage the device.

4. Do not damage the earphone, otherwise may lead to earphone fault or burned, please send earphone to authorized service center for repairs.

5. The damage caused by the drop, scratch or Transport collision etc. non quality problem after purchase.

6. The breakdown and the damage caused by the Force majeure(Such as lightning, floods, fires and other natural disasters)

ENJOYOU

Guaranteed card User card

[Distributor return receipt]

Product name:

Product type:

User name:

User address:

Contact NO.:

Postcode:

Purchase Date:

Distributor company name and address (if applicable)

Name:

Address:

Telephone No.:

Produced by puhua technology co.,Ltd

4/F BLDG-B,Forzen Technology Park,Fuyuan 2nd Road,

Fuyong Town,Baoan District,Shenzhen,China,

Place of origin: Shenzhen China

FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF warning statement: the device has been evaluated to meet general RF exposure requirement , The device can be used in portable exposure condition without restriction.