
## 便携式折叠键盘 说明书

支持系统 Win/iOS/Android 注意:正确操作本产品,请仔细阅读用户手册。

# 产品功能 /indows




## 蓝牙连接(以蓝牙1模式键为例) 1.打开电源开关.(开机) S || D 2.按fn+ **①** 蓝牙键切换通道 ∥ S





SH. MARIN.









常见问题解答

1、平板无法连接蓝牙键盘?

搜索设备讲行连接。

键盘充电后再使用。

2、键盘指示灯在使用途中一直闪烁?

按键盘任意键唤醒,蓝牙连接自动恢复。

iOS System (Bluetooth Connection)

-- Consult the dealer or an experienced radio/TV technician for help

that may cause undesired operation.

This device complies with part 15 of the FCC rules. Operation is subject to

the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference

4 Go to Settings and turn Bluetooth on.

Please complete Bluetooth Connection steps 1 2 3 and switch your keyboard into Bluetooth Mode before pairing.

3、设备显示蓝牙键盘断开连接?



1)请先检查蓝牙键盘是否有进入配对状态。然后再打开平板电脑蓝牙

2)检查蓝牙键盘电量是否充足,电量不足也会导致无法连接,请将蓝牙

键盘指示灯在使用途中一直闪烁,表示电池即将没电,请尽快将键盘充电。

蓝牙键盘在一段时间内不使用,设备为了省电将自动关闭蓝牙功能,



IOS/Android		Windows		Wir	
Fn+	对应功能	Fn+Shift+	对应功能	Fn+	
~ 🖒 \ Esc	返回桌面	~ 🖒 \ Esc	主页	~ 🛆 \ Esc	
! Q 1 F1	搜索	! Q 1 F1	搜索	! Q 1 F1	
@ M 2 F2	全选	@ 2 F2	全选	@ F2 2 F2	
# 🛭	复制	# 🛭	复制	# 0	

Fn+	对应功能	Fn+Shift+	对应功能	Fn+	对应功能
~ <u>\( \)</u> \( \) Esc	返回桌面	~ 🖒 ` Esc	主页	~ <u>^</u> \ Esc	Esc
! Q 1 F1	搜索	! Q 1 F1	搜索	! Q 1 F1	F1
@ M 2 F2	全选	@ M 2 F2	全选	@ M 2 F2	F2
# 🖟 3 F3	复制	# 🖟 3 F3	复制	# D 3 F3	F3
\$ 🖺 4 F4	粘贴	\$ 🕹 4 F4	粘贴	\$ 🖫 4 F4	F4
% <u>%</u> 5 F5	剪切	% ¾ 5 F5	剪切	% ¾ 5 F5	F5
^ I <b>≪</b> 6 F6	上一曲	∧ 1 <b>44</b> 6 F6	上一曲	^ I <b>≪</b> 6 F6	F6
& ►II 7 F7	暂停/播放	& ►II 7 F7	暂停/播放	& ►II 7 F7	F7
* ►►1 8 F8	下一曲	* ►►1 8 F8	下一曲	* ►►1 8 F8	F8
( <b>◀</b> 9 F9	静音	( <b>4</b> 9 F9	静音	( <b>◀</b> <b>9</b> F9	F9
) <b>4</b> ) 0 F10	音量减小	) <b>4</b> ) <b>0</b> F10	音量减小	) <b>∢</b> ) 0 F10	F10
— <b>∢</b> ≬ – F11	音量增大	— <b>4</b> 0 – F11	音量增大	— <b>4</b> 0 - F11	F11
+ <u>a</u> = F12	锁屏	+ <u>a</u> = F12	锁屏	+ <u>a</u> = F12	F12



iOS: control+空格键 Windows: Alt+Shift Android: control+空格键 / Shift+空格键

#### 三系统输入法切换:

iOS: control+ 空格键 Windows : control+ Shift Android : control+ Shift

#### 技术规格

键盘尺寸: 295 X 101 X 17 mm (折叠) 使用按键工作电流:<1.5 mA 150 X 101 X 8 mm (打开) 待机电流:<0.5 mA 键盘重量:187 g

休眠电流:<100 μA 工作距离:10 m 休眠时间:10分钟 锂电池容量: 90 mAh 唤醒方式:按键唤醒 工作电压: 3.7 V

充电器规格:5V === 1A或2A

Product Overview

### 状态显示LED

- ◆对码:按fn+①蓝牙键切换通道,蓝牙指示灯亮一下,即进入① 蓝牙模式。 长按fn+ Φ蓝牙键5秒即可进入蓝牙配对模式.
- ◆ 充电:指示灯红色,充满灯灭
- ◆ 低电压指示: 当电压低于3.3V, 红色指示灯闪烁

#### 多通道连接

- ◆连接第1个设备前,先按Fn+ 1 切换通道,再长按Fn+ 1 对码,开始连接. ◆连接第2个设备前,先按Fn+ ② 切换通道,再长按Fn+ ② 对码,开始连接. ◆连接第3个设备前,先按Fn+ 3 切换通道,再长按Fn+ 3 对码,开始连接.
- ◆ 在多个设备同时使用,按Fn+ 1/2/3 切换,即可自由切换到已 连接的设备.

#### 故障分析 请与售后服务人员联系 知识产权信息

未经本司的许可,禁止复制本用户手册的内容。

请不要打开或修理该设备,请不要在潮湿环境内使用设备,请用干 布擦拭该设备。

质保条款 本设备自购买之日起,提供1年保修服务。


#### 键盘保养


- 1、请勿将设备暴露在液体和潮湿的环境中或使其淋雨,请勿在浴缸、水槽、 桑拿房、游泳池或蒸汽房附近使用。
- 2、请勿将设备暴露于过高或过低的温度下。
- 3、请勿长时间放置在阳光直射的地方。
- 4、请勿靠近明火,如烹饪用炉、蜡烛或者壁炉。
- 5、避免使用锋利器物刮擦产品,及时给产品进行充电以保证正常使用。




## Bluetooth Keyboard **User Manual**

Compatible System Win /iOS /Android Note: Please read the





Bluetooth Connection (Take BT1 for example)




indicator lights on, indicates your channel has switched into 0 .


Press fn+ • Bluetooth key for 5 seconds to enter into Bluetooth pairing mode.


Status Display LED

down Fn+ 1 to start the connection.


the device with a dry cloth.







IOS/Android		Windows		Windows	
Fn+	Corresponding function	Fn+Shift+	Corresponding function	Fn+	Corresponding function
~ 🖒 • Esc	Return to Desk	~ 🖒 \ Esc	Home Page	~ <u>^</u> \ Esc	Esc
! Q 1 F1	Search	! Q 1 F1	Search	! Q 1 F1	F1
@ @ 2 F2	Select	@ -9 2 F2	Select	@ M 2 F2	F2
# 🖟 3 F3	Сору	# 🖟 3 F3	Сору	# 🖟 3 F3	F3
\$ 🖺 4 F4	Stick	\$ 🖫 4 F4	Stick	\$ 📮 4 F4	F4
% & 5 F5	Cut	% & 5 F5	Cut	% & 5 F5	F5
^ I <b>44</b> 6 F6	Previous	∧ 1 <b>44</b> 6 F6	Previous	∧ 1 <b>44</b> 6 F6	F6
& ►II 7 F7	Play/Pause	& ►II 7 F7	Play/Pause	& ►II 7 F7	F7
* ►►1 8 F8	Next Track	* ►►1 8 F8	Next Track	* ►►1 8 F8	F8
( <b>◀</b> 9 F9	Mute	( <b>◀</b> <b>9</b> F9	Mute	( <b>4</b> <b>9</b> F9	F9
) <b>4</b> ) <b>0</b> F10	Volume-	) <b>4</b> ) <b>0</b> F10	Volume-	) <b>4</b> ) <b>0</b> F10	F10
— <b>∢</b> 0 – F11	Volume+	— <b>4</b> 8 - F11	Volume+	— <b>4</b> 0 - F11	F11
+ <u>a</u> = F12	lock	+ <u>a</u> = F12	lock	+ <u>a</u> = F12	F12



Three system switching languages

iOS: control+Space key

Lithium battery capacity: 90 mAh

Charger specifications: 5V === 1A or 2A

Working voltage: 3.7 V




Sleep current: < 100 μA

Sleen time: Ten minutes

Awaken way : Press key

• Before connecting the second device, press Fn+ 2 to switch channels, and then hold down Fn+ 2 to start the connection. • Before connecting the third device, press Fn+ 3 to switch channels, and then hold down Fn+ 3 to start the connection. • To use multiple devices at the same time, press Fn + 1 / 2 / 3 to switch to the connected devices freely Troubleshooting Copyright It is forbidden to reproduce any part of this manual without the permission of seller. Safety instructions

Do not open or repair this device, Do not use the device in a damp environment. Clean



The device is provided with one-year limited hardware warranty from the purchase day. Changes or modifications not expressly approved by the party responsible Keyboard Maintenance for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a 1.Please keep the keyboard away from liquid or humid environment, saunas, swimming Class B digital device, pursuant to Part 15 of the FCC Rules. These limits pool, steam room and don't let the keyboard get wet in the rain. are designed to provide reasonable protection against harmful interference 2. Please don't expose the keyboard at too high or too low temperature condition. in a residential installation. This equipment generates uses and can radiate 3.Please don't put keyboard under sun for a long time. radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. 4.Please don't put keyboard close to the flame, such as cooking stoves, However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or 5. Avoid sharp objects scratching products, timely to recharge products to television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna. 1.The tablet PC can't connect the BT keyboard? -- Increase the separation between the equipment and receiver 1) At first check the BT keyboard is into match code state, then open -- Connect the equipment into an outlet on a circuit different from that to the table PC Bluetooth searching. which the receiver is connected.

2) Checking the BT keyboard Battery is enough, the battery low is also lead to can't connect, you need charge.

2. The keyboard indication light always flashing when use? Keyboard indication always flashing when use, is means the keyboard

candles or fireplace.

ensure the normal use.

will be no power ,please charge the power as soon as possible.

3.The table PC display BT keyboard is disconnect? The Bluetooth keyboard is not used for a period of time, the device will automatically

enter the sleep state in order to save power. Press any key on the keyboard to wake up, and the Bluetooth connection will be automatically restored.

