


## 一、应用 Application

### 1.1应用中心首屏 Application Center——Home Screen



1. 在蓝牙链接情况下，点击进入蓝牙电话界面。When connecting to a bluetooth device, click to enter the Bluetooth Phone interface.
2. 在蓝牙或USB连接的情况下，点击进入音乐播放器。When connecting to a bluetooth or USB device, click to enter Music Player interface.
3. 点击进入电台播放界面。Click to enter the Radio Player interface.

### 1.2应用中心--第二屏Application Center -- Second Screen




1. 点击进入空调界面。Click to enter the Air Conditioning interface.
2. 点击进入系统设置。Click to enter the System Settings interface.
3. 蓝牙连接状态下，点击进入拨号键盘界面。When connecting to a bluetooth device, click to enter the Dial interface.
4. 点击进入系统指南。Click to enter the System Guide interface.
5. 在USB设备连接情况下，点击进入图片查看。When connecting to an USB device, click to enter the Image interface.
6. 在USB设备连接的情况下，点击进入视频观看。When connecting to an USB device, click to enter the Video interface.

### 1.3导航栏Navigation Bar



1. 点击返回，返回上一操作界面，当无上一操作时点击不做跳转，只有按钮提示效果。Click the Return button to return to the previous operation interface. If no previous interface is available, it will not jump to other interface and only display button prompt effect.
2. 点击主页按钮（此按钮常亮），返回主页第一屏。Click the Home button (always on) to return to the Home Screen interface.
3. 点击收音机快捷按钮，进入上一次退出时的记忆界面，如果每个点火周期首次进入则由检测页面开始。Click the Radio Player button to enter the last saved interface. In case of first entry in each ignition period, it will start from the Test interface.
4. 点击熄屏按钮，进入屏保界面。Click the Screen OFF button to enter the Screensaver interface.

### 1.4下划通知栏Notification Bar(sliding downward).




1. 滑动进度条调节媒体音量大小。Slide the progress bar to adjust the media volume.
2. 滑动进度条调节蓝牙通话音量大小。Slide the progress bar to adjust the bluetooth phone volume.
3. 点击快速打开或关闭蓝牙。Click to quickly turn on or off bluetooth.
4. 显示当前USB状态。Displays the current USB connection status.
5. 点击按键进入空调界面。Click to enter the Air Conditioning interface.
6. 点击快速打开或关闭WIFI。Click to quickly turn on or off WIFI.
7. 点击按键通知栏快速返回当前页面。Click the notification bar to quickly return to the current page.

### 1.5上划后台应用进程Background Application Process(sliding upward)



1. 向上拖动至顶部删除应用进程。Drag upward to the top to delete the application progress.
2. 点击按钮删掉全部后台应用。Click to delete all background applications.

## 二、空调Air Conditioning



- 1.点击按键可以调节空调风速。Click to adjust the air-conditioning wind speed.
- 2.点击按键可以调节空调温度。Click to adjust the air-conditioning temperature.
- 3.点击按键空调切换吹脚模式。Click to switch to the foot-blowing mode.
- 4.点击按键空调切换吹头模式。Click to switch to the face-blowing mode.
- 5.点击按键空调切换吹头吹脚模式。Click to switch to the face- and foot-blowing mode.
- 6.点击按键空调切换除雾吹脚模式。Click to switch to the defogging and foot-blowing mode.
- 7.点击按键空调切换除雾模式。Click to switch to the defogging mode.
- 8.点击按键快速开空调。Click to quickly switch on or off the air conditioner.
- 9.点击按键空调打开或关闭制冷开始工作。Click to switch on or off the cooling mode.
- 10.点击按键空调打开或关闭内外循环切换。Click to switch between the internal circulation and external circulation.
- 11.点击按键空调打开或关闭除湿模式。Click to switch on or off the dehumidification mode.
- 12.点击按键空调打开或关闭制热模式。Click to switch on or off the heating mode.
- 13.点击按键空调打开或关闭除霜模式。Click to switch on or off the defrosting mode.

## 三、音乐 Music

### 3.1 音乐界面 Music Player Interface



- 1.USB设备连接情况下，点击进入USB播放音乐。When connecting to an USB device, click to play USB music.
- 2.蓝牙状态连接情况下，点击进入蓝牙播放音乐。When connecting to a bluetooth device, click to play bluetooth music.
- 3.播放插入USB时或蓝牙连接时的音乐列表。Play music in USB device or bluetooth connected device.
- 4.当前状态的收藏的音乐列表。Current favorite music list.
- 5.在当前音乐列表中搜索歌曲。Search for songs in the current music list.
- 6.进入音乐播放界面。Enter the Music Player interface.

### 3.2 音乐播放界面 Music Player Interface



1. 点击或拖动进度条可调节播放的进度。Click or drag the progress bar to adjust the playback progress.
2. 点击切换播放模式；包括随机播放、单曲循环、列表循环。Click to switch playback mode: random play, single cycle, and list cycle.
3. 点击播放上一曲。Click to play the previous song.
4. 点击暂停播放或继续播放。Click to pause or resume playing.
5. 点击播放下一曲。Click to play the next song.
6. 点击收藏或取消收藏当前音乐。Click to favorite or unfavorite the current music.

### 3.3 蓝牙音乐播放界面 Bluetooth Music Player Interface



1. 点击播放上一曲。Click to play the previous song.
2. 点击暂停播放或继续播放。Click to pause or resume playing.
3. 点击播放下一曲。Click to play the next song.


## 四、收音机 Radio Player

### 4.1 本地电台播放界面 Local Radio Player Interface



1. 点击切换AM或FM模式。Click to switch to AM or FM mode.
2. 点击搜索寻台。Click to search the radio station.
3. 点击切换到上一个电台。Click to switch to the previous radio station.
4. 点击电台暂停播放或继续播放。Click to pause or resume playing.
5. 点击切换到下一个电台。Click to switch to the next radio station.
6. 点击收藏该电台。Click to favorite the radio station.
7. 点击弹出电台收藏列表界面。Click to pop up the radio station favorite list.
8. 手动滑动电台。Slide to choose the radio station.
9. 收藏列表，长按不放弹出删除收藏电台的弹出框。Favorite list. Press and hold to pop up the dialog box of deleting the favorite radio stations.

## 4.2本地电台删除收藏电台Delete local favorite radio stations



1.收藏列表，长按不放弹出删除收藏电台的弹出框。


Favorite list. Press and hold to pop up the dialog box of deleting the favorite radio stations.

2.点击确认删除当前收藏电台。Click Sure to the current favorite radio stations.

3.点击取消，取消删除当前收藏电台，并返回收音机播放界面。Click to cancel deleting the current favorite radio stations, and return to the Radio Player interface.

## 五、蓝牙电话 Bluetooth Phone

### 5.1蓝牙电话界面Bluetooth Phone Interface



1.点击进入拨号键盘界面。Click to enter the Dial interface.

2.点击进入通话记录界面。Click to enter the Records interface.


3.点击进入查看通讯录界面。Click to enter the Contacts interface.

4.点击数字键盘拨号操作。Click to dial the phone number.

5.点击删除按钮删除数字。Click to delete the entered number.

6.拨号完成点击进行通话。Click to make a call.

### 5.2蓝牙电话通话界面 Bluetooth Phone Call Interface



1.点击接听电话。Click to answer the phone.

2.点击挂断电话。Click to hang up.

3.点击切换车机设备接听或蓝牙设备接听。Click to answer the phone through vehicle-mounted or bluetooth device.

4.点击进入数字键盘拨号界面操作。Click to enter the Dial interface.

5.点击静音或取消静音。Click to mute or unmute.

6.点击挂断电话。Click to hang up.

## 六、图片Image



1.顺时针90°旋转该图片。Rotate the image 90 degrees clockwise.

2.点击切换到上一张可查看的图片。Click to switch to the previous viewable image.

3.点击开始或暂停图片幻灯片播放。Click to start or stop the image slide show.

4.点击切换到下一张可查看的图片。Click to switch to the next viewable image.

5.根据手势放大或缩小图片。Zoom in or out by gesture.

## 七、视频Video



1.全屏播放当前视频。Play the current video in full screen.

2.点击切换到上一个可播放的视频。Click to switch to the previous playable video.

3.点击暂停或播放该视频。Click to pause or play the video.

4.点击切换到下一个可播放的视频。Click to switch to the next playable video.

5.拖动或点击进度条控制播放进度。Drag or click the progress bar to control the playback progress.

## 八、系统设置 System Settings



1.点击进入蓝牙设置；连接蓝牙、设置自动接听和自动连接。Click to enter the bluetooth settings; bluetooth connection, automatic answering and automatic connection.

2.点击进入无线网络设置；连接WIFI。Click to enter the WIFI settings; Connect to WIFI.


3.点击进入声音设置；设置触摸提示音、调节媒体、通话音量、音效、音场的音量。Click to enter the sound settings; Set touch sounds, adjust media, call volume, audio effect, and sound field volume.

4.点击进入通用设置；设置系统语言、屏幕亮度、时间和日期。Click to enter the general settings; Set the system language, screen brightness, time, and date.

5.点击进入还原操作设置；还原系统或车辆设置、以及清除所有内容。Click to enter the restoration settings; Restore system or vehicle settings, and clear all contents.

6.点击进入系统信息设置；查看系统版本信息等。Click to enter the system information settings; View system version information, etc.

### 8.1蓝牙设置界面 Bluetooth Settings Interface



1.点击方框下方滑块即可打开或关闭车机蓝牙。Click the slider below to turn on or off the bluetooth function.

2.点击滑块可以打开或关闭自动接听功能。Click the slider to turn on or off the automatic answering function.

3.点击滑块可以打开或关闭自动连接功能。Click the slider to turn on or off the automatic connection function.

4.显示当前设备的蓝牙名称，点击可以修改该名称。Display the bluetooth name of the current device, click to modify it.

5.刷新按键，点击重新搜索周围可配对连接的蓝牙设备。Refresh; Click to search for surrounding bluetooth devices that can be paired.

6.点击该按键连接当前蓝牙设备。Click to connect to the current bluetooth device.

7.点击该按键即可删除已配对过的蓝牙设备。Click to delete the paired bluetooth device.

### 8.2无线网络设置界面 WIFI Settings Interface



### 8.3 声音设置界面 Sound Settings Interface




1. 点击下方滑块即可打开或关闭触摸提示音。Click the slider below to turn on or off the touch sounds.
2. 点击该按键可以调节该功能对应的音量大小。Click to adjust the volume for the function.
3. 拖动滑块可以调节媒体音量的大小。Drag the slider to adjust the media volume.

1. 点击下方滑块即可打开WIFI功能。Click the slider below to turn on or off the WIFI function.
2. 点击断开按键，可以断开当前网络。Click the disconnect button to disconnect the current network.
3. 刷新列表按键，点击刷新当前搜索到的设备。Refresh list; Click to refresh the currently searched devices.
4. 点击连接按键，可以连接当前网络。Click the connect button to connect to the current network.


4. 拖动滑块可以调节通话音量的大小。Drag the slider to adjust the call volume.
5. 点击按键进入到音效界面。Click to enter the audio effect interface.
6. 点击按键进入到声场界面。Click to enter the sound field interface.
7. 点击按键进入到音效切换模式。Click to enter audio effect switching mode.
8. 点击两边按键或者拖动滑块可以调节低音音效增益。Click the buttons on both sides or drag the slider to adjust the bass audio effect gain.
9. 点击两边按键或者拖动滑块可以调节中音音效增益。Click the buttons on both sides or drag the slider to adjust the middle audio effect gain.
10. 点击两边按键或者拖动滑块可以调节高音音效增益。Click the buttons on both sides or drag the slider to adjust the treble audio effect gain.
11. 点击按键音效设置恢复为出厂设置。Click the button to restore the audio effect settings to the factory settings.
12. 点击按键声场滑块向上移动。Click and drag the sound field slider up.
13. 点击按键声场滑块向左移动。Click and drag the sound field slider left.
14. 点击按键声场滑块向下移动。Click and drag the sound field slider down.
15. 点击按键声场滑块向右移动。Click and drag the sound field slider right.
16. 拖动滑块调节声场位置。Drag the slider to adjust the sound field position.
17. 点击重置按钮，声场调节滑块回到初始位置。Click the Reset button to return the sound field adjustment slider to its initial position.

### 8.4 通用设置界面 General Settings Interface



1. 点击按键进入到语言设置界面。Click to enter the Language Setting interface.
2. 点击该按键亮度模式切换。Click to switch the brightness mode.
3. 拖动滑块可以调节亮度大小。Drag the slider to adjust the brightness level.
4. 点击按键进入到日期与时间设置界面。Click the button to enter the Date and Time setting interface.
5. 点击该按键可以选择车型。Click to select vehicle model.
6. 点击按键选择简体中文模式。Click to select Simplified Chinese.
7. 点击按键选择English模式。Click to select English.
8. 点击按键进入24小时制模式。Click to select 24-hour system.
9. 点击按键进入12小时制模式。Click to select 12-hour system.
10. 点击打开或关闭自动设置时间功能。Click to turn on or off the automatic time setting function.
11. 点击按键弹出时区设置框。Click to pop up the timezone setting box.

## 8.5还原设置界面/系统信息界面 Restore Settings/System Information Interface



1.所有用户数据恢复到默认值。Restore all user data to default values.

2.显示系统的版本信息；其中包括：硬件版本：操作系统的版本；MPU软件版本。Display the system version information, including hardware version, operating system version and MPU software version.

### FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

### FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.