English

Coca-Cola

Caddy Speaker

CC-6PS
Batch: 76257

Operation Manual
Please read this manual before operating this product

M&S Accessory Network declares that radio equipment CC-6PS is in compliance with Directive 2014/53/EU.
The EU Declaration of conformity is available at https://gabbagoods.com/pages/compliance-documents

Introduction

Thank you for purchasing this Coca-Cola Speaker. In order to get the best use of this product, please read this user manual to get yourself familiar with the product's features and functions!

Safety Rules

1 Please follow the rules depicted in this manual closely to ensure your safety. Before using the product, we would strongly encourage you to read through this user manual.

2 Be wary of any edges, uneven surfaces, metal parts, accessories, and its packaging to prevent any possible injury or damage.

3 Do not modify, repair, or dismantle the product. Doing so may result in fire, electric shock, complete breakdown of the product, etc. All of which are not covered under warranty.

4 Do not use any diluent or volatile liquid to clean the product.

5 Do not use the product in a hazardous location.

Packaging Contents

1 × Type-C Charging Cable

1x Coca-Cola® Caddy Bluetooth Speaker

1 × User Manual

Product Diagram

Handle
ON/OFF Button
Volume Up Button
Volume Down Button
Mode/Functions Button

Charge the Speaker

• Connect the Type-C end of the included cable to the charging port on the speaker.
• Plug the USB end into a 5V wall charger (not included) or a computer USB port.
• The red LED turns on while charging.
• When fully charged (approx. 3–4 hours), the red light turns off.
• Charge fully before first use.

Power On

• Long press the Power Button until ⏻ you hear a startup tone.
• The blue LED begins flashing, indicating pairing mode.

Pair with Your Phone

• On your mobile device, enable Bluetooth and open Bluetooth Settings.
• Select "Coke Caddy" from the available devices.
• A confirmation tone will sound, and the blue LED turns solid when paired.

Play Music

• Open any music app on your device.
• Control playback and volume using the speaker buttons.

Controls & Functions

• ⏻ Power Button
• Long Press ⏻: Turn speaker ON / OFF
• Short Press ⏻: Play / Pause music OR Answer/End calls
• ⊕ Button
• Short Press ⊕: Increase volume
• Long Press ⊕: Next track
• ⊖ Button
• Short Press ⊖: Decrease volume
• Long Press ⊖: Previous track
• Ⓜ Button
• Short Press Ⓜ: Switch between Bluetooth Mode and FM Radio Mode
• Long Press Ⓜ: Enter TWS (True Wireless Stereo) Mode

Bluetooth Pairing

• Bluetooth Pairing
• Power on the speaker (blue LED flashing).
• Open Bluetooth settings on your phone or device.
• Select "Coke Caddy."
• Once paired, the blue LED turns solid.
• The speaker will auto-reconnect to the last paired device when turned on (if in range).

Tips:

• If pairing fails, turn Bluetooth off and back on, then retry.
• To pair a new device, "forget" the old connection from your phone, then search again.
• Wireless range is up to 10 meters (33 feet) (environment-dependent).

TWS Mode (True Wireless Stereo)

Pair Two Caddy Speakers For Stereo Sound:

• Power on both speakers.
• On one speaker, long press the M button. The main speaker's blue light will flash, and the sub-speaker's light will turn off.
• Connect your phone via Bluetooth to the main speaker.
• Once paired, both speakers will play together in left/right channel stereo.

FM Radio Mode

• Short press the M Button to switch to FM Radio.

Phone Call Function

• Answer/End Call: Short press the Power Button.
• Built-in Microphone allows hands-free calling.

LED Indicator Guide

• Charging indicator:
• Red Light On = Charging
• Light Off = Fully charged
Charge fully (3–4 hours) before first use.
• Flashing Blue = Pairing mode
• Solid Blue = Bluetooth connected
• Red On = Charging
• Red Off = Fully charged / no charge in progress
• No Light = Speaker off

Technical Specifications

Bluetooth Version: 5.3
Wireless Range: Up to 10m (33ft)
Charging Port: USB Type-C
Charging Time: 3–4 hours
Modes: Bluetooth, FM Radio, TWS
Battery Capacity: 1200 mAh

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference, and (2)This device must accept any interference received, including interference that may cause undesired operation.
WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Compatible with all Bluetooth® enabled devices

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc.

COCA-COLA, COKE, the Contour Bottle Design, the Dynamic Ribbon Device and the Red Disc Icon are trademarks of The Coca-Cola Company and, in Canada, Coca-Cola Ltd. ©The Coca-Cola Company. All rights reserved. Produced by M&S Accessory Network Corp. under a trademark license from The Coca-Cola Company.

Safety & Care

• Use only chargers that do not exceed 5 Volts.
• Keep away from water, fire, and extreme temperatures.
• Do not disassemble or modify the product.
• Clean only with a soft, dry cloth.

Support

If you have problems with your device, please consult the instructions in this manual.

Manufacturer Warranty

We stand by our products! That's why we guarantee them from any functional defects for one year from the original date of purchase. Should you have an issue please call us at (877)995-8505 or email us at info@mnsbrands.com

WARRANTY 1 YEAR

CC-6PS

Manufactured, marketed, and distributed by M&S Accessory Network Corp.,
10 W. 33rd St., New York, NY 10001
Designed in the U.S.A | Made in China.

mnsbrands.com

FCC ID: 2AFXXGG-6PS
Technical Support
Keep All Relevant Information for Future Reference.