

Appendix C. Setup Photographs


<Radiated Emission>

Earphone Mode


Y Plane for SA N7/SA N41/SA N66/DC_66A_n7A/DC_66A_n41A/

DC_2A_n66A/DC_5A_n66A/DC-7A-n66/DC-12A-n66

LF




HF



Adapter Mode

Y Plane for SA N5/DC_7A_n5A

LF



HF

