





Edge 1RB Left-Ant1-PASS




Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-10-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-10-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-15-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-15-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS







NTNV-N77-3450-3550-PC2-30-15-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-15-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-15-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-15-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-15-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS

NTNV-N77-3450-3550-PC2-30-15-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-15-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-15-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-15-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-15-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-20-L-DFT-QPSK-



NTNV-N77-3450-3550-PC2-30-20-L-DFT-QPSK-



Edge 1RB Left-Ant1-PASS




Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-20-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-20-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-20-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-20-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS







NTNV-N77-3450-3550-PC2-30-20-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-20-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-20-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-20-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-20-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS

NTNV-N77-3450-3550-PC2-30-20-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-25-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-25-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-25-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-25-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-25-M-DFT-QPSK-




NTNV-N77-3450-3550-PC2-30-25-M-DFT-QPSK-



Edge 1RB Left-Ant1-PASS




Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-25-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-25-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-25-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-25-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS







NTNV-N77-3450-3550-PC2-30-25-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-25-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-30-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-30-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-30-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS

NTNV-N77-3450-3550-PC2-30-30-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-30-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-30-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-30-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-30-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-30-H-DFT-QPSK-




NTNV-N77-3450-3550-PC2-30-30-H-DFT-QPSK-



Edge 1RB Left-Ant1-PASS




Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-30-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-30-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-40-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-40-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS






NTNV-N77-3450-3550-PC2-30-40-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-40-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-40-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-40-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-40-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS

NTNV-N77-3450-3550-PC2-30-40-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-40-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-40-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-40-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-40-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-50-L-DFT-QPSK-




NTNV-N77-3450-3550-PC2-30-50-L-DFT-QPSK-



Edge 1RB Left-Ant1-PASS




Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-50-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-50-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-50-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-50-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS







NTNV-N77-3450-3550-PC2-30-50-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-50-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-50-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-50-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-50-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS

NTNV-N77-3450-3550-PC2-30-50-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-60-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-60-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-60-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-60-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-60-M-DFT-QPSK-




NTNV-N77-3450-3550-PC2-30-60-M-DFT-QPSK-



Edge 1RB Left-Ant1-PASS




Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-60-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-60-M-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-60-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-60-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS







NTNV-N77-3450-3550-PC2-30-60-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS




NTNV-N77-3450-3550-PC2-30-60-H-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-70-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-70-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS



NTNV-N77-3450-3550-PC2-30-70-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS

NTNV-N77-3450-3550-PC2-30-70-L-DFT-QPSK-
Edge 1RB Left-Ant1-PASS