

ENV-1011

ENVY
REMOTE-CONTROLLED
THRUSTER
P-SPOT VIBRATOR & DUAL STAMINA RING
USER GUIDE

CLEANING, STORAGE & SAFETY


Always clean and dry your device thoroughly before and after use. **DO NOT** store wet. We recommend that you use a mild cleanser that is suitable for use with silicone items. Clean the device with a soft, damp cloth. **DO NOT** clean with an alcohol or chemical-based cleaner. Use water based lubricant as desired. **NOT COMPATIBLE WITH SILICONE LUBRICANT.**

Avoid leaving your device in direct sunlight and never expose it to extreme heat. Keep away from water, and never immerse it.

CARE AND MAINTENANCE
Clean the vibe with a soft, damp cloth. **DO NOT** clean with an alcohol or chemical-based cleaner.

DISPOSAL INFORMATION
Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):

87mm **41.3mm** **124mm** **261mm**



WARNING

For adult use only. For external use only.

Any individual who may be pregnant, has a pacemaker, suffers from diabetes, phlebitis and/or thrombosis, is at an increased risk of developing blood clots, or who has pins/screws/artificial joints or other medical devices implanted in his/her body should consult with a physician before using a massaging device designed for home use.

ENVY shall not be liable for incidental or consequential damages resulting from the misuse of this product.

FCC WARNING STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

HOW TO USE

- **DEVICE POWER ON/OFF**
Press and hold the **Power** button for 2 seconds to turn the device on and enter standby mode, press and hold for 2 seconds to turn off.
- **VIBRATION AND THRUSTING MODES**
Press the **Power** button on the device continually to cycle through the vibration and thrusting modes. Press the **Down** button on the remote continually to cycle through the vibration modes, press the **Up** button on the remote continually to cycle through the thrusting modes. When you turn on the vibration and thrusting mode using the **Power** button on the device, you can also use the **Up** and **Down** buttons on the remote to control these 2 functions. Press and hold the **Power** button for 2 seconds on the remote to stop both functions. There is a total of 10 patterns of vibration mode, there is a total of 5 patterns of thrusting mode.
- **CHARGING THE DEVICE**
Flashing Light (Red LED light): Item is charging. Solid Light (Red LED light): Item is fully charged. Apprx 120mins to fully charge for up to 60mins of use.

SPECIFICATIONS

- **BULLET SIZE:** 143 x 91 x 34mm
- **WEIGHT:** 188g
- **MATERIAL:** Silicone, ABS
- **ITEM BATTERY:** Lithium Battery 800mAh USB 3.0
- **REMOTE BATTERY:** Lithium Battery 110mAh USB 3.0
- **FCC ID:** 2AG2K042023
- **ITEM POWER:** 3.7V/ 800mAh USB 3.0
- **REMOTE POWER:** 3.7V/ 110mAh USB 3.0
- **WATERPROOF:** IPX7 (Item only, remote not waterproof)
- **BATTERY LIFE:** Up to 60 mins use depending on speed and vibration modes and pattern chosen.

STORAGE

- Store at 20 C - 25 C
- Store in a cool dry place.

UK Responsible Person:
ArangaRanga UK LTD, 20-22 Wenlock Road, London, N17 GU, UK.
Phone: +44 2037692960, E-Mail: UKresponsibleperson@arangaranga.com

EU Responsible Person:
ArangaRanga SL, Paseo de la Castellana 194, Madrid, 28046, Spain.
Phone: +34 910054258, E-Mail: EUresponsibleperson@arangaranga.com

XGEN, LLC
Horsham, PA 19044 All Rights Reserved
Email us at www.envymenswear.com for any unanswered questions.