

bodywand™

i.D.

USER GUIDE

HOW TO USE

• DEVICE POWER ON/OFF

Hold and press the  button for 3 seconds to turn your device on or off. The device will vibrate immediately once turned on.

• VIBRATION MODES

There are 10 adjustable vibration modes for both the insertable base and dual tips.

To adjust the insertable base's vibration modes, press the  button on your device to cycle through each mode.

To adjust the dual tip's vibration modes, press the  button on your device to cycle through each mode.

• REMOTE POWER ON/OFF

The remote will be automatically paired with the device. Ensure your main device is turned on before using the remote.

With your main device turned on. Press the  button on the remote to put your device on or off stand by mode.

• VIBRATION MODES

To adjust the insertable base vibration mode, press the  button on your remote to cycle through each mode.

To adjust the dual tip vibration mode, press the  button on your remote to cycle through each mode.

HOW TO USE

• CHARGING THE DEVICE

Plug in your device into the charging port on the underside of the insertable base using the included USB Pin charging cable.

The device will not function while charging, unplug the charger before using the device.

Flashing LED Light: Item is charging
Solid LED Light: Item is fully charged.

It takes approx 100 minutes of charge for up to 60 minutes of use.

• REPLACING THE REMOTE BATTERY

Slide open the back cover on the remote and replace the coin battery accordingly.


Front



BRIDGE

Remote Controlled C-Shaped Vibrator for targeted G-spot and Clitoral Sensations with 10 Vibration Functions.

Create a steady buzz with the independently controlled dual motors or select from 10 different vibration modes. Its remote control makes it easy to choose your desired level while you, or your partner, relax and allows this exquisite toy to hit all the right spots.



 Power Button / Vibration Control

 Dual Tip Vibration Control

Device may be used with or without the remote control.

Ensure the main device is ON before use.

CLEANING, STORAGE & SAFETY

Always clean and dry your device thoroughly before and after use. **DO NOT** store wet. We recommend that you use a mild cleanser that is suitable for use with silicone items.

Clean the device with a soft, damp cloth.

DO NOT clean with an alcohol or chemical-based cleaner.

Use water based lubricant as desired.

Not compatible with silicone lubricant.

Avoid leaving your device in direct sunlight and never expose it to extreme heat. Keep away from water, and never immerse it.

Warning: This product contains a battery that is hazardous and is to be kept away from children. The battery can cause serious injuries if it is swallowed or placed inside any part of the body. Seek medical attention immediately if it is suspected the battery has been swallowed or placed inside any part of the body.



SPECIFICATIONS

BRIDGE

Size: Tamaño: 75mm x 52mm x 90mm

Taille: GröÙe:

Weight: Peso: 113.3g
Poids: Gewicht:

Material: Material: ABS + Silicone
Matériau: ABS + Silicone
Materiale: ABS + Silikon

Battery: Batería: 240mAh
Batterie: Akku:

FCC WARNING STATEMENT

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help
- Device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

SPECIFICATIONS

POWER:

3.7V 240mAh USB2.0

WATERPROOF:

IPX7 (Device Only), for cleaning the device. Not to be used under water.

BATTERY LIFE:

100 minutes for up to 60 minutes of use.

WARNING

For adult use only. For external use only.

Any individual who may be pregnant, has a pacemaker, suffers from diabetes, phlebitis and/or thrombosis, is at an increased risk of developing blood clots, or who has pins/screws/artificial joints or other medical devices implanted in his/her body should consult with a physician before using a massaging device designed for home use.

Bodywand shall not be liable for incidental or consequential damages resulting from the misuse of this product.

DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):



The crossed-out dustbin symbol indicates that these items should not be treated as household waste, but rather brought to the appropriate collection point for recycling electrical and electronic equipment.

XGEN, LLC

Horsham, PA 19044 All Rights Reserved

FCC WARNING STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

UK Responsible Person:

ArangaRanga UK LTD, 20-22 Wenlock Road, London, N17 GU, UK.

Phone: +44 2037692960,

E-Mail: UKresponsibleperson@arangaranga.com

EU Responsible Person:

ArangaRanga SL, Paseo de la Castellana 194, Madrid, 28046, Spain.

Phone: +34 910054258,

E-Mail: EUresponsibleperson@arangaranga.com

Email us at sales@xgenproducts.com for any unanswered questions

Back