




[Note]: This user manual is for reference only, subject to change without notice

◆ Contents

1.	Operation Instructions	2
1.1	Introduction	2
1.2	Application list	3
1.3	Settings	5
1.3.1	Wireless & networks	5
1.3.2	Sound	8
1.3.3	Display.....	10
1.3.4	APPs.....	11
1.3.5	Language & input	12
1.3.6	Backup & Reset.....	13
1.3.7	Date& time.....	14
1.3.8	About tablet.....	15
1.4	Super-HD Player.....	16
1.5	Music.....	16
1.6	Camera	17
1.7	Browser.....	18
2.	USB Driver installation.....	19

1. Operation Instructions

1.1 Introduction



Return



Home



Running Program under background



Voice -



Voice +



Application Menu



USB Connected



Voice input




Time / WIFI signal / External 3G dongle signal / Battery capacity



Google search


1.2 Application list

Click  icon into applications menu:



Note: Long pressing an application icon can add shortcut to the desktop automatically


Click **WIDGETS** icon to view widgets:





Note: Long pressing any widgets; you can create a shortcut on the desktop

1.3 Settings

✧ 1.3.1 Wireless & networks


Click  icon, then select wireless & network:






✧ **Wi-Fi settings**

Turn on Wi-Fi, tablet can search for nearby Wi-Fi networks automatically and display related information. Choose WIFI router.


If it displays locked as , you need type password before connection:




1.3.1 Sound

✧ Sound settings

Click  **Sound** to set volume



Click **Volumes** icon to adjust the volume



LCD Brightness setting

Set wallpaper

Set sleep interval

Set screen protect

Adjust font size

Calibrate

Select an accelerometer
coordinate system

Adjust screen adaption

1.3.2 Display



Via WIFI and HDMI Dongle, connect to TV

Set WIFI display in full screen model

*Smart color
(It Is better for playing games and video and picture)*


*Demo mode
(Only half of the screen is an effective,easy to see the effect of it)*

Intelligent backlight

*Demo mode
(Only half of the screen is an effective,easy to see the effect of it)*


intelligent backlight



Demo mode
Only half of the screen is an effective, easy to see the effect of it



1.3.3 Apps

✧ Manage applications

Click  into application settings interface. You can see all application details and uninstall programs completely.






1.3.4 Language & input



✧ Select language

Click  **Language & input** to set native language.



1.3.5 Backup & Reset


Click  **Backup & reset** →  **Factory data reset**
Erases all data on tablet →  **Reset tablet** icon to reset tablet:



Note: All applications are installed by user will be disappeared.

1.3.6 Date & time

Click **Date & time** to set date and time:



Automatic date & time
Use network-provided time

Obtain the time automatically

Automatic time zone
Use network-provided time zone

Obtain the time zone automatically

Set date 5/9/2012 **Set time** 06:24

Set current date/time

Select time zone
GMT+00:00, GMT+00:00

Select time zone for your location

Use 24-hour format
13:00


Set 24-hour format

Choose date format
12/31/2013


Select data format

1.3.7 About tablet


You can check the Tablet detail information:




1.4 Super-HD Player



Click icon to browse picture and video:




Note: It needs some time to load all files at first time. Press one file 2S for more advanced operation.

If you want to browse the file from TF card, please make sure **Storage** → **Enable media scanning on extsd** choose .


1.5 Music




Click icon to play music:



1.6 Cameras



Click icon into camera interface:



Take photo



Click this icon you would find



Small window



Click this icon you would find



Exposure



Camera setting



Different mode




Switch camera/video recorder

1.7 Browser




Click icon to browse web page:



Make sure the internet is connected.

2. USB Driver installation

- 1) Please download driver file from the website of wholesale or Dealer.
- 2) Power on device., then connect device with computer by USB cable, and then follow the instruction to install the driver.
- 3) After installation successfully, you can check the android phone on the laptop ("My Computer"→" Property"→" Hardware"→" Device Manager").



- English:

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

- French:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help.**

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.