



Manji Times

Model No.: AS511

Introduction	1
Accessories list	1
General function	2
Charging your device	3
Pairing to a computer and Entertainment	4
Pairing to Mobile phone or other device	4
Warning	5
Technical specification	5
FAQ	5
Safety Rules	6

Repeatedly charging and discharging of the headset, over time will cause the battery performance to diminish. This is normal for all rechargeable batteries.

Pairing to a computer and Entertainment

1. If there is no Bluetooth function supported by your computer, a Bluetooth adaptor is necessary. Fix the adapter with your computer and ensure its Bluetooth function is activated.

2. Turn on the device and go to the pairing mode.

3. After a few seconds, the device name will be listed AS511. Select the device name icon and click right button of mouse to select pairing item, then select to connect with audio device.

5. Open you media player to play music, watch TV/movie and play game, then you can hear all the sound or music from the device.

Pairing to Mobile Phone or other device

Pairing means unique and encrypted wireless connection between two Bluetooth devices when they agree to communicate with each other.

In pairing mode, two devices should be placed close enough to each other.

Pairing to a phone and Entertainment:

1. Activate the Bluetooth feature on your phone and search for the Bluetooth

Headset AS511

2. Turn on your device go to the pairing mode.

3. Select the AS511 from the list of devices found by your phone.

4. If requested enter the Bluetooth PIN 0000 to pair and connect the

Introduction

Congratulations, and thank you for choosing the Bluetooth Stereo HEADPHONE. This manual will help you operate the Sport Bluetooth Stereo headphone, but you should first familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Sport Bluetooth Stereo headphone Safety Rules.

1. Please follow the rules depicted in this manual closely to ensure your safety. Before using this Sport Bluetooth Stereo Earphone, we would strongly encourage you to read through this user manual.

2. Be more wary of any edges, uneven surfaces, metal parts, accessories and its packaging so as to prevent any possible injury or damage.

3. Do not modify, repair or dismantle this Bluetooth Stereo headphone. Doing so may result of fires, electric shocks, complete breakdown of this port Bluetooth Stereo headphone, etc. All of which, are not covered under warranty.

4. Do not use any diluents or volatile liquid to clean the Sport Bluetooth Stereo headphone.

5. Do not use the Sport Bluetooth Stereo headphone in a hazardous location.

Accessories list

1 x Bluetooth Stereo headphone

headset to your phone.

5. Your phone will confirm the pairing, and then press Yes/OK.

6. Select to connect with device from your phone. You can play music, watch TV/movie and play game with your phone, then you can hear all the sound or music from the device. Also you can control the player by operating the device. Example, volume level and next music.

Warning

You Must select a qualified charger DC 5V/1A. from a reputed brand/manufacturer.

You Must charge the bluetooth headphone if it has been not used for more than 2 months.

Technical specification

Bluetooth Specification:2.1+EDR

Bluetooth Profile:HFP1.6, HSP1.2, AVRCP1.4.

RF Range: 10meter

Stand-by time: about 7 days

Charging time: About 2 hours

Safety Rules

1) Never disassemble or modify your headset for any reason.

Doing this may cause the headset to malfunction,

. These damage to your device can void your manufacturer's warranty.



General function

Power On: Press the "  " button for 3 seconds when the device is off, (blue LED slowly flashes and a "power on" voice beep).

Enter the pairing mode: In power off mode, press the "  " button to power on the device and then sequentially hold on for 5 seconds.(blue LED and red LED quickly flash alternately with "pairing" voice).

Pairing: Use a Bluetooth function mobile phone or other Bluetooth Master device and to perform pairing action (detail refer to the chapter about pairing).

Play/pause: Press "  " to play when the device is pausing and press "  " to pause when the device is playing.

Volume up: Press "  " is for volume up.

Volume down: Press "  " is for volume down.

Playback/Previous: Press "  " 1 second is for previous music, press

"  " 1second is for the next music.

Power off: Press the "  " button for 3 seconds when the device is off (a "power off" voice beep and all LED is off).

Low battery warning: (a "battery low" voice beep and the red LED flash)

Charging: Charging via USB charging cable connected to a computer USB port (red LED is on).

Answer call: Press the "  " button once while the call is coming.

End call: Press the "  " button once to end call.

Transfer call voice: Press the "  "button to reject call when the call is ringing.

Replay the phone: In stand-by mode or playing music, double press

the "  "button.

Charging your device

1. Connect the charging cable to the charging socket of the headset.

2. During charge, the indicator light will turn red.

3. When the headset is fully charged, the red indicator light changes to blue.

Unplug the charger from the headset.

Use only approved chargers, Unauthorized chargers could cause damage to the headset, it could also invalidate any warranty on the product.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.