

Bluetooth Watch Instructions

Model:2S

Thank you for choosing our BT Watch devices. You can read the manual, a comprehensive understanding of the use of equipment, in fact, with a taste of the function and simple method of operation.

This device is used as long as the brand of intelligent machines are adapted to use intelligent machines can synchronize phonebook and provides a variety of useful features and services to facilitate your work and leisure activities in the smart machine operation.

The Company reserves the right to make any prior notice in the case of the contents of this manual for the right to amend, without notice.

First, open the Bluetooth feature on your smartphone, search BT watch Equipment "U WATCH 2" and connect, BT watch will prompt " ** (Connected) " while there will be a standby interface "  " icon indicates a successful connection has been your smartphone, connect after the success you can follow the instructions below BT watch operations:

Key Description: There are four buttons on the left upper and lower volume keys, page up and down keys, top right of the Enter key, the answer key, bottom right of the switch button, back button, hold button.

Uwatch second generation



Standby screen displays: Time, day and date as the right

the main menu: Standby screen, press the Enter key to enter the main menu interface. Main menu interface: In this interface adjustment. Page up and down keys to select a different function, and then press the ENTER button to enter.


Main Menu Features:



1、**Bluetooth** : Turn on Bluetooth after the following two menus, such as



the right



(1) Bluetooth settings: 1) Press the Enter key can be turned on or off Bluetooth, BT watch Bluetooth turned off by default, Bluetooth is turned on if the status bar of the main menu screen will display a small icon "X";

2) The machine can be searched can be turned on or off, default is on.

3) The local device name display: U WATCH 2.



(2) Bluetooth sync: 1) You can search for Bluetooth devices;

2) Display can be connected Bluetooth device name, press the Enter key can connect / disconnect, remove, and help functions.



2、Phonebook: If there is no sync phone book, press the Enter key



displays "not connected", such as the right , Now press the Enter key for




phonebook access, prompt "Loading", such as the right , Loaded successfully, you can view the phone book down keys. Successful synchronization phonebook, press the Enter key to enter the contact list screen: Tap the contact can be a phone call functionality.



3. Remote Notification: Enter the remote notification feature, you can see the latest mobile phone synchronization information, this feature only shows the latest news. It is suitable for smartphone of Andior OS only, Please interview the ftp://211.144.196.251 (user: 123456 password: 123456) and download the " BTNotification.apk " AndroidPackage at the "Uwatch 2" document, and then install it in your smart phone(Notice: you have to install the Btnotification and open it before use the watch)



4. Bluetooth music : If a Bluetooth connection with another phone,



press the Enter key to enter the interface. In this interface, the OK button to play or pause music, volume key up or down when the music player can switch songs; To adjust



the volume, you can press the Back key to return to the idle screen , Then press the volume key up or down to adjust the other smart phones connected thereto adjusting the volume also can increase or decrease the volume of BT PHONE play music, and



vice versa if not even prompt box will pop up on the "not connected."


NOTE: To ensure consistency with other phones Media Audio connection in order to play music!



5. Information : If the remote device supports the MAP protocol (such as Samsung GLAXY 2, millet, 2, etc.), press the Enter key to enter, you can see the Inbox and Sent two menu two menu message list; if the remote phone does not support MAP protocol (go to the Inbox and Sent messages prompt "remote device does not support MAP"), the remote device is installed "Bluetooth notice" APK, remote notification view the latest messages.



6. Call records : Press the Enter key to see: missed calls, dialed calls,



received calls, and all calls, such as the right



7. Toolbox : Open the Toolbox has the following menus, such as the




right



(1) Language Settings: Enter this interface , Support Chinese and English native default is Chinese, press the Enter key to select to select the appropriate language. Press the Return key to exit this function:

(2) Time setting: There are two ways to set the time




1) Press the Enter key to enter this interface , Switch button to jump to different locations numeric setting, each location can press the volume keys up or down to adjust the specific numbers, setting completed, press the Enter key to save the settings.
2) Installed on the smart machine "Bluetooth notification" APK, when connected to the phone dialer, the dialer client will prompt "with the remote device's date and time synchronization?", Then press the Enter key can be time synchronized to the phone dialer side , so there is no need to manually adjust the time.

(3) Date Set: There are two ways to set the date



1) Press the Enter key to enter this interface , Press the switch button to jump to different locations numeric setting, each location can press the volume keys up or down to adjust the specific numbers, setting completed, press the Enter button to save the settings;
2) Installed on the smart machine "Bluetooth notification" APK, when connected to the phone dialer, the dialer client will prompt "with the remote device's date and time synchronization?", Then press the Enter key can be synchronized to the phone dialer end date , so no need to manually adjust the date.


(4) Ringtone: enter ringtones function, vibration and ringtone 1-4 to select, simply choose the ringtone press the Enter key after the prompt above the "Saved" is set successfully.



(5) Stopwatch  : Press OK to start timing or pause, press the return key to exit this function.




(6) Alarm: Press the Enter key to enter the alarm interface, Alarm clock can be set to 5, press the volume up and down keys to select an option, press the Enter key




to enter this list


1)、Alarm status: Press the Enter key to enter the selection and preservation of the interface, the default is off, press the Enter key you can choose to open or close, as the right



, Setup is complete press the Enter key to save the settings, such as the



right




2)、Set the time : Press the switch button to jump to different locations numeric setting, each location can press the volume keys up or down to adjust the specific numbers, setup is complete press OK to save the settings.

3) Ring type: Press the Enter key to enter the selection and save screen, press the up and down volume keys can be set once or daily (the default one) or a customized setup is complete press the OK button to save the settings.

4) Alarm tone: Press the Enter key to enter the alarm tone screen, press the up and down volume keys can be set to select the alarm tone, setup is complete press the Enter key to save the settings

Note: Set the alarm is complete, set the alarm if opened, the list box will interface to select the tick,



as shown , The status bar will be the standby interface Alarm "☒," small icons; alarm sound, press the Enter key to stop the alarm.

(7) About Bluetooth Watch: Enter this function to display BT watch version information.

(8) Automatic Test: Enter this function, Bluetooth watch will be an automatic test features, including: backlit test, LCD test, test button, earpiece, speaker and microphone test, the test is completed, this will disappear.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference
that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance
could void the user's authority to operate the equipment.