


Getting Started

What's in the box



Wheel scroll & button

- Click the wheel to switch between pen and eraser functions.
- Use the scroll to modify the ink /eraser thickness or to page up & down.

Home button

- Click the home button to switch between ink, cursor or windows menu functions.



Pen tip

- Specially designed pen tip diffuses light reflection and maximizes touch experience.

LED Indicator

- Check the battery status in the LED indicator.



Sliding button

- Pen color selection
4 color (Red, Blue, White, Black)

Charger hole



- Insert it into the charging port in EZ holder or EZ Button.
- Full charging time : MAX 2.5 hours
- Continuous uptime : More than 10 hours
- Continuous standby time : More than 6 days



2.5H

Discharge protection cap

Remove discharge protection cap before the first use.




How to recharge

Insert the bottom part of the pen into the charging port to recharge. EZ button's LED will turn on when charging starts.
In order to recharge insert the pen into the charging port with the charging hole facing downwards. The LED in the EZ Button turns on when charging starts.

Green : Full battery
Red : Low battery
Blue : Power On


Battery check

- Check the remaining battery by pressing the Home button and the Wheel simultaneously.
- Blue : More than 50%
- Magenta : More than 20%
- Red : Below 20%



Replacing the pen tip


Replace the pen tip in case it is worn out.



System Environment

EZ Pen can be used in the following settings.

- IFTD S/G/M/B series
- WINDOWS 7 or newer
- D3 Board



Driver Installation


EZ Pen require a driver installation. Download the drivers at the link below.

www.edgeind.com/download

EZ Learning


Visit the link below for more information.

www.edgeind.com/ez_learning




Product Features


- RF - 2.4GHz ISM Band (2.405 ~ 2.470)
- Easy to change 4 colors - sliding color buttons
- Wheel up/down & Wheel button
- Battery indication LED - 3level(Blue, Magenta, Red)
- Battery - Li-ion 3.7V 100mAh
- Dimensions (H x Ø mm) 178 x 22



EZ CONNECT™
TECHNOLOGY

Pen





FCC Information to User

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution

Modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Compliance Information : This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

