
Patented Product Counterfeiting not allowed Smart 5V Special Glasses



- and video in daily life and traveling by our easy-taking Spardar Smart Glasses. Drop your heavy camera away from now on.
- 2. Doze reminder by voice and vibration- nice voice or vibration will remind you no driving after drinking and while tired.
- 3. Bluetooth- free our hands by Spardar Smart Glasses bluetooth, easily answer your urgent calls and GPS and avoid dange rous conduct during driving, company with the traffic laws.
- 4. Flashlight-lighting technology used on the glasses. Easily get lighting by a convenient touching on our smart glasses for the emerg -ency, keep the darkness away without the heavy torch.

Part Name



Function Instructions

Long press on the front volume button, the volume increase, Long press the volume back-end key, volume decreased; According to the back-end. choose back Asong. Long press after the Bluetooth on when the red and blue lamp flashing alternately mobile phone connecting Bluetooth sear -ching and pairing successful, flashing stop and the device is in standby node when the blue lamp inte (I) power on and off flashlight press anytime for phototaking. one press for one photo. Blue light flash once. press the button, blue lamp start flash inter -mittently, video camera start working, blue lamp flashing stop, camera stop working, indicator lamp headset hook Emergency light switch Bluetooth headset plug Listen to the music on bluetooth mode Phone call on bluetooth mode (GPS) mobile synchro GPS plug(charging vibrator switch and data tran emitting, USB cable connecting Network camera;

Method of use

Left-side function (camera and reminder)

press anytime for photo taking, one press for one photo. Photo Taking Blue lamp flash once.

press the button, blue lamp start flash intermittently, video camera Camera start working, blue lamp flashing stop, camera stop working.

U disk, Inserted

Doze reminder

press the button, turn on the Doze reminder mode. When the driver naturally lower his head, the reminder will remind the driver by voice or vibration. If you don't want the remind, just press again to turn off the mode.

PC Camera Connect the glasses and computer by plugging in the USB cable on left plug, the camera can be used as a webcam.

Memory card Connect the glasses and computer by plugging in the USB cable on left plug, the camera can be used as memory card or USB stick with the TF card

Right-side function (bluetooth and lighting)



This product support apple mobile phones and android system. Bluetooth pairing: Long press after the Bluetooth on, when the red and blue lamp flashing alternately, mobile phone connecting. Bluetooth searching and pairing successful, flashing stop and the device is in standby mode when the blue lamp intermittent flashing, (please make sure that the pairing and glasses phone calls within 10 meters Range, and there is no obstacles blocking, in Phone After the bluetcoth successfully pairing with your mobile, and then connect to the headphones. When the calls coming across the part of the headphones when the calls coming across the part of the part of

the headphones. When the calls coming, earing or vibrationwill remind you.

(Bluetooth) press the bluetooth key to answer, press it again to end the call. Music

After the bluetooth successfully pairing with your mobile, then connect the headast, The glasses will be directly connected to the mobile music, when



(Bluetooth) there is a coming call, press the bluetooth button to pick up the phone and the music will continue when the call stop. After the bluetooth successfully pairing with your mobile, then connect the headset. The glasses will be directly connected to the mobile Navigation (Bluetooth) navigation instructions start with the glasses, no need to look at the navigation screen to avoid the traffic accident.

lighting Put forward the switch to turn on the emergency light open, and put (Emergency) back to turn off.

Camera Instructions

Left-side Indicator

(camera and remind)

Photo shoots, blue lamp flashing only once, one photo one flash.

Camera, the blue lamp intermittently flashing, lasting around 2 seconds per time, stop when the videoing stop.

When switched on, the red lamp and blue lamp flash at the same time, and

When Standby, Blue lamp on all the time

When Shutdown, the red lamp and blue lamp flash at the same time, and then the lamp off When ${\bf charging}$, the red lamp flash all the time during charging, device is standby.blue lamp flash when full charged, and the device turned on. The camera is workable while charge

Charging
1> Connect to a computer with USB cable for charging
2> Charging indication
4a> charging: Long red lights on and blue lamp off
4b> charged: red lamp off, blue lamp on
4c> low batter: red lamp and blue lamp flash same time for five times, device will be turned

of submarcary

<d>no card: red lamp flash 8 times, device will be turned off automaticall


<e>can use the OTG smart phone to charge the glasses, synchro with the OTG card read

USB Mode

1> when the device standby or shutdown, connect to the computer with USB cable, the device will be on USB mode and can be used as a flash card. 2> while connected with USB, press the power botton, can use the computer cemera.

3> Support the OTG smart phones to read the image and video data in the glass

-es synchro with the OTG card reader / some chops pls download the player



Videma and Charging Mode

he charger or plug with USB cable, you can charging and videoing at the

a Reoing and Charging Mode, all the function works normally and the lamb is

3> pls sav - Idrideo data before you get off the Videoing and Charging Mode.

Blustooth Instructions

Right- 1e Function

(bluetooth an inting)

(*) When switch - n, the -/

mp and blue lamp flash at the same time, and fwhe device into standby mode.

When Standby, the sturr ap inte-When Shutdown, the rice tric land .

"lethly flashing, lasting around 2 seconds/time op flash at the same time, and then the lamp off

When charging, the re-

rose time during charging, device is standby, blue turned on. The device is workable while charg

Charging: Long red lights on -------- flashing slowly when the charging finished.

Calling: blue lamp flash quickly whe.... call incoming, and flash slowly again after you hang

Callback: press the bluetooth button twice while connected.

Take and Reject Call: press the bluetooth once for answering and long press more than

Cancel Call: shortly press the bluetooth button

Hang off: press the bluetooth button while calling to hang off.

Pairing: while shutdown mode, long press bluetooth more than 4.5 seconds to enter the paring mode

If the earphone never paired with other device, then pairing directly,

the earphone never paired with other device, then pairing directly,

Playing Music: shortly press bluetooth for pause, shortly press play button for stopping Press the front of the volume button, shortly press for next song, long press for volume up. Press the back of the volume button, shortly press for previous song, long press for volume

Clear the Paring: Press the front and back side of the volume button at the same time

Mute: Clear the Paring: Press the front and back side of the volume button at the

Safe use items



This product is completely separated from the left and right sides, you need to power on/off and charging separately.

2. This product is the standard 5 v, cannot use any charger above 5 v to avoid the damage of the machine.

3. For the first charging, pls make sure that both side betteries have been charged. Normally need about 2 hours for full charging. Be careful not to charge in high temperature or humid place.

warning

4. Doze reminder, it will only work when the compulsive switch on. Please check the right position or pose when you use the glasses as a reminder. Dozing down will make the glasses lose the balance and cause the alectricity connecting and voice on for reminding. While the first time use the reminder, pls trito check the position and balance in order to achieve the best effect.

5. When you don't use the glasses, pls make sure the both side powered off and put the glasses into the cloth bag. And put it in the dr and in dry and no dust condition. Don't expose in liquid or high maist condition. Also put awy from high temperature and fire to avoid explosion and extramely cold.

6. Please do not use abrasive solvent to clean glasses, and don't use sharp objects to scratch glasses to avoid the damage

7. In the hot summer after sweating, please clean the glasses with the special cloth, as the sweat contain salt, may damage the glasses. And don't expose the glasses in the ver high temperature long time to avoid the explosion

8. Please do not open the glasses by yourselves, as the device contains some components that you may can't repair, and will cause the damage easily.

9. Please don't listen to music while driving with bluetooth, avoid the accidence

10. Please do not let children to play the glasses, to avoid the children get burt by the small parts.

11. While taking photo or video, the device will automatically delete the oldest files when the card gets not enough space. please download and save our video and image files to you computer in time

12. Pls use the specialized charging cable, charger, earphone and all other accessories. The inspecialized accessories ma damege the device Pis use the product safely!

Guarantee of quality

Type no. One year Order no. warranty Client phone Purchase date ignature Seller Stamp

1. This product is under the normal use of the free maintenance for one year since the

2. More than the warranty period will charge for replacement of spare parts, maintenance

3. During the warranty period, the below situations are not free repair

A. failed to present the warranty card or purchase document (invoice or receipt)

B. for disassembling or damage of transformation;

C. because of the wrong use improper use or man-made damage;

D. in abnormal use environmental damages to the bad place;

E. look old scratch etc.

The pictures in this instruction brochure are for referrence only,

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter