

User Guide




Sovereign USB Memory Stick Player

KA-SBT010

Included in the Box

- Mains adapter compatible with Sovereign and Sonic players only.
 - SOVEREIGN player with rechargeable battery fitted
 - User Guide

Sovereign Button Layout:



Buttons Explained:

1 Play/Pause

Press button during play to pause audio, and again to resume.

2 Track Back / Rewind

Click to skip back a track or hold down to rewind

3 Track Forward / Fast Forward

Click to skip forward a track or hold down to fast forward

4 Reset / Skip Book

Click to skip to the next book/folder or hold down to reset to the beginning of track 1, folder 1

5. USB port

Insert the USB stick into the port – it will only fit one way.

6 On/Off and Volume Dial

Rotate clockwise to switch player on. You will hear a click and musical tone. Continue turning clockwise to increase volume.

7 Headphone Socket

Please use headphones with a mini jack connector

8. Power Socket

Only use the AC charger supplied with the Sovereign

Playing Memory Sticks

To play a memory stick simply insert it into the slot on the top of the player (number 5) and switch on. The Sovereign will find the audio and start playing automatically. You can then use the buttons as described above to navigate the audio content.

Bookmarking

Bookmarking is automatic and will remember the last played position for

multiple memory sticks. Simply turn the unit off or remove the stick and the position will be marked and remembered.

Connecting with Bluetooth:

Connecting to the Sovereign player via Bluetooth does not require any buttons pressed on the Sovereign. Simply search and select for the Sovereign on your bluetooth device (Phone, Tablet etc) and select connect.. you will hear a tone through the player when the connection has been made. Bluetooth is not useable when a USB stick is inserted.

For more details see:

<http://www.kingsaudio.co.uk/prod/53319/sovereign-usb-memory-stick-player>

Charging & Changing the Battery

We recommend your first charge lasts 6-8 hours and thereafter charge for 1-2 hours as required. Do not charge overnight, and **only use the charger supplied with the player**.

If you intend to use the Sovereign on mains power only, we recommend removing the battery.

The battery should easily click out once the cover has been removed. Then line up the new battery with the gold contacts and replace the cover.

Using Headphones

The headphone socket is located on the front of the player to the left of the On-Off/Volume dial (in the 7 O'clock position). It is designed for use with headphones connected by a mini jack.

Large format Guide and Video Instructions

Please contact us for a downloadable large print guide or details of our video guide.

The Sovereign Player is Designed and Manufactured by Kings Audio

www.kingsaudio.co.uk 01935 411322 enquiries@kingsaudio.co.uk

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.