




Check the Accessories



BKK masturbation cup



Cable Charger




Manual



Lubricants







Instruction of Buttons



- 1. Constant power light stands for normal status.
- 2. The power light flashes on the condition of low battery.
- 3. The power light flashes while the cup is being charged.
- 4. Constant power light on indicates the charging is complete.

- 1. Disconnection results in light off.
- 2. Light on while it is connected.
- 1. Press the power button for 2 seconds to turn it on or off.
- 2. BKK turns to sleep mode if it hasn't been operated for 5 minutes constantly.
- 3. BKK will shut down automatically once it hasn't been operated for 10 minutes constantly.

Step 01 → Step 02 → Step 03 → Step 04 → Step 05



Download the application onto the smartphone, please visit www.bkksexttoy.com for more information.

Press the power button for 3 seconds to turn on the cup.

Run the application in smartphone, connect cup with bluetooth.

Add appropriate lubricants into the silicon.

Control device manually, interact with the app through the button and shaking device.





Operation Instructions



Maintenance

Step 01 → Step 02 → Step 03 → Step 04 → Step 05



Remove the silica gel from the cup.

Rinse the silicone surface with water.

Turn the silica gel inside out, rinse the surface with water.

Wipe the silicone, and lay it in a cool place until it is dry.

Put the silica gel back in the cup.



Handing Information

1. Please do not charge the masturbation cup next to the sink or under any humid environment.
2. Watch out for the food or dirty liquid dropping into the cup.
3. Please rinse the masturbation cup after every entertaining, and keep it clean, wipe it with soft cloth and lay it in a cool and well-ventilated place till it dries naturally.
4. Please do not use hair-dryer, microwave or other heating devices to dry the masturbation cup.



Warranty and Costumer Support

One year Standard factory warranty from date of purchase. Factory warranty does not include the following:

1. Unable to provide official warranty card or receipt, or if device has been modified at an unauthorized store.
2. Damages caused by improper caring such as improper handing, Wrong operation, liquid inlet, artificial rupture, bump scratch, handling objects fall into.
3. Natural wear and tear, IE: damage of the outer appearance and charging plug by over use.

4. Damages devices that are modified outside of an authorized BKK service location.
5. Hardware and Software that is not marked by the original factory markings.
6. Distributors will be solely responsible for any free gifts or promotions offered.
7. Any damages caused by any natural disasters.



Copyrights and Trademark

copyright @ BKK all right reserved. All the Intellectual property

rights in the product belong to Shenzhen huachuang zhenxin science development co.ltd. Golden Convention Limited is authorised to apply the BKK trademark by Shenzhen Huachuang Zhenxin Science development co.ltd.



Supplementary Instruction

Due to the continuous renewal of product function, your user manual in hand may differ from the actual operation. Please download the updated manual from the official website. Please visit the official website for any details and support. www.bkksexttoy.com



WWW.BKKSEXTOY.COM

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.