

Instruction Manual

8094731




HEADRUSH™

TRUE WIRELESS EARBUDS

HRB 3038

INTRODUCTION

Thank you for purchasing the HRB 3038 true wireless earbuds. In order to maximize your listening experience please read the following instructions.



OPERATING INSTRUCTIONS
Prior to first use, remove the plastic battery isolator tab located between the earbuds and the charging case.

| TO | DO THIS |
|-------------------------|---|
| Power ON | Remove the earbuds from the charging case. |
| Power OFF | Place earbuds back in the charging case or press and hold both MFB buttons for 5 seconds. |
| Play/Pause | Double press either MFB button. |
| Next song | Press and hold the right MFB button for 1 second. |
| Previous song | Press and hold the left MFB button for 1 second. |
| Answer a call | Press either MFB button twice. |
| End a call | Press either MFB button twice. |
| Reject an incoming call | Press and hold either MFB button for 2 seconds. |

NOTE: The function compatibility may vary among different smartphones or devices. Not all functions are available on all devices.

CHARGING THE CASE

Use the included charging cable to fully charge the case before first use. It will take approximately 2.5 hours to fully charge.

TO USE ONLY THE LEFT OR RIGHT EARBUD

If both earbuds are turned ON and paired to your Bluetooth® device, you can return the right or left earbud to the charging case and the earbud (R or L) in your ear will continue to play. To use the right or left earbud only, remove it from the charging case. It will turn ON and connect automatically to your Bluetooth® device.

WHAT'S INCLUDED

• HRB 3038 earbuds

• Charging case

• Small, medium and large earbud tips

• USB-C charging cable

• Instruction manual

1 LED flashing, the power level is less than 25%

1 LED ON and 1 LED flashing, the power level is less than 50%

2 LEDs ON and 1 LED flashing, the power level is less than 75%

"3" charge to "4" LEDs ON, the battery is fully charged

CHARGING THE EARBUDS

Place both earbuds in the charging case, they will automatically begin charging and the red LED on the earbuds will turn ON. When the earbuds have fully charged, the LED will turn OFF. It will take approximately 1.5 hours to fully charge the earbuds. The charging case provides up to "3" charge to "2.5".

PAIRING

The earbuds will automatically enter Bluetooth® pairing mode when used for the first time. The left and right earbuds will automatically connect to each other.

1. Remove both earbuds from the charging case. The red and blue LEDs will flash to indicate the earbuds have powered ON.

2. Select "HRB 3038" on the Bluetooth® device list to pair the earbuds automatically.

3. When the earbuds have successfully paired the red LEDs will flash on both sides after 5 seconds.

OPERATION

• While playing music, double press either MFB button to pause, press again to resume

• Press and hold the right MFB for 1 second for the next song, press and hold the left MFB for the previous song

• The music will pause and the earbuds will ring when there is an incoming call. double Press either MFB button once to answer the call, press and hold for 2 seconds to reject the call. Press again to end a call

4. After initial pairing, the earbuds will automatically turn ON and connect to your device when removed from the charging case, provided both earbuds and your Bluetooth® are ON and within range.

5. If the earbuds are not connected to a Bluetooth® device, they will turn OFF after 5 minutes.

CHARGING CASE

Fully charged:

Provides up to "5" charge to "2.5"

Rated input:

DC 5V, 500mA

Output:

DC 5V, 50mA

Battery capacity:

40mAh

IP rating:

X4 (add: earbuds)

CHARGING CASE

Fully charged:

Provides up to "5" charge to "2.5"

Rated input:

DC 5V, 500mA

Output:

DC 5V, 50mA

Battery capacity:

40mAh

IP rating:

X4 (add: earbuds)

OPERATING INSTRUCTIONS

Prior to first use, remove the plastic battery isolator tab located between the earbuds and the charging case.

CHARGING THE EARBUDS

Place both earbuds in the charging case, they will automatically begin charging and the red LED on the earbuds will turn ON. When the earbuds have fully charged, the LED will turn OFF. It will take approximately 1.5 hours to fully charge the earbuds. The charging case provides up to "3" charge to "2.5".

PAIRING

The earbuds will automatically enter Bluetooth® pairing mode when used for the first time. The left and right earbuds will automatically connect to each other.

1. Remove both earbuds from the charging case. The red and blue LEDs will flash to indicate the earbuds have powered ON.

2. Select "HRB 3038" on the Bluetooth® device list to pair the earbuds automatically.

3. When the earbuds have successfully paired the red LEDs will flash on both sides after 5 seconds.

OPERATION

• While playing music, double press either MFB button to pause, press again to resume

• Press and hold the right MFB for 1 second for the next song, press and hold the left MFB for the previous song

• The music will pause and the earbuds will ring when there is an incoming call. double Press either MFB button once to answer the call, press and hold for 2 seconds to reject the call. Press again to end a call

4. After initial pairing, the earbuds will automatically turn ON and connect to your device when removed from the charging case, provided both earbuds and your Bluetooth® are ON and within range.

5. If the earbuds are not connected to a Bluetooth® device, they will turn OFF after 5 minutes.

CHARGING CASE

Fully charged:

Provides up to "5" charge to "2.5"

Rated input:

DC 5V, 500mA

Output:

DC 5V, 50mA

Battery capacity:

40mAh

IP rating:

X4 (add: earbuds)

OPERATING INSTRUCTIONS

Prior to first use, remove the plastic battery isolator tab located between the earbuds and the charging case.

CHARGING THE EARBUDS

Place both earbuds in the charging case, they will automatically begin charging and the red LED on the earbuds will turn ON. When the earbuds have fully charged, the LED will turn OFF. It will take approximately 1.5 hours to fully charge the earbuds. The charging case provides up to "3" charge to "2.5".

PAIRING

The earbuds will automatically enter Bluetooth® pairing mode when used for the first time. The left and right earbuds will automatically connect to each other.

1. Remove both earbuds from the charging case. The red and blue LEDs will flash to indicate the earbuds have powered ON.

2. Select "HRB 3038" on the Bluetooth® device list to pair the earbuds automatically.

3. When the earbuds have successfully paired the red LEDs will flash on both sides after 5 seconds.

OPERATION

• While playing music, double press either MFB button to pause, press again to resume

• Press and hold the right MFB for 1 second for the next song, press and hold the left MFB for the previous song

• The music will pause and the earbuds will ring when there is an incoming call. double Press either MFB button once to answer the call, press and hold for 2 seconds to reject the call. Press again to end a call

4. After initial pairing, the earbuds will automatically turn ON and connect to your device when removed from the charging case, provided both earbuds and your Bluetooth® are ON and within range.

5. If the earbuds are not connected to a Bluetooth® device, they will turn OFF after 5 minutes.

CHARGING CASE

Fully charged:

Provides up to "5" charge to "2.5"

Rated input:

DC 5V, 500mA

Output:

DC 5V, 50mA

Battery capacity:

40mAh

IP rating:

X4 (add: earbuds)

OPERATING INSTRUCTIONS

Prior to first use, remove the plastic battery isolator tab located between the earbuds and the charging case.

CHARGING THE EARBUDS

Place both earbuds in the charging case, they will automatically begin charging and the red LED on the earbuds will turn ON. When the earbuds have fully charged, the LED will turn OFF. It will take approximately 1.5 hours to fully charge the earbuds. The charging case provides up to "3" charge to "2.5".

PAIRING

The earbuds will automatically enter Bluetooth® pairing mode when used for the first time. The left and right earbuds will automatically connect to each other.

1. Remove both earbuds from the charging case. The red and blue LEDs will flash to indicate the earbuds have powered ON.

2. Select "HRB 3038" on the Bluetooth® device list to pair the earbuds automatically.

3. When the earbuds have successfully paired the red LEDs will flash on both sides after 5 seconds.

OPERATION

• While playing music, double press either MFB button to pause, press again to resume

• Press and hold the right MFB for 1 second for the next song, press and hold the left MFB for the previous song

• The music will pause and the earbuds will ring when there is an incoming call. double Press either MFB button once to answer the call, press and hold for 2 seconds to reject the call. Press again to end a call

4. After initial pairing, the earbuds will automatically turn ON and connect to your device when removed from the charging case, provided both earbuds and your Bluetooth® are ON and within range.

5. If the earbuds are not connected to a Bluetooth® device, they will turn OFF after 5 minutes.

CHARGING CASE

Fully charged:

Provides up to "5" charge to "2.5"

Rated input:

DC 5V, 500mA

Output:

DC 5V, 50mA

Battery capacity:

40mAh

IP rating:

X4 (add: earbuds)

OPERATING INSTRUCTIONS

Prior to first use, remove the plastic battery isolator tab located between the earbuds and the charging case.

CHARGING THE EARBUDS

Place both earbuds in the charging case, they will automatically begin charging and the red LED on the earbuds will turn ON. When the earbuds have fully charged, the LED will turn OFF. It will take approximately 1.5 hours to fully charge the earbuds. The charging case provides up to "3" charge to "2.5".

PAIRING

The earbuds will automatically enter Bluetooth® pairing mode when used for the first time. The left and right earbuds will automatically connect to each other.