
User guide for Remote Control RC3662811/01BR

1. Know your Remote



2. BLE Manual Pairing

Step 1: input 2*AAA batteries to Battery compartment.

Step 2: point the remote to the STB IR receiver.

Step 3: Pressed & hold <<SENTRICS MENU>> & << Digit 1>> keys for more than 3 seconds.

If pairing is successful, the STB LED will blink 2x (short pulse).

If the pairing is unsuccessful, the Both STB & TV LED will blink 4x (short pulse).

The remote can be unpaired by pressing <<SENTRICS MENU>> & <<DIGIT 9>> for more than 3 seconds. The STB LED will blink 2x (short pulse) if un-pairing is successful.

3. Voice Function

RCU features a button to activate the Voice Search application to search for content by speaking through the remote's built-in microphone.

FCC information:

FCC ID:2AGOFRC366C

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

FCC Caution

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC information:

This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

RF exposure statement

This equipment complies with the FCC and ISED radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-

located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme aux limites d'exposition aux rayonnements de la FCC et de l'ISED é tablies pour un environnement non contrôlé. Cet émetteur ne doit pas être co-localis é ou fonctionner en conjonction avec une autre antenne ou un autre émetteur.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d' Innovation, Sciences et Développement é conomique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisé e aux deux conditions suivantes:

- 1. L'appareil ne doit pas produire de brouillage;
- 2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement.