

**USER MANUAL**  
**VEHICLE LOCATING SYSTEM**  
**BLE 12**

AutoMap,LLC

275 SE 24th Ave, Hillsboro, OR, 97123, US

AutoMap's BLE12 is a OBD-II Bluetooth BLE 4.0 transmitter placed into the OBD port in a vehicle.

Upon receiving power the BLE 4.0 begins to send out a broadcast signal which contains data packets with 32 bits of information pulled from the vehicle's onboard computer. The signal repeats on a 0.75 second interval, and can only be read by a receiving unit (smart phone capable of Bluetooth 4.0) at an approximate range of 30 yards. The use of the device is to allow automotive dealers and the financial institutions funding their inventory access to the current location of the in questioned assets.

## FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.