

Thank you for choosing our stereo sports Bluetooth earphone.

This user manual will tell you the specifications of it and how to use this earphone correctly.

Before using this earphone, please firstly get to know the Bluetooth function of your cellphone or other Bluetooth facilities, e.g. Bluetooth function of the pad or computer.

ATTENTIONS:

To ensure your safety, please operate according to this user manual. Before using this Bluetooth earphone, we strongly recommend you to finish reading this manual.

Please do not disassemble or repair the product yourself. It may lead to electronic components broken-down or damage the product thoroughly, or even cause injury. And these inappropriate operations are not included in the warranty.

Please do not use alcohol or other volatile liquid to wipe this product. It is not water-proof. Please take care of it when using and keeping.

Please do not use this product at dangerous places, e.g. thunder weather etc.

Please do not listen to music using the earphone more than 2 hours in order to not hurt your hearing. In order to protect your hearing better, please do not turn on the volume to the biggest.

Accessories


Bluetooth earphone——1 pcs

USB charging cable——1 pcs

Ear cap——6 pcs (L/M/S)

Ear hook——6 pcs (L/M/S)

User manual——1 pcs



Instructions

According to individual demand, try different dimensions of ear caps (large, medium and small size), to match with ears properly to ensure high quality bass effect.

According to individual comfort, rotate the ear hook and earphone to adjust angle to achieve the most comfort and stability.

Round the earphone behind your neck to achieve comfort and pleasure.

You can choose to use the cord according to personal demand and adjust the length of wire.

Turn on and charge:

When the first time you use this new earphone, press the multi-functional button 9, the indicator 7 (which is between button 8 and 9) shines blue, then shines blue and red by turns, then release button 9 and go into matching mode. Open the Bluetooth device in the cellphone and set it to "search for new devices", find and choose KS082. Please enter the password (0000) if necessary or accept the connection.

There are enough electricity for new earphone to support you to finish matching and have some phone calls for first use.

When the battery is low and it needs charging, open the cap on the surface 6 and turn it upside, and plug into USB. Charging time for the earphone is around 2.5 hours, and the indicator turns red when charging, turns blue when finish charging. Please do not use this product during charging.

The battery will die down if the earphone is charged and discharged over and over, and this is normal for all rechargeable batteries. if the product is not used for a long time (e.g. more than one year),please charge it fully before store.

Main functions

Turn on ---matching : long press 9, indicator 7 shines blue----alternate blue and red, start to match when hear the beep and find KS082.

Turn off : long press 9, indicator 7 shines red---dies out, already turn off when beep.

Play/pause: short press 9

Last song:long press 8
Next song: long press 10
Volume- : short press 8
Volume+: short press 10
Pick up/hang up the call : short press 9
Reject the call : long press 9 for about 2 seconds
Last number repeat : double press 9
Microphone silence: long press 10 for about 2 seconds during phone call.
Cancel silence: during phone call (microphone silence) long press 10 for about 2 seconds.
Voice dial: short press 9 and 10 under the connection.
Voice switch : earphone and cellphone switch , long press 9 for 2 seconds during the phone call.

Switch between cellphone and earphone

Three-way calling switch :

- ◆ Pick up the second call and hang up the first one, short press 9.
- ◆ Pick up the second call and wait for the first one, double press 9.
- ◆ Switch the first and second call, double press 9.
- ◆ Hang up the current call, short press 9.

Matching two cellphones at the same time

In paired state:

Start two cellphones connection:

Long press 9 and 10 at the same time.

Turn off two cellphones connection:

Long press 9 and 8 at the same time.

Two cellphones match with KS082 separately (When matching the second cellphone, turn off bluethooth of the first cellphone).

Turn off KS082, open bluetooth of two cellphones.

Turn on KS082, KS082 automatically connects with the last two cellphones at the same time, which have been matched.

Once your cellphone successfully matches with KS082, when you restart it, it will automatically connect the last two cellphones. But some cellphones need authorization to connect, it depend on your own cellphone.

When your cellphone matches successfully with KS082, you can short press multi-functional button 9 to automatically connect the last two cellphones, if you haven't restarted the power supply.

Specifications

Bluetooth version:	V4.0
Audio decoding:	APT-X
A2DP:	A2DP1.2
AVRCP:	AVRCP1.4
HFP:	HFP1.6
CVC version:	CVC 6 th
Charging time:	around 2.5 hours

Indicate of battery power:	IOS(Apple device)
Open distance:	above 10m
Music play time :	around 10 hours (middle volume)
Talking time:	around 12 hours (middle volume)
Standby time:	around 330 hours
Auto-turn off:	without connection for 5 minutes
Charging input:	5V/200mA
battery capacity:	170mAh

Safety instructions

Avoid being isolated in the strong sunlight.
Input voltage can not exceed 5.5V.
Product can not put into water.

Exclude difficulty

Indicators do not shine:
Check whether the device turns on.
Battery may run out and needs charging.

Safety rules

Please do not disassemble or convert the earphone, or it may lead to the product break down or burning down , and these are all not included in the warranty.

Please make the product stay away from water, or it may lead to serious damage. The product itself is not water-proof and product damage due to this is not included in the warranty.

Please do not put the product in too high or low temperature (below 0°C, or above 45°C).

Please avoid using the device indicator near the eyes of children or animals.

Please do not use this product in thunder weather. Thunder may lead to product not working properly and increase the danger of electric shock.

Please do not use this product in rain, hurricane .

When on the plane , in the hospital, at the explode place or potential explode place, you may be asked to shut down the electronic devices and wireless facilities. And please pay attention to related instructions when enter specific places.

Warranty

12 months from the purchase date.

Free service:

Within warranty, customers can contact seller to enjoy free repair service with this warranty card and purchasing proof, if the defect is caused by the product itself.

Below situations are without free warranty:

Without warranty card or repair label of product has been broken.

Disassemble by yourself.

Defect caused by putting into water or dropping or manual damage.

Broken by force majeure.

If you do not use our original accessories or disassemble by yourself or manual damage, or electric power/voltage do not fit the requirements, above situations exceed the warranty conditions.

Warranty card

Customer service data

customer name:

phone number:

address:

product name:

product model:

purchase date:

retailer:

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received,

including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.