

User Instruction Book



Pls Use After Reading Instruction Book!

Functions Instruction

Bluetooth Connecting

- Speaker Power on, open your phone settings, turn on bluetooth button, then choose "search".
- Find "IMA03BSL01" name(that is our speaker name),choose connect, will be ok.
- connecting completely.

Music Playing


When pairing successfully, open your phone music player to play your music, sound will come from the speakers. You may press the speaker buttons to control the music

Press power on/off button-- pause/play the music;
Press volume up button once-- next music; Non-stop pressing-- Volume up;
Press volume down button once-- previous music; No-stop pressing-- Volume down;



Specifications

Item Name: Smart Lighting Speaker
Model: IMA03BSL01
Input: DC 5V, 1000mA
Battery: 3.7V, 7000mAH
Charging Time: 2.5~4h
Inner Speaker Info:
Mega Bass: 3" 4Ω 10W 1.8~20KHz
SNR: ≥85db
Item Size: φ 99*199mm
Weight: 800g

Packing Details



Function Buttons



Button Using Instructions

Lamp Button	1st Press	2nd Press	3rd Press	4th Press	Non-Stop Press 3 Seconds
	Colorful Lighting	White Lighting On	Brighter White Light	Brightest White Light	SOS Alarming RED Light
Volume Up	One Press Next Music	Non-Stop Press Volume Up			
Power On/Off	One Press Pause	Press Again Play		Non-Stop Press Power On/Off	
Volume down	One Press Previous Music	Non-Stop Press Volume Down			
Call Answering Button	One Press Answering	Press Again Hung Up			

Speaker Charging Notes

First time to use the speaker, pls make sure the battery is full; There are 3pcs power indicators, pls recharge it when the 3rd indicator low battery warning; Pls use data cable to charge.(Reminder: Use your mobile adaptor or other 5V output adaptor to charge.) When charging, power indicators on, all indicators on means the battery is full.

Power On/Off

Press the power on/off button 3 seconds, power on;
Speaker working status, press power on/off button 3 seconds, power off.

Frequently Asked Question



Failed to connect:

- To check if the speaker is under Bluetooth connecting;
- Or restart your phone;
- If there are too many Bluetooth devices in your list, pls close them first;
- Disconnect and cancel the last connection, and connect again;



The Volume is too low or not clear:

- Check the speaker volume setting and adjust the volume button;
- If the speaker is low battery, pls recharge first;



Audio Playing not stable:

- Distance is over Bluetooth connecting, move the device into closer distance to your phone;
- Pls check if there is barrier between the speaker and your phones;

Attentions:

Pls use the device under normal working temperature;
Don't put the device under the rain or wet circumstances;

Don't throw, hit or drop the device to damage it;

Don't open or repair the device personally;
Don't change the device design;
Pls use the nominal voltage power to charge the speaker;

High volume will be bad for your ears, pls don't use too louder playing for longer time;
The insurance will be disable if any personal damage or disassembling the speaker.

FCC Warning Statement
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.