



5.33"


Preparing To Play



- 1 Use a coin to remove battery door. Push screw in and turn coin counterclockwise to lift battery door.




- 2 Insert 4 AA alkaline batteries (included).



- 3 Place battery door back in place and use coin to turn screw clockwise to tightly close battery door. Do not over tighten.

- 4 Remove the lid by placing your finger in the circular slot and pressing down on the latch release. Store your letters in the playset when not in use.



- 5 To interact with the Square Panda™ games for the iPad®, place the letters, silver side down, in one of the eight letter slots as instructed by the game.



- 6 Download Square Panda™ games for iPad® from the App Store™.

- 7 Launch a Square Panda™ game.

- 8 The first time you launch a Square Panda™ game, follow the instructions to register your Square Panda™ phonics playset.

Playing Square Panda™

- 1 Power on and the light bars will sequence on and off.



- 2 Follow Instructions on Square Panda™ game to connect and play.



5.33"

IONIC



www.ioniccommunications.com
Fax 513.487.5353
Office 513.281.7800
Cincinnati, Ohio 45219
38 East Hollister Street
Ionic Communications Group, Inc.

PROOFING NOTICE: Ionic Communications Group Inc. has checked this artwork carefully for accuracy. Please review for errors or omissions before reproduction; final review and approval are the sole responsibility of the client. Color proofs or match prints from separator films are encouraged for client sign-off before the press run.

CMYK

PMS

P 96-7C

PMS

PMS

PMS

PMS

PMS

CLIENT SIGNATURE

DATE

APPROVED AS IS

APPROVED w/CHANGES

CHANGE & RESUBMIT

FINAL GRAPHIC – FINAL STRUCTURE – FINAL COPY APPROVALS:

ORIGIN DATE: 12.14.15

REVISION DATE: 12.15.15

RELEASE DATE: 12.15.15

PROJECT#: 3524

IMAGE ID#: SUPPLIED

BLUEPRINT#: SUPPLIED

MECHANICAL INFORMATION:

D2M – ABC! Pad

QUICK START GUIDE no SPT

PRODUCT DESCRIPTION:

HELLO

QUICK START GUIDE:
See inside to
get started!



5.33"

Adult setup is required.

Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.

For Ages 3 years and up.

The playset works with the 3rd, 4th generation of iPad®, all models of iPad Air®, iPad mini®, and iPad Pro®. iPad® not included.

Care Tips
Clean your playset and letters with a clean damp cloth. Do not use alcohol or ammonia based cleaning products and do not immerse in water.

Square Panda Inc.
935 Benecia Ave.
Sunnyvale, CA 94085

squarepanda.com

Model Number SP-0042

Patent Pending

2016 Square Panda, Inc. All Rights Reserved.
Square Panda is a trademark of Square Panda, Inc.

Apple, the Apple logo, iPad, are trademarks of Apple Inc., registered in the U.S. and other countries.
App Store is a service mark of Apple Inc.

For product support, contact our team at support@squarepanda.com or visit us at squarepanda.com

Play = Learning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including any interference that may cause undesired operation.

CAN ICES-3(B)/NMB-3(B)

This device complies with Industry Canada Licence-exempt RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

CE0359







Designed in USA
Printed in China

8"

OUTSIDE

5.33"

5.33"