

## Technical features and characteristic

the product includes the following features and characteristics:

Mode/Band	Frequency	Power (dBm)
BT	2402-2480MHz(TX/RX)	11
BLE	2402-2480MHz(TX/RX)	9
2.4G WiFi	2412-2472MHz(TX/RX)	23
5G WiFi	5150-5250MHz(TX/RX)	13.5
5.8G WiFi	5725-5850MHz(TX/RX)	16

## RF Exposure Statement (SAR)

This equipment complies with EU, FCC and IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.


Manufacturer: Shanghai Sunmi Technology Co., Ltd.

Address: Room 505, No.388 Song Hu Road, Yang Pu District, Shanghai, China.

MS0504243

## D2s Quick Start Guide 收款机用户指南

### 收款机共有以下三款选配



15.6'' Touch Screen

15.6'' Touch Screen + 10.1'' Customer Screen

15.6'' Touch Screen + 15.6'' Customer Screen

### 极简设置

开启智能商用设备，只需几步

按电源键，屏幕点亮，进入首次开机界面，按提示操作即可。  
本机可选择2种上网模式。

WIFI设置

· 点击【设置】按钮，然后开启WIFI，进入WIFI搜索界面，等待其搜索并列出可用的WIFI热点；  
· 点击要连接的WIFI，若选择一个加密的网络，则需要输入访问密码方可连接。

LAN设置

如何下载 / 使用应用


相关应用可在联网模式下，打开应用市场，浏览并下载应用即可完成安装。

系统预置软件列表

· 应用市场 - 使用指南 - 硬件管家 - 用户反馈 - 远程协助  
· 图库 - 下载 - 计算器 - 系统更新 - 店铺中心  
备注：预置软件列表会随着系统软件的升级而变更

更多使用帮助请阅读机内帮助APP

### 产品简介




电源键

关机状态下，短按开机启动；  
使用状态下，长按2-3秒，可选择关机或重启；  
死机状态下，长按11秒，断电关机。

触摸屏

用于操作员使用的触摸屏。

### 收款机安装



● 打开纸仓门

向上拉打印机把手，纸仓盖自动弹出。

● 连接电源线

将适配器电源接口连接至主机底部电源口。  
将适配器另一头插入市电插座。

● 安装打印机

放入58mm热敏纸并拉出一段于打印纸口外，再盖上纸仓门。

● 打印机

放入58mm热敏纸并拉出一段于打印纸口外，再盖上纸仓门。

### 本产品有毒有害物质名称及含量标识表

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
电路板组件	×	○	○	○	○	○
壳体组件	○	○	○	○	○	○

：表示该有毒有害物质至少在该部件的某一均质材料中的含量均在SJ/T11363-2006规定的限量要求以下。

：表示该有毒有害物质至少在该部件的某一均质材料中的含量超过了SJ/T11363-2006规定的限量要求；但是表上打“×”的部件，其含量超过了因为目前业界还没有成熟的可替代的技术。

对达到或超出环保使用年限的产品，应依据《电子信息产品污染控制管理办法》规定进行回收再利用，不应随意丢弃。

：表示该有毒有害物质至少在该部件的某一均质材料中的含量超过了因为目前业界还没有成熟的可替代的技术。

### 产品保修卡

产品型号:	以下情况都不提供保修:
产品编号:	· 未经授权擅自拆卸维修的产品。
购买日期:	· 产品条码、易碎和玻璃及保修卡涂改、残缺的。
保修期限:	· 未按照说明书的保养说明使用设备所引起的故障。
联系方式:	· 因使用不当而造成的故障、划伤或破损的人为损坏。
公司地址:	· 不可抗拒因素造成的故障或损坏。
联系电话:	· 保修期届满。

### 产品合格证

### 产品合格证

### 注意事项

#### 安全警告

· 请将交流电源插头插入与电源适配器上标识输入相对应的交流电源插座中；  
· 请在温度0°C ~ 40°C范围内使用本设备，并在-20°C ~ 60°C范围内储存设备及配件；  
· 严禁在存有任何潜在爆炸性气体的场所使用；  
· 非专业人员不要随意打开电源适配器，以免发生危险；  
· 此为A级产品。在生活环境，该产品可能会造成无线电干扰。在这种情况下，可能需要用户对于干扰采取切实可行的措施。

#### 关于产品的更换：

1. 用错型号电池更换会有爆炸危险！

2. 更换后的旧电池应交维修人员处置，切勿把它投入火中！

#### 重要安全说明

· 避免在雷电期间安装或使用，否则有被雷电击中的危险；  
· 当您发现有异常气味、过热或烟雾情形下，请立刻切断电源！

#### 建议

· 不要在靠近水或潮湿环境使用，避免液体落入终端中；  
· 不要在极端冷、热环境中使用，例如靠近火源或点燃的香烟；  
· 不要摔、投掷或弯折；  
· 尽量在清洁无尘环境中使用，避免小物品落入终端中；  
· 在未获允许的情况下，不要在医疗设备附近使用。

#### 声明

本公司不对以下行为负责  
· 不在本指南说明的条件下使用和维护所造成的损坏；  
· 对于因选件或耗材（非本公司提供之最初产品或认可产品）造成的损坏或问题；  
· 未经本公司同意，无权进行产品修改或变动；

· 本产品的操作系统支持官方的系统更新，如果用户用了第三方的ROM系统或者采用破解方式修改了系统文件，可能会导致系统不稳定，以及带来安全风险和安全威胁。


#### 免责申明

由于产品的更新，此文档某些细节可能与产品不符，请以实物为准。此文档的解释权归本公司。保留不预先通知的情况下，修改本说明书的权利。

制造商：上海商米科技集团股份有限公司

地址：上海市杨浦区淞沪路388号创智天地7号楼505室

### Three Configuration Options



15.6'' Touch Screen

15.6'' Touch Screen + 10.1'' Customer Screen

15.6'' Touch Screen + 15.6'' Customer Screen

### Easy Setup

Get the device ready for use in a few steps.

1 Press the power button to turn on the screen and enter into the boot interface, then operate following the onscreen instructions.  
The two network modes can be selected for this device.

#### Wi-Fi Setting

· Click the button【Setting】，and enable WLAN to enter into the interface for Wi-Fi searching.Wait for the available Wi-Fi list;

· Click the Wi-Fi to be connected, and a password is required if you want to connect to an encrypted network.

#### LAN Setting

#### How to Download/Use Apps

With network connection, you can download and install apps you need from the App Store.

#### List of System Preset Software

· App Store - Instruction - Pos Steward - Feedback - Remote Assistance  
· Gallery - Downloads - Calculator - System Update - ShopCenter


Note: the preset software list is subject to change due to software update.

For more help, please refer to the Instruction App in the device.

#### Package Items List

· Small terminal x 1  
· Quick start guide x 1  
· Power adapter x 1  
· Printing paper roll x 1

### Product Overview



Power button

Press the button to boot up the device when it is off;


Press and hold the button for 2-3 seconds to power off or reboot the device when it is on;

Press and hold the button for 11 seconds to power off the device when it crashes.

Touch Screen

A touch screen for operators to use.

### Device Installation



● Open the printer cover

As shown in the figure, press the button at the bottom left corner to pop open the printer cover.


● Install the printing paper

Load the 58mm thermal paper and pull out a section outside the cutter, then close the cover.



● Connect the power cable

Connect the power adapter to the power port on the back of the display.  
Plug the other end of the power adapter into the mains socket.



### Attentions

#### Safety Warnings

· Please insert the AC plug into the AC socket corresponding to the input marked on the power adapter;  
· Please use the device within the temperature range of 0°C ~ 40°C, and store the device and accessories within the range of -20°C ~ 60°C;

· It is strictly prohibited to use the device in places with any potentially explosive gas;

· Use the device in a clean and dust-free environment to prevent small items from falling into the device;

· Do not use the device near medical facilities without permission.

#### Declaration

The Company does not assume responsibilities for the following actions:

· Do not use the device near water or in a damp environment to prevent liquid from getting inside the device;

· Do not use the device in extremely cold and hot environments, such as near a source or lit cigarettes;

· Do not drop, throw or bend the device;

· Do not use the device in a clean and dust-free environment to prevent small items from falling into the device;

· Do not use the device near medical facilities without permission.

#### Product Safety Instructions

· Do not install or use the device during lightning storms to avoid the potential risks of lightning shock;

· Cut off the power immediately when you find a suspicious smell, overheating or smoke!

#### PRODUCT SAFETY WARNINGS

To prevent possible injury, please read all instructions and safety information before you use the product.

Operating temperature: 0°C ~ 40°C;

Storage temperature: -20°C ~ 60°C;