

Test positions for body:

According to the antenna position, the Body-worn/hotspot SAR is tested at the following 5 test positions all with the distance =5mm between the EUT and the phantom bottom:





Test positions for Limb:

According to the antenna position, the limb SAR is tested at the following 5 test positions all with the distance =0mm between the EUT and the phantom bottom:

	
Figure 1-6 Front Side mode	Figure 1-7 Back Side mode
	
Figure 1-8 Left Side mode	Figure 1-9 Right Side mode
	
Figure 1-10 Top Side mode	

Test positions for sensor triggering minus 1 mm:

The sensor triggering minus 1 mm SAR is tested at the following 3 test positions with the distance =24&9&14mm between the EUT and the phantom bottom:

	
Figure 1-11 Back Side mode 24mm	Figure 1-12 Left Side mode 9mm
	
Figure 1-13 Top Side mode 14mm	