

Test Configuration Photos

Test positions for Head:




Figure 1 Left Touch



Figure 2 Left Tilt 15°




Figure 3 Right Touch



Figure 4 Right Tilt 15°


Test positions for Body-worn/Hotspot:

According to the antenna position, the Body-worn/Hotspot SAR is tested at the following 6 test positions all with the distance =10mm between the EUT and the phantom bottom:



Test positions for Limb:

According to the antenna position, the Limb SAR is tested at the following 6 test positions all with the distance =0mm between the EUT and the phantom bottom:



Test positions for sensor triggering minus 1 mm:

The sensor triggering minus 1 mm SAR is tested at the following 2 test positions with the distance =29/19mm between the EUT and the phantom bottom:

