

Mini Level

1. Wireless sport bluetooth headphone

2. description

Thank you for using our production Bluetooth headset ,This manual will help you to learn how to use Bluetooth headset. Please read the guide before using the device .

3. Getting Started


Package including : headset*1 ; USB data cable*1 , instruction*1 ;

Device attached accessories may be different with your region or service provider

attached accessories are designed for this device May be not compatible with other devices

Use the only parts of our company allows .When using the unauthorized accessories and cause problems ,This situation is not under the warranty .

4. Getting to know it



1.Charging port

2.Power on/off


3.Led light

4.Play/pause/Answer/Hang up/reject/ Redial/pairing/Disconnect

Mini Level

5.Pairing and connection

Pairing one mobile phone




1: open the “ Mini Level “ power switch, Move the switch to the ON file ,The headset automatically enters pairing mode .then the red and blue lights flashing alternately

2..Turn on the Bluetooth on the device has Bluetooth capabilities and search Mini Level,

As long as the device and the headset is paired, turn on the headset will automatically connect a single device


Using the touchpad

Use the right headset touch panel control of the connected devices function




Mini Level

Volume up
Slide up the touch panel



Volume up
Slide down the touch panel



Previous song

Slide front the touch panel

next song

Slide up the touch panel

Calling function : Hang up and answer : Click once
Reject :Press three seconds continue

Pairing 2 mobile phones


1. Open the headset power switch, connect the headset with a mobile phone with Bluetooth-enabled
2. After the successful connection with the first mobile phone ,Press the multifunction key continue ,Headset will enter pairing state again and disconnect the first mobile phone ,then the red and blue lights flashing alternately
3. Search “Mini level “ with a second mobile phone with a Bluetooth-enabled, find out the device and connect it
4. Manual Connect the device on the first mobile phone .

For the charging

1. The device is equipped with a built-in battery.
2. Charger and USB data cables must with the company licensing .Without permission of the USB power adapter cable or USB cable will cause the battery explosion or equipment damage.
3. If the earphone is totally discharge, it will not be able to start immediately when we connect the charger.
4. Please charge the earphone for a few minutes before use it. When the battery is run out
5. Please Connect the computer or USB Power adapter cable With USB Cable
6. The equipment was charging with red indicator light , charging completed with blue.

Power indicator

When the earphone was connected with your IOS system devices, the current power will shown on the top right corner of your devices .



Automatic shutdown

When the earphone and phone beyond pairs, earphone will shutdown automatically after 10 minutes .

Troubleshooting

The device is not open.

When the battery is run out , the device cannot open , please charge the battery before open the earphone .

Bluetooth earphone cannot found by mobile phone

Ensure the bluetooth is in match mode.

The distance should ensure that your equipment and other bluetooth devices within the scope of bluetooth connection (10 meter).

Bluetooth connection disconnected often

if there have obstacles between devices , effective distance may be shortened

The distance should ensure that your equipment and other bluetooth devices within the scope of bluetooth connection (10 meter).

Cannot hear from others by call with earphone

Adjust the devices' volume

When use the devices,You still cannot hear from others with biggest volume ,please Please adjust the volume of the connected devices.

Echo was sounded by call with earphone

Press the volume keys to adjust the volume or move to another area

Cannot hear from you by call with earphone

Make sure not to cover the microphone

Cannot hear clearly

Wireless service may be forbidden by the service provider's network problems, ensure the equipment away from electromagnetic waves.

The distance should ensure that your equipment and other Bluetooth devices within the scope of Bluetooth connection(10 meter).

NOTE: This equipment has been tested and found to comply with the limits for a

Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference
- (2) this device must accept any interference received, including interference that may cause undesired operation.