

MDC2-1004-BLK Manual Artwork

Dimensions: 546.975mm x 95mm
Print 4 color, 2 sided, accordion fold



Introduction

Thank you for choosing the Monster 2K QHD Smart Dash Camera! This WiFi-enabled camera records your drive in stunning 1440P HD quality, so you never miss a detail. Easily access your footage and other helpful features through the free, user-friendly app. Featuring a discreet design and seamless technology, your camera will provide you with peace of mind on every journey. Drive smarter with Monster!

Features

- Record and take photos of your car exterior
- Connect to your phone with WiFi
- Download the footage via the free app or a MicroSD (not included)
- Record and protect collision footage with G-Sensor and Parking Monitoring

What's Included

- 2K Smart Dash Camera
- Mount
- 12ft 12V DC Power Adapter
- Manual

What You Need

- Mobile device with WiFi enabled (requires iOS 12 or Android 11 and above)
- MicroSD card (256GB Max)

Safety Warnings

Please read all instructions before using this product. If damage is caused by failure to follow the instructions, the warranty is null and void.

Dash Cam Recording Tips:

- Recording quality can be affected by lighting conditions such as directly facing bright sunlight, entering/exiting darkness, and tinted windshields.

- Recording quality can be affected by a dirty lens or windshield. Ensure that the lens and windshield are free from dirt and foreign material.

Important Safety Information and Care Tips:

- Exercise all due caution when using this product and obey all applicable traffic laws.
- Do not install the product in a location where it can interfere with the driver's vision of the road and surroundings, or interferes with vehicle operating controls.
- Do not place the unit on the vehicle's dashboard.
- Never attempt to take pictures, view recordings, or adjust the product while driving.
- Do not expose the product to rain or moisture, and do not use near water such as swimming pools, bathtubs, or sinks.
- Do not expose the product to excessive heat.
- Do not use the product in a strong magnetic field.

KEEP YOUR ATTENTION ON THE ROAD. DO NOT OPERATE THIS PRODUCT WHILE DRIVING.

At a Glance

1. Mount Port	11. Power On / Off
2. USB-C Port	12. Display Screen
3. MicroSD Port	13. Microphone
4. Up/Right Arrow	14. Reset Button
5. Menu / Delete / Lock / Unlock	15. Camera Mount Suction Cup
6. Down / Left Arrow	16. Camera Mount Locking Lever
7. Camera Lens	17. Camera Mounting Clip
8. Ok / Select	18. Power Cord USB-C Connector
9. Camera / File Management / Go Back	19. Power Cord 12V DC Connector
10. Lock File Button	

How to Use

Quick Start

- Remove the package contents.
- Insert a MicroSD card up to 256GB (not included) into the MicroSD reader and press down firmly to secure. Note: Camera will not record without a MicroSD card.
- Plug the USB-C end of the included power cord into the camera's USB-C port. Plug the other end into your car's 12V DC port (cigarette port).
- Start your engine to automatically power on the camera. You should see a blinking red camera icon with a timer on the top left of the screen, which indicates the camera is now recording.
- The camera will automatically power off when you turn off your car engine. To manually power off the camera, press and hold the Power On/Off button.

Installation

- Insert the mount into the camera's mount port with the mounting clip nub positioned on the right. Slide the mount to the right to fasten it. Check to make sure it is secure.
- Choose where you want to place the camera on your windshield and wipe the area with a clean cloth. Recommended: Choose a location near the rearview mirror that will provide a clear picture of the car exterior without obstructing the driver's view.

Access Saved Recordings:

- When the camera is powered on, press and hold the Camera Button for 2 seconds until it switches to the File Management screen. Here you can view your saved and locked videos.
- Saved Videos:** Once you have reached the File Management screen, press the OK Button Twice and use the Up/Down Arrows to scroll through your saved videos.
- Saved Photos:** Once you have reached the File Management screen, press the OK Button then press the Down/Left Arrow twice to reach your saved photos. Press the OK Button again, then use the Up/Down Arrows to scroll through the photos.
- Saved Photos:** Once you have reached the File Management screen, press the OK Button. When you are done viewing the photo or video, press the Camera Button to return to the File Management screen.
- Saved Photos:** Once you have reached the File Management screen, press the OK Button until the camera reboots to the recording mode.
- Saved Photos:** Once you have reached the File Management screen, press the OK Button until the camera reboots to the recording mode.

How to Use

File Management

Front

2501012307.f.ts

2501012207.f.ts

2501012107.f.ts

2501012007.f.ts

2501011907.f.ts

2501011807.f.ts

2501011707.f.ts

2501011607.f.ts

2501011507.f.ts

2501011407.f.ts

2501011307.f.ts

2501011207.f.ts

2501011107.f.ts

2501011007.f.ts

2501010907.f.ts

2501010807.f.ts

2501010707.f.ts

2501010607.f.ts

2501010507.f.ts

2501010407.f.ts

2501010307.f.ts

2501010207.f.ts

2501010107.f.ts

2501010007.f.ts

2501010907.f.ts

2501010807.f.ts

2501010707.f.ts

2501010607.f.ts

2501010507.f.ts

2501010407.f.ts

2501010307.f.ts

2501010207.f.ts

2501010107.f.ts

2501010007.f.ts

2501010907.f.ts

2501010807.f.ts

2501010707.f.ts

2501010607.f.ts

2501010507.f.ts

2501010407.f.ts

2501010307.f.ts

2501010207.f.ts

2501010107.f.ts

2501010007.f.ts

2501010907.f.ts

2501010807.f.ts

2501010707.f.ts

2501010607.f.ts

2501010507.f.ts

2501010407.f.ts

2501010307.f.ts

2501010207.f.ts

2501010107.f.ts

2501010007.f.ts

2501010907.f.ts

2501010807.f.ts

2501010707.f.ts

2501010607.f.ts

2501010507.f.ts

2501010407.f.ts

2501010307.f.ts

2501010207.f.ts

2501010107.f.ts

2501010007.f.ts

2501010907.f.ts

2501010807.f.ts

2501010707.f.ts

2501010607.f.ts

2501010507.f.ts

2501010407.f.ts

2501010307.f.ts

2501010207.f.ts

2501010107.f.ts

2501010007.f.ts

2501010907.f.ts

2501010807.f.ts

2501010707.f.ts

2501010607.f.ts

2501010507.f.ts

2501010407.f.ts

2501010307.f.ts

2501010207.f.ts

2501010107.f.ts

2501010007.f.ts

2501010907.f.ts

2501010807.f.ts

2501010707.f.ts

2501010607.f.ts

2501010507.f.ts

2501010407.f.ts

2501010307.f.ts

2501010207.f.ts

2501010107.f.ts

2501010007.f.ts

2501010907.f.ts

2501010807.f.ts

2501010707.f.ts

2501010607.f.ts

2501010507.f.ts

2501010407.f.ts

2501010307.f.ts

2501010207.f.ts

2501010107.f.ts

2501010007.f.ts