

1. Photographs of Test Configuration

The initial test position. +Z axis. Phi and Theta are zero degree.

For EUT 1





For EUT 2





For EUT 1:

Test Setup Photos




For EUT 2:

Test Setup Photos




2. Antenna Configuration Diagram of EUT

For EUT 1:



For EUT 2:



————THE END————