FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2AHGI-306B

Manufacturer: Dongguan Lisong Electronics Co., Ltd. Address: Lianping Village, Dalingshan Town, Dongguan

Tel: 86-769-38811211(ext-8221)

Fax: 86-769-22653590

Website: http://www.lisong.com.cn





Quick guide for using stereo Bluetooth wireless headset 306BD



MARROW Stereo Bluetooth Wireless headset







Description of Function Compound Key One single push towards the One single push towards the left – function of next song/long right – function of previous push - volume "-" song/long push - volume "+" Press the midpoint - play/pause/call function

Headset charging

The headset has built-in rechargeable battery. Before the first use, it is recommended to fully charge the headset. Insert the matching USB cable into charging port of the headset, and the other end into USB interface of desktop/USB interface of laptop or USB interface of mobile charger (confirm to be DC 5V). The indicator light turns red during charging and the charging light is off automatically after charging.

Note: Do not replace the built-in lithium battery arbitrarily to avoid headset damage.

Boot pairing

Slide the power switch to "ON" or "LED-OFF" to turn on Bluetooth (the dazzling light is on in "ON" position and off in "LED-OFF" position), at which time the Bluetooth pairing light flashes quickly. Turn on Bluetooth function of cellphone according to the mobile manual and search, and confirm pairing when any headset model is displayed on the phone, after which the pairing light will flash slowly, the headset will give a long sound of "Beep", and successful pairing will be displayed on the phone. (For pairing failure after trying for a long time, please slide the power switch to "OFF" position, and start up and try for pairing again 3s later.)

Music play

After successful pairing of cellphone and headset, play music with music player of cellphone. It is recommended to adjust the volume to the maximum since the headset is subject to volume control; for volume up, press volume "+", and for volume down, press volume "-". Select to play by pressing the previous song or next song, enter pause mode by pressing pause once in play state, and resume play by pressing play again in pause state.

Answer calls

Answer by pressing the headset talking key once when hearing ring tone, and end call by pressing the talking key once during call.

Button control

necessary to adjust the volume, push the function compound key towards the direction of up, down " — " for a long time to realize adjustment. When it is necessary to select a song, push the function resetting key towards " HT / HT " once to select the previous or next song. Press the button center down once (go to pause during play, resume play during pause). When there is a call, press button center of function compound key down once to answer (end call by pressing once during call).

Note: Volume of the phone will have direct influence on volume of the headset.

Prompt: When hearing the sound of "Beep" from the speaker during use, it indicates the cellphone is in low battery mode, so please charge promptly. When pressing volume "+" key to adjust the volume to the maximum, there will be short sound of "Beep".