

Pool Party Animal Amphibious User Manual

Battery installation

For Animal Amphibious:

Remove the screw and open the battery cover.

Insert 3x 1.5V AAA Alkaline batteries and close the battery cover.


Put the screw back and lock the battery cover.

For Remote Controller:

Remove the screw and open the battery cover.

Insert 2x 1.5V AAA Alkaline batteries and close the battery cover.

Put the screw back and lock the battery cover.



Operation procedure

Put the animal amphibious on the water and make sure the frequency docking successfully when the animal amphibious and the controller are turned on.

The animal amphibious can also be played on land.

Use the remote controller to control the animal amphibious.

The animal amphibious will move forward when you press the button in left side.

The amphibious will turn left and move backward when you press the button in right side.



Pool Party Animal Amphibious User Manual

Notes:

Please make sure the animal amphibious and remote controller within 8-10 meter range.

Age Recommendation: 10+ years and adult supervision required.

If you do not play the animal amphibious, you must remove the batteries from both of the remote controller and the animal amphibious

Packaging includes:

Animal amphibious unit 1pc (2 assortment – Flamingo / Unicorn)

Remote controller unit 1pc

Product dimension:

Flamingo unit: 5.5”W x 3”D x 5”H / Unicorn unit: 6.75”W x 3”D x 6”H

Remote controller unit: 3.5”W x 2.5”D x 1.25”H

Description:

Remote controller batteries: 2 x 1.5V AAA Alkaline batteries are not included

Animal Amphibious batteries: 3 x 1.5V AAA Alkaline batteries are not included

Range: 8-10 meters

Duration: about 12mins

Suitable for children of 10 years old or above

Place the animal amphibious on the water before playing.

The animal amphibious will malfunction if submerged underwater.

For safety, do not touch the propeller when the animal amphibious is on the water.

Place amphibious on the water before playing



The amphibious will malfunction if submerged underwater



For safety, do not touch the propeller when the amphibious is on the water.



Place amphibious on the water before playing



The amphibious will malfunction if submerged underwater



For safety, do not touch the propeller when the amphibious is on the water.



Pool Party Animal Amphibious User Manual

FCC ID on 27 MHZ frequency: 2AHGJJMSDB2111-27-1 (Flamingo)

FCC ID on 49 MHZ frequency: 2AHGJJMSDB2111-49-1 (Unicorn)



This device complies with Part 15 of FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for the compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part, 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Warning statement:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

Conforms to ASTM F963-17

For AAA Batteries:

⚠️ WARNING: TO AVOID BATTERY LEAKAGE

- 1) The batteries used with this product are small parts and should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone American Association of Poison Control Centers (1-800-222-1222).
- 2) Always purchase the correct size and grade of battery most suitable for intended use.
- 3) Do not mix old and new batteries, alkaline, standard (Carbon - Zinc) or rechargeable (Nickel-cadmium) batteries.
- 4) Clean the battery contacts and those of the device prior to battery installation.
- 5) Ensure the batteries are installed correctly with the regard to polarity (+ and -).
- 6) Always remove batteries if consumed or if product is to be left unused for a long time.

Distributed by 1616 Holdings, Inc.
701 Market Street, Suite 200
Philadelphia, PA 19106
Made in Shantou, China

Tracking Number: JM011020



1 92234 04807 8