Vayyar Home Dry Contact Installation Guide







Proprietary Data Copyright 2021 Vayyar Imaging Ltd. All rights reserved.

This document is the property of Vayyar and all materials and information contained herein is the proprietary information of Vayyar and are protected by international copyright laws. The copyrights are owned by Vayyar or the original creator of the material. The materials and information contained herein are provided to you for internal information purposes only, and no portion of the materials and information herein may be copied, reproduced, distributed, transmitted, displayed, published, broadcasted or used in any way whatsoever directly or indirectly without the prior written consent of Vayyar or in any case of third party materials, without that third party's consent. This document shall be returned to Vayyar promptly upon request. The materials and information contained herein are provided "AS IS" and Vayyar does not provide any warranties of any kind, whether express or implied, including but not limited to implied warranties of merchantability, fitness for a particular purpose, and non-infringement.


What's included:




Sensor



Back cover



Chassis with adhesive strips



▶ Front cover



> 3 x self-tapping screws

Note: Recommended that the installation be done by a professional installer. Always abide by local regulations.

You'll also need:




Pencil

▶ Wire stripper



Wall plugs& screws

► 12/24 VDC Power Supply




Transmitter and cables Precision screwdriver

In-wall installation




Mark a line on the wall, measured 1.5m/5ft from the floor, where you plan to attach the sensor to the wall.





Note: The 1.5m/5ft mark should align with the center of the device.

1.5m/5ft


Using the front cover as a template, draw a circle with the line going through the center.









Wrap the cable over the ribs and into the slot.




Insert the
Type-C USB
Connector to
the bottom of
the board on
the back of the
Chassis.






Connect the dry contact alarm from the transmitter* to the Vayyar Home dry contact board.

*Transmitter not supplied by Vayyar






The transmitter cables should be connected to the bottom first (GND) and third (ALARM 1) locations on the board. Do not attach the cables at locations directly next to each other.

Connect the sensor to the electrical supply*.

*Note: It is important to connect the transmitter before connecting the electrical supply.




The electrical cables should be connected to the bottom eighth (12/24V IN) and sixth (GND) locations on the board. Do not attach the cables at locations directly next to each other.


Test the device, before completing wall installation:

- If your device is pre-provisioned, make sure the device is powered ON and you see a white light from the LED
- If your device is NOT pre-provisioned, please reference the provisioning instructions provided by the Vayyar Home Customer Success team
- Once pairing is complete & power is confirmed, simulate the dry contact is working by pressing the power button for 2-seconds

Attach the chassis to the wall with screws.



Attach the front cover to the chassis and align as shown, until it snaps into place.






Assembly is complete.




On-wall installation







Wrap the cable over the ribs and into the crease.




Insert the USB connector.



With a spirit level, mark a line 1.5m/5ft from the floor on the wall where you want the sensor.




1.5m/5ft




Mark drill-hole positions on the wall, including one in the middle for the cable.

WALL PARALLEL


Drill and insert wall plugs in line with the holes in the back cover.



Attach the back cover to the wall with screws.





(Optional) Connect a dry contact alarm to the sensor.



Pass the cable through the bottom-center of the device, there should be a specific opening in the back cover for the cable in this location (see illustration).


The transmitter cables should be connected to the bottom first (GND) and third (ALARM 1) locations on the board. Do not attach the cables at locations directly next to each other.






Note: Make sure the voltage reaching the system is under 5 volts.


Connect the sensor to the electrical supply.






The electrical cables should be connected to the bottom eighth (12/24V IN) and sixth (GND) locations on the board. Do not attach the cables at locations directly next to each other.


Attach the chassis to the back cover with the snap-fit lugs (to ease installation).




Attach the chassis to the back cover with screws.



Attach
the front
cover to
the chassis
with the
snap-fit
lugs.







Assembly is complete.








Peel the stickers from the chassis and attach the sensor in place.


THIS SIDE UP

ROLL CABLE THIS WAY


Wrap the cable over the ribs and into the crease.




Insert the USB connector.




Orient the back cover according to the room wall widths – the top arrows should be parralel to the x-axis.






Drill holes for wall plugs and insert Y axis X axis (Wide side of room) (Narrow side of room) them.


Attach the back cover to the ceiling with screws.



Alternatively, attach the back cover using cable ties/hose clamps.


8 Connect the sensor to the electrical supply.






The electrical cables should be connected to the bottom eighth (12/24V IN) and sixth (GND) locations on the board. Do not attach the cables at locations directly next to each other.


9 (Optional) Connect a dry contact alarm to the sensor.




Pass the cable through the bottom-center of the device, there should be a specific opening in the back cover for the cable in this location (see illustration).


The transmitter cables should be connected to the bottom first (GND) and third (ALARM 1) locations on the board. Do not attach the cables at locations directly next to each other.







Align the holes between the parts according to the required orientation







Attach the chassis to the back cover with the snap-fit lugs (to ease installation).





Attach the chassis to the back cover with screws.











Disassembly instructions




Release the snap-fit joint by inserting a flat-headed screwdriver into the top slot.




Detach the screws from the chassis.




Push the snapfit lugs towards the center and mannually detach the chassis from the back cover.



Detach the elctrical cable from the sensor.



Unscrew the screws from the wall/ceiling to detach the back cover.



FCC Statement

FCC Interference Statement This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter. For product available in the USA/Canada market, only channel 1~11 can be operated. Selection of other channels is not possible. FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body





For questions about Vayyar Home™

Email: homesupport@vayyar.com



Vayyar Home Dry Contact Installation Guide Vayyar.com

