


Guldance

Thank you for purchasing and using our T10 wireless earbuds. Before using T10, Please read user manual carefully.

Description of product structure



Wearing way

Please put the earbuds Into the cochlea gently, and adjust to the suitable angle.

Turn on , Pairing the Wireless

- 1. Tun on method 1 : When the earbuds are charging in the charging case ,take out the left and right earbuds , they will turn on and pair automatically .
- Turn on method 2: When the earbuds are not in the charging case and it is off ,long press the left and right Multi-function button for 3 seconds to turn on. Then they will pair outpreption. automatically.
- After the two earbuds pair successfully, the right one enters into the pairing model and orange and white light flickers alternately Then turn on the Bluetooth function of your phone and search the name T10. And then pair. They will get paired successfully when earphone prompt tone reminds "connected". For later use, just need to pair according to the first and second step. T hearbuds will connect automatically with the phone which was connected with last time. If the phone is not nearby or its Bluetooth fuction is off, the earphone will enter into searching mode. (The right earphone oranged and white light flickers alternately).

1) The pairing model lasts for 5 seconds . If they can not pair , the earbuds will turn off . And then , pis do as the 1-3 steps .

 If the earbuds are taken away from the phone without the transmission range, it will disconnect. After the earbuds is taken back within the transmission range , they will get pair again automatically .

Method 1 : Put the earbuds into the charging case and then it will turn off automatically . (If the charging case is out of battery, the earbuds will not turn off automatically).

Method 2: In the non-music status, Long press 3 seconds of each earphone, orange light flickers for 1 second, and then the earbuds turn off.

Answering a call

Short press either of the mulit-function button

Ending a call

Short press either of the mulit-function button;

Rejecting a call

When phone call is coming , long press either of the mulit-function button.

Call Siri

The earbuds in standby model, double press the mulit-function model to turn on or turn off Siri (This feature is limited to the ISO system).

Music play:

1. On/Pause : Short press the Mulit-function

True Wireless Stereo Earbuds Manual

- 2. Previous song : Long press the Left button
- 3. Next song : Long press the right button for 28.
- 4. Play automatically: Receiving a call in music mode, it will revert to the music mode automatically after phone conversation ends.

Charge for the charging case:

When the charging case is in charge, the crange light will be on . When it is fully charged , the white light will be on .

Charge for the earbuds:

1. When the earbuds attery is lower than
3.3\forall the campa lig will micker quickly and
there is pompt towneof "battery lowow"
2. Put the campuds in-to the charging case to
change, the crampe light will be on during
charging. The change light will be off after
fully changed.

Product Parameter

Product Components:

1, T10 Wiraless earbuds · · · · · 1 set

2. Charging case ----- 1 set

Earphone size: 46.4x18.5x19.5cm Charge box size: 64.5x57x27mm Version: V5.0 T ransmissiondistance: 10m

- Input voltage: DC 5V Battery capacity:3.7v/40mAh Charge box capacity:3.7V/500mAh
- Earphone Charging time:<=2H Play time: 4H Charge box charge time:3H
- Earphone weigh: 5.3g(each) Whole set weigh:48.7g ISO electric quantity: support

Technical solution:

If your Wire less exphone can't be paired with your phone, try thefollowing steps: Please make sure the earbuds is fully charged; Please make sure the earphone is power on; Please make sure the earbuds is not paired

with other devices; Please make sure the mobile phone BT function is enabled, and BT function has

already been on; Please make sure that the distance between the earuphne and mobile phone is within 10

mete rs;
If the above steps can't help solve the problem please restart your earbuds and mobile phone;

>Press the MBF for 5 times, (orange and white light fix wite at the same time) and then short press both of the searbufs to forcibly get into paining mode. After they pair successfully, they will turn off automatically.

Safety criterion:

- Do not disassemble or modify the device for any reason, or may cause the earbuds to breakdown or burn
- 2. Do not drop the product to any liquid or
- wash in water
 3. Do not charge the earphone with charger
 which is over-voltage. Ensure your charger is
 limited within 5V/1A. Or it will damage the
- 4. Do not place the device in an environment where the temperature is too high or too low (Below 0 degrees or above 45 degrees) 5. Do not block any mouth of sarphone, such as charging interface, LED indicator or
- microphone.

 6. Do not use the earphone overtime and over-volume, or it w vifiake you feel dizzy or damage your hearing.

 7. Do not use the : pelpm it unifienthunder-storm environment. Thunderstorm may cause abnormal operation of equilipment, signal interruption, etc.

THANK YOU!

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.